



Entegra and Envision
EX5000 Series MFD
Release 8.2

Installation Manual

Models

700-00004-()

700-00030-()



P/N 600-00073-001

Document Revision History

Date	Revision No.	Description
February 21, 2018	00	Initial Release
June 04, 2019	01	Software Update 8.2.2
June 08, 2019	02	Appendix Q Wiring Diagram Update

This document is applicable to the following part numbers:

Hardware Part Number 700-00030-() - Landscape MFD

Hardware Part Number 700-00004-() - Portrait MFD

Software Part Numbers:

530-00235-000 SW, EX5000, RELEASE 8.2, PIPER PA46/PA34 (4 KNOB)

530-00235-002 SW, EX5000, RELEASE 8.2, PIPER PA28/PA32/ PA44 (2 KNOB)

530-00235-100 SW, EX5000, RELEASE 8.2, CIRRUS (2 KNOB)

530-00235-200 SW, EX5000, RELEASE 8.2, COLUMBIA (2 KNOB)

530-00235-500 SW, EX5000, RELEASE 8.2, LANDSCAPE AFTERMARKET WITH RADAR (4 KNOB)

530-00235-502 SW, EX5000, RELEASE 8.2, LANDSCAPE AFTERMARKET WITHOUT RADAR (2 KNOB)

The latest revision of the Entegra EX5000-Series MFD Installation Manual is available to authorized Avidyne dealers at www.avidyne.com.

Avidyne®, FlightMax®, and TCAD® are registered trademarks of Avidyne Corporation.

CMax™ and EMax™ are trademarks of Avidyne Corporation.

Stormscope® and Skywatch® are registered trademarks of L-3 Communications.

1. About the EX5000 MFD	7
1.1 Standard Functionality.....	7
1.2 Optional Functionality	7
2. General Information	9
2.1 Equipment Description	10
2.2 MFD Technical Specifications	11
2.3 TSO Information	12
2.4 Configuration Options	15
3. MFD Configurations.....	23
4. Installation Planning	24
4.1 Location and Viewing Angle	24
4.2 Cooling.....	24
4.3 Mounting the MFD.....	24
4.4 Electrical and Sensor Interfaces	24
4.4.1 Wiring Notes.....	25
4.4.2 Weight and Balance.....	25
4.5 Electrical Load Analysis	26
4.5.1 Broadcast Antenna Details	26
4.6 Wiring External Devices	26
4.6.1 GPS and FMS Wiring	26
4.6.2 Dual GPS Setup with GAMA 429	26
4.6.3 FIS-B Weather and ADS-B Traffic Receiver Wiring.....	26
4.6.4 XM Broadcast Datalink Receiver Wiring.....	27
4.6.5 Lightning Sensor Wiring	27
4.6.6 Traffic Sensor Wiring	27
4.6.7 TAWS Wiring.....	28
4.6.8 Map Configuration	28
4.6.9 Radar Sensor Wiring.....	29
5. MFD Feature Setup and Checkout.....	30
5.1 Preliminary Test.....	30
5.2 Optional MFD Function Activation Utilities	30
5.3 Using the Configuration Save and Restore (CSR) Utility	31
5.4 Using the Maintenance Mode Page	32
5.4.1 Entering Maintenance Mode.....	32
5.4.2 Working in Maintenance Mode.....	32
5.5 GPS/FMS Navigators Setup	33
5.5.1 GAMA 429 Graphics Setup	35
5.5.2 Dual GPS Setup with GAMA 429	36
5.5.3 RS-232 Setup	36
5.5.4 Dual GPS Setup with RS-232	37

5.5.5	GPS/FMS Communications Check (Messages)	37
5.5.6	GPS/FMS Installation-Specific Issues	38
5.6	Lightning Sensor Setup	39
5.6.1	Lightning Sensor Setup	40
5.6.2	Lightning Sensor Checkout.....	42
5.7	Traffic Sensor Setup	43
5.7.1	TAS (Avidyne, SkyWatch, & Bendix/King) Setup, Connected via ARINC 429	45
5.7.2	TAS (SkyWatch) Checkout	46
5.7.3	TAS (Bendix/King) Checkout.....	46
5.7.4	TCAD Setup, Connected via RS232	46
5.7.5	TCAD Dual Display Setup.....	48
5.7.6	TCAD Checkout.....	48
5.7.7	TIS-G Setup	48
5.7.8	TIS-G Checkout.....	49
5.7.9	Traffic Communications Check (Messages)	49
5.8	ADS-B Weather and Traffic (Optional).....	50
5.8.1	SkyTrax100/100B ADS-B Weather Setup.....	50
5.8.2	FreeFlight FDL-978-RX, NGT-9000 or Garmin GTX-345 ADS-B Weather Setup ..	51
5.8.3	SkyTrax 100/100B ADS-B Traffic Setup.....	52
5.8.4	FreeFlight FDL-987-RX NGT-9000 or Garmin GTX-345 ADS-B Traffic Setup	52
5.8.5	ADS-B Weather Interface Checkout.....	53
5.8.6	ADS-B Traffic Interface Checkout.....	53
5.9	TAWS Setup (Optional).....	54
5.9.1	TAWS Setup	54
5.9.2	TAWS Communications Check (Messages).....	55
5.10	Radar Sensor (700-00030-005/-805 only).....	56
5.10.1	RADAR System Calibration	57
5.10.2	Roll Trim Adjustment.....	66
5.10.3	RADAR Checkout.....	66
5.10.4	RADAR Sensor Communications Troubleshooting	66
5.11	Engine Instruments Setup.....	67
5.11.1	Engine Instruments Setup.....	67
5.11.2	Engine Sensor Checkout	72
5.12	Aircraft Setup	72
5.12.1	Auxiliary Data Setup	73
5.12.2	XM Broadcast Datalink and FIS-B Setup	73
5.12.3	XM Broadcast Datalink and FIS-B Checkout.....	74
5.12.4	Long Range Tanks Setup	75
5.12.5	Checklists Setup (Cirrus & Columbia Only)	75
5.12.6	Dimming Bus Setup	75
5.12.7	Dimming Bus Checkout.....	75
5.13	Map Setup	76
5.13.1	Setup with Entegra PFD as Heading Source.....	76

5.13.2	Setup with GPS/FMS as Heading Source	77
5.13.3	Setup with StormScope as Heading Source	77
5.13.4	Setup with Traffic (TAS) as Heading Source	77
5.13.5	Map Orientation with Track	77
5.13.6	Map Heading/Track Status	78
6.	Post-Installation Check	79
6.1	System Info Pages	79
6.1.1	System Info Platform Page	79
6.1.2	System Info Port Page	79
6.2	Electro-Magnetic Compatibility (EMC) Check	80
6.3	TWX670 Lightning Sensor Strike Test	80
6.4	WX-500 Lightning Sensor Strike Test	81
6.5	Traffic Test	81
6.6	XM Broadcast Datalink Satellite Reception Confirmation	81
6.7	Magnetic Compass Swing	82
7.	MFD General Maintenance	83
7.1	Cleaning the EX5000 Screen	83
7.2	MFD Data Updates	83
7.2.1	Loading NavData (the Navigation Database)	84
7.2.2	Loading CMax Chart Data	84
7.2.3	Downloading EMax Data	85
8.	Avidyne Technical Support and Service	87
8.1	Technical Support	87
8.2	Service	87
	Appendix A: Environmental Qualification Data	88
	Appendix B: Flight Manual Supplement Information	90
	Appendix C: STC Permission	91
	Appendix D: Landscape EX5000 Dimensions	92
	Appendix E: Landscape EX5000 with Integrated Datalink Dimensions	93
	Appendix F: Portrait EX5000 Dimensions	94
	Appendix G: Landscape Cutout Dimensions	95
	Appendix H: Portrait Cutout Dimensions	96
	Appendix I: Wiring Diagram – Power, Dimming Bus, and Exceedance Horn	97
	Appendix J: Wiring Diagram – GPS/FMS	98
	Appendix K: Wiring Diagram – Lightning and Broadcast Datalink	100

Appendix L: Wiring Diagram – Traffic Sensors	101
Appendix M: Wiring Diagram – TAWS.....	102
Appendix N: Wiring Diagram – Radar Sensor	103
Appendix O: Wiring Diagram – Engine Sensors.....	104
Appendix P: Wiring Diagram – Primary Flight Display (PFD).....	105
Appendix Q: Wiring Diagram – FIS-B Weather and ADS-B Traffic	106
Appendix R: 3rd Party Avionics System Interconnect	109

1. About the EX5000 MFD

The Avidyne Multi-Function Display, or MFD, is a single unit computer system mounted in an aircraft instrument panel in the pilot's view that interfaces to various aircraft avionics. The MFD increases pilot situational awareness and enhances flight safety by providing supplementary navigation, traffic, terrain, airspace, weather, engine, and approach chart information.

The EX5000-Series MFDs are intended for use as a supplementary situational awareness device. The EX5000 contains software developed in accordance with RTCA/DO-178B Level D requirements.

A complete Entegra or Envision EX5000-Series Multi-Function Display system consists of the following components:

- Avidyne Entegra or Envision EX5000-Series Multi-Function Display (MFD).
- System installation kit, including MFD assembly and necessary connectors.
- User documentation including *Pilot's Guide*, *Installation Manual*, and *Instructions for Continued Airworthiness*.

1.1 Standard Functionality

MFD standard functionality available on the EX5000:

- A GPS interface to provide position, velocity, and flight plan data to the MFD.
- The MFD displays the current aircraft position and active flight plan graphically overlaid on the moving map comprised of terrain, geo-political boundaries, airspace, nav aids, airports, airways, and obstacles.
- The MFD displays the current active flight plan in textual format.

1.2 Optional Functionality

The following features are optional for the EX5000. However, they may not be available for all aircraft:

- **External traffic detection system**—Allows the MFD to display a pictorial representation of nearby transponder-equipped aircraft overlaid on the moving map display.
- **External lightning detection system**—Allows the MFD to present a visual display of lightning strikes or cells overlaid on the moving map display.
- **External Engine Data Acquisition Unit (DAU) or Sensor Interface Unit (SIU)**—Allows the MFD to display the aircraft engine gauges and other Engine Page functions, and provides engine leaning assistance.
- **External Mini Data Acquisition Unit (Mini-DAU)**— Allows the MFD to display rudder trim, generator and alternate current, and bus voltage.

Note: Avidyne Iridium MLX770 support has been discontinued. Release 8.2 software does not support the MLX770 Datalink transceiver.

- **Broadcast Datalink receiver**—Allows the MFD to display strategic weather and airspace information in graphical and textual formats.

Note: Avidyne MLB700 Weather Datalink receiver support has been discontinued. Release 8.2 software does not support the MLB700 Datalink receiver. XM weather using the Heads Up XMD-076 and ADS-B FIS-B weather are supported.

- **External Terrain Awareness and Warning System (TAWS)**—Allows the MFD to display EGPWS terrain image data on a TAWS page.
- **Terminal and Procedure Chart Data (CMax™ Charts)**—Optional charts available from Jeppesen Sanderson, Inc. provide terminal and procedure charts at the touch of a button.

- **External Digital Radar Receiver/Transmitter**—Allows the MFD to display radar image data on a radar page or overlaid on the moving map display.
- **ADS-B FIS-B Weather and Traffic** — Displays FIS-B weather and ADS-B traffic when interfaced to Avidyne SkyTrax100 ADS-B Receiver or Freeflight FDL-978-RX Ranger ADS-B Receiver.

Note: ADS-B weather and traffic are supported in Release 8.2 or later.

2. General Information

This manual contains information about the physical, mechanical, electrical characteristics, and installation instructions for part numbers:

- 700-00030-() - Landscape MFD
- 700-00004-() - Landscape or Portrait MFD

This manual applies to EX5000-Series MFDs with software listed in **Table 11: MFD Hardware and Software Part Numbers**

➔ To obtain maximum performance from the MFD, follow the installation instructions carefully.

MFD operating information is contained in the Entegra or Envision EX5000-Series MFD Pilot's Guide, which is supplied with the MFD.

➔ Avidyne strongly recommends that avionics installers review the *Pilot's Guide* before operating the MFD.

The current version is available on the web at www.avidyne.com.

Note: The conditions and tests required for TSO approval of this article are minimum performance standards. It is the responsibility of those installing this article either on or within a specific type or class of aircraft to determine that the aircraft installation conditions are within the TSO standards. TSO articles must have separate approval for installation in aircraft. The article may be installed only if the installation is performed in accordance with Part 43 or the applicable airworthiness requirements.



Caution: AC 20-68B, Recommended Radiation Safety, sets forth recommended radiation safety precautions to be taken by personnel when operating airborne weather radar on the ground. Dangers from ground operation of airborne weather radar include the possibility of human body damage and ignition of combustible material by radiated energy. The full text of this FAA Advisory Circular may be found on the web at http://faa.gov/RegulatoryAdvisory/ac_index.htm.

2.1 Equipment Description

The EX5000 MFD is a panel-mounted, multi-function display, available as follows:

The 700-00004-() MFD is available in two display orientations:

- Landscape
- Portrait

In all configurations, part number 700-00004 has the following attributes:

- Two control knobs.
- Four ARINC 429 ports. Each port can be individually set to transmit (TX) or receive (RX).
- Two ARINC 453 ports, both set to receive (RX)

The 700-00030-() MFD with dual-concentric knobs is available only in landscape format.

In all configurations, part number 700-00030 has the following attributes:

- Two dual-concentric knobs (that is, four knobs). Dual-concentric knobs are required for Radar installations.
- Eight ARINC 429 ports. Four ports are set to transmit (TX) and four ports to receive (RX).
- Two ARINC 453 ports, both set to receive (RX)

Note: For clarity, most unit and display illustrations in this guide are shown in landscape orientation. Unless otherwise specified, all information is applicable to both viewing orientations.




Figure 1: Multi-Function Display Landscape and Portrait Rear Views

The MFD system consists of the following components:

- EX5000 Multi-Function Display (MFD).
- User documentation including the appropriate *MFD Pilot's Guide* and *Installation Manual* (optional).

2.2 MFD Technical Specifications

Table 1: MFD Technical Specifications

Standard Features	
Display	High Brightness Color Active Matrix LCD, sunlight readable
Diagonal size	10.4 inches
Resolution	SVGA 800 X 600
Interfaces	RS-232, USB
Viewing angle (Landscape)	± 60 degrees horizontal, +45/-15 degrees vertical
Viewing angle (Portrait)	± 60 degrees vertical, +45/-15 degrees horizontal
Optional Interfaces	
EX5000-Series only	RS-232, ARINC 429, ARINC 453, and TTL
Physical Characteristics	
Weight	
700-00004-001/002/007/008/009/010 700-00030-805	6.4 lbs
700-00004-004/005/006 700-00030-005	7.6 lbs (with Narrowcast)
700-00004-104	7.6 lbs (with Narrowcast)
CG from Instrument Panel (Landscape) 700-00004-001/002/007/008/009/010 700-00004-004/005/006 700-00030-005	1.60 inches
CG from Instrument Panel (Portrait) 700-00004-104	1.60 inches
CG from Instrument Panel (Landscape)	1.60 inches
Height (Landscape)	8.50 inches
Height (Portrait)	11.0 inches
Width (Landscape)	10.7 inches
Width (Portrait)	7.8 inches
Depth	
700-00004-001/002	4.3 inches (3.7 inches behind the panel)
700-00004-004/005/006/007/008/009/010/104 700-00030-005/805	5.2 inches (4.6 inches behind the panel)
Electrical Requirements	
Voltage	18-35 VDC, negative ground
Current	
700-00004-001/002/007/008/009/010 700-00030-805	Maximum 3.5 A at 28V
700-00004-004/005/006/104 700-00030-005	Maximum 4.0 A at 28V
Cooling Requirement	Unrestricted airflow to the top and bottom of the landscape chassis or both sides of portrait chassis.
Operating Limits	See <i>Appendix A: Environmental Qualification Data</i>
TSOs	See Table 2: TSOs by Software Part Number.

2.3 TSO Information

This section covers information regarding TSOs applicable to the MFD. The conditions and tests required for TSO approval of this article are minimum performance standards. It is the responsibility of those installing this article either on or within a specific type or class of aircraft to determine that the aircraft installation conditions are within the TSO standards. TSO articles must have separate approval for installation in aircraft. The article may be installed only if performed under 14 CFR part 43 or the applicable airworthiness requirements.

Table 2: TSOs by Software Part Number

Part #	TSO#
530-00235-000	TSO-C43c, TSO-C44c, TSO-C45b, TSO-C47a, TSO-C49b, TSO-C55a, TSO-C63c, TSO-C110a, TSO-C113, TSO-C147, TSO-C157b, TSO-C165
530-00235-002	TSO-C43c, TSO-C44c, TSO-C45b, TSO-C47a, TSO-C49b, TSO-C55a, TSO-C110a, TSO-C113, TSO-C147, TSO-C157b, TSO-C165
530-00235-100	TSO-C43c, TSO-C44c, TSO-C45b, TSO-C47a, TSO-C49b, TSO-C110a, TSO-C113, TSO-C147, TSO-C157b, TSO-C165
530-00235-200	TSO-C43c, TSO-C44c, TSO-C45b, TSO-C47a, TSO-C49b, TSO-C110a, TSO-C113, TSO-C147, TSO-C157b, TSO-C165
530-00235-500	TSO-C63c, TSO-C110a, TSO-C113, TSO-C147, TSO-C157b, TSO-C165
530-00235-502	TSO-C110a, TSO-C113, TSO-C147, TSO-C157b, TSO-C165

Table 3: TSO Descriptions

TSO#	Meaning
TSO-C43c	Temperature Instruments
TSO-C44c	Fuel Flowmeters
TSO-C45b	Manifold Pressure Instruments
TSO-C47a	Pressure Instruments—Fuel, Oil, and Hydraulic (Reciprocating Engine Powered Aircraft)
TSO-C49b	Electric Tachometer: Magnetic Drag (RPM)
TSO-C55a	Fuel and Oil Quantity Instruments (Reciprocating Engine Aircraft)
TSO-C63c	Airborne Weather and Ground Mapping Pulsed Radars
TSO-C110a	Airborne Passive Thunderstorm Detection Equipment
TSO-C113	Airborne Multipurpose Electronic Displays
TSO-C147	Traffic Advisory System (TAS) Airborne Equipment
TSO-C151b	Terrain Awareness and Warning System.
TSO-C157b	Aircraft FIS-B Datalink Systems and Equipment
TSO-C165	Electronic Map Display Equipment for Graphical Depiction of Aircraft Position

For some of the functions for which TSO approval has been granted, the MFD only provides part of the functionality covered by the TSO. below lists those partial function TSOs along with the portion of the TSO functionality provided by the MFD.

Table 4: Partial Function TSO

TSO	Function Performed by MFD
C43c	Display function only
C44c	Display function only
C45b	Display function only
C47a	Display function only
C49b	Display function only
C55a	Display function only
C63c	Display function only
C110a	Display functions only
C147	Display functions only
C157b	Airborne display functions only

There are some functions performed by the MFD that are not covered by TSOs. It is the installer's responsibility to ensure that when the MFD is installed it will meet the required minimum performance standards for those functions. Those functions performed by the MFD but not covered by TSO are listed in Table 5.

Table 5: Functions Not Covered by TSO

Non-TSO Functions
Display of charts
Display of checklists
Lean assist function
Display of percent power

Table 6 below lists the TSO deviations that have been granted for the applicable TSOs.

Table 6: TSO Deviations

TSO	Deviation
TSO-C43c -- Temperature Instruments	The MFD is environmentally qualified using the conditions and procedures of DO-160E instead of those prescribed in the TSO.
TSO-C44c – Fuel Flow meters	A digital readout is used instead of a dial.
	Digits change from white to yellow or red when the parameter is in the caution or warning range.
	The MFD is environmentally qualified using the conditions and procedures of DO-160E instead of those prescribed in AS407c.
TSO-C45b – Manifold Pressure	Digits change from white to yellow or red when the parameter is in the caution or warning range.
	The MFD is environmentally qualified using the conditions and procedures of DO-160E instead of those prescribed in the TSO.
TSO-C47a – Fuel, Oil and Hydraulic Pressure Instruments	Digits change from white to yellow or red when the parameter is in the caution or warning range.
	The MFD is environmentally qualified using the conditions and procedures of DO-160E instead of those prescribed in AS408c.
TSO-C49b – Tachometer	Digits change from white to yellow or red when the parameter is in the caution or warning range.
	Graduations are every 100 RPM instead of every 50 RPM as would be required by AS404b.
	The MFD is environmentally qualified using the conditions and procedures of DO-160E instead of those prescribed in AS404b.
TSO-C55a - Fuel and Oil Quantity	The MFD is environmentally qualified using the conditions and procedures of DO-160E instead of those prescribed in the TSO.
TSO-C63c -- Airborne Weather and Ground Mapping Pulsed Radars	The MFD is environmentally qualified using the conditions and procedures of DO-160E instead of those prescribed in the TSO.
TSO-C110a -- Airborne Passive Thunderstorm Equipment	The MFD is environmentally qualified using the conditions and procedures of DO-160E instead of those prescribed in the TSO.
TSO-C113 - Airborne Multipurpose Electronic Displays	The MFD is environmentally qualified using the conditions and procedures of DO-160E instead of those prescribed in the TSO.
TSO-C147 - Traffic Advisory System (TAS) Airborne Equipment	The MFD is environmentally qualified using the conditions and procedures of DO-160E instead of those prescribed in the TSO.
	Absence of GPS position the dedicated traffic display removes the traffic intruders and ownship and the following message is displayed "Traffic Display Not Available Without GPS".
TSO-C157b – Aircraft Flight Information Services – Broadcast (FIS-B) Data Link Systems and Equipment	The EX5000 MFD provides a simple scaling and smoothing mechanism to overlay NEXRAD on a variable range moving map in a distinctive, easy to interpret format. At large map ranges, small areas of high-intensity NEXRAD may not be displayed.
	On the map page, the MFD is capable of displaying a number of weather data products, including NEXRAD, graphical METARs, SIGMET and AIRMET areas, and various forecast products. Of these, only NEXRAD displays product age.
	Product Update Unavailable reports are consolidated onto a single page. The text "FIS-B" and "Product Updates Unavailable" is used as a title and removed from the individual decoded text messages for readability.
	The MFD is environmentally qualified using the conditions and procedures of DO-160E instead of those prescribed in the TSO.
TSO-C165 - Electronic Map Display Equipment for Graphical Depiction of Aircraft Position	The MFD is environmentally qualified using the conditions and procedures of DO-160E instead of those prescribed in the TSO.

2.4 Configuration Options

To support the many sensor types encountered in the typical aircraft installation, the installer must configure the EX5000 for the sensor type and select the correct port configuration. Table 7 lists sensor options and their associated port configurations. This data may be used when executing Maintenance Mode sensor setup utilities. Port selection must match the aircraft wiring. Default port assignments must match the wiring diagrams shown from Appendix I: *Wiring Diagram – Power, Dimming Bus, and Exceedance Horn* through Appendix P: *Wiring Diagram – Primary Flight Display (PFD)*. For configurations with dual GPS/FMS inputs, see Appendix J: *Wiring Diagram – GPS/FMS*.

When the MFD is used in conjunction with a digital radar system, ARINC 429 TX port 3 and ARINC 453 RX port 1 are default settings, which are not selectable via the procedures contained in this document.

Table 8: Main Connector (P1) Pin Assignments provides a cross reference between port assignments and functional use.

Table 8: Main Connector (P1) Pin Assignments

Table 7: Sensor Port Configuration Options

Sensor Type	Sensor Option	Port Type	Default Port	System Type	Port Configuration
Engines	DAU	ARINC 429		Meggitt DAU	Speed: High
	SIU	RS-232		Avidyne SIU	Baud: 9600
		RS-232		Avidyne DAU	Baud: 19200
	All Piper:	RS-232		Moritz DAU	
GPS/FMS	GAMA 429 Format	ARINC 429	1	Avidyne IFD4XX/5XX (GAMA 429 Graphics w/INT)	Speed: Low
			1	Garmin GPS 155XL, GNC 300XL	Speed: Low
			1	Garmin GPS 400/500	Speed: Low
			1	Garmin GNC 420	Speed: Low
			1	Garmin GNS 430/530 (GAMA 429 Graphics w/INT)	Speed: Low
			1	Bendix/King GNS-XLS	Speed: Low
			1	Bendix/King KLN-90B	Speed: High
			1	Universal UNS-1B	Speed: High
			1	NAVIS CH-4312-02	Speed: High
	King/Aviation Format	RS-232	1	Bendix/King GNS-XLS	Baud: 9600
			1	Bendix/King KLN-89B	Baud: 9600
			1	Bendix/King KLN-90B	Baud: 9600
			1	Bendix/King KLN-94	Baud: 9600
			1	Garmin GNS 480	Baud: 9600
			1	Trimble 2000, 2101	Baud: 9600
			1	UPSAT – all GPS units	Baud: 9600
	Northstar Format	RS-232	1	Northstar M3	Baud: 9600
	NMEA 0183 Format	RS-232	1	Garmin 150/250	Baud: 4800

Sensor Type	Sensor Option	Port Type	Default Port	System Type	Port Config.
Traffic	<i>Not Installed</i>	—	—	—	—
	TAS	ARINC429	2	Avidyne TAS600 Series Avidyne TCAD 9900BX L3 SkyWatch, SkyWatch Bendix/King KTA-870, KMH-880 Other ARINC 735 compliant TAS (configure as SkyWatch)	Speed: Low
	TIS-G	ARINC429	2	Garmin GTX330	Speed: High
	TCAS	ARINC429	2	Goodrich TCAS 791 Bendix/King CAS-66A, KTA-970	Speed: High
	RS-232 Devices	RS-232	2	Avidyne TAS600 Series Avidyne TCAD 9900BX Avidyne TCAD 9900B	Baud: Auto
	ADS-B Traffic	ARINC429	2	Avidyne SkyTrax 100 Avidyne SkyTrax 100B FreeFlight FDL-978-RX	Speed: Low
	SkyTrax 100	ARINC429	2	DO NOT USE	
	GTX 345	ARINC429	2	Garmin GTX 345	Speed: High
Aircraft Setup (Datalink Weather)	<i>Not Installed</i>	—	—	—	—
	Xm Radio	RS-232	4	Heads up XMD 076A	Baud: 115,200
	SkyTrax 100 Radio	RS-232	4	DO NOT USE	
	Capstone Radio	RS-232	4	Avidyne SkyTrax 100 Avidyne SkyTrax 100B FreeFlight FDL-978-RX GTX 345	Baud: 38,400 or 115,200
Lightning	<i>Not Installed</i>	—	—	—	—
	TWX670	RS-232	3	Avidyne TWX670	Baud:38,400
	WX-500	RS-232	3	L3 WX500	Baud:9600
Radar	The radar port is factory configured to ARINC 429 Port 3 and ARINC 453 Port 1 and should require no setup.				
TAWS	<i>Not Installed</i>	—	—	—	—
	Honeywell EGPWS	ARINC 429	4	Honeywell EGPWS	Speed: Low
		ARINC 453	2		
Map Heading {Source}	None (use GPS Track)	RS-232 or ARINC 429	----	Multiple manufacturers	
	Synchro	ARINC 407	----	Multiple manufacturers	
	GPS/FMS	ARINC 429	—	Multiple manufacturers	
	Traffic	ARINC 429		Multiple manufacturers	
	Stormscope	RS-232		L3 Stormscope	
	Avidyne EXP5000 PFD	RS-232 or ARINC 429		Avidyne Can also use other compatible ARINC 429 heading source.	



Some installations of EX5000 MFDs have been made with Garmin or Avidyne 400 and 500 series GPS units connected via RS-232 under previous revisions of this installation manual. Those installations are known, non-compliant installations with respect to TSO-C165 as curved paths from the GPS are depicted as straight lines on the MFD.

Avidyne recommends customers with Garmin or Avidyne 400 and 500 series GPS units connected via RS-232 switch to an ARINC 429 connection, otherwise the following warning must be added to the pilot's guide: "Warning: The EX5000 MFD will display straight lines instead of curved lines when curved paths are in the flight plan of a Garmin or Avidyne 400 or 500 series GPS unit."

Installations of EX5000 MFDs with Garmin or Avidyne 400 and 500 series GPS units under this installation manual must be done using ARINC 429.

Table 8: Main Connector (P1) Pin Assignments provides a cross reference between port assignments and functional use.

Table 8: Main Connector (P1) Pin Assignments

Pin	Function	Suggested	Your Setup	Pin	Function	Suggested	Your Setup
1	RT ON/OFF	RADAR		40	28 VDC		
2	RESERVED			41	28 VDC		
3	RESERVED			42	28 VDC		
4	GND			43	ARINC 429 TX1 A		
5	ARINC 429 RX1 A	GPS1		44	TESTn	RADAR	
6	ARINC 429 TX2 A			45	ARINC 429 RX2 A	ADS-B or Active Traffic	
7	DISCRETE OUT 2			46	ARINC 429 TX3 A	RADAR	
8	ARINC 429 RX3 A			47	DISCRETE OUT 3		
9	ARINC 429 TX4 A	TAWS		48	ARINC 429 RX4 A		
10	RS232 TX1			49	RS232 TX3	Lightning	
11	RS232 RX1	GPS1		50	RS232 RX3	Lightning	
12	RS232 RTN1	GPS1		51	RS232 RTN3	Lightning	
13	RESERVED			52	RESERVED		
14	DISCRETE OUT 4	Exceedance Horn		53	RESERVED		
15	GND			54	RESERVED		
16	RESERVED			55	ARINC 453 TX3 A	(UNUSED)	
17	RESERVED			56	ARINC 453 RX2 A	TAWS	
18	DIMMING			57	GND		
19	RESERVED			58	ARINC 453 TX3 B	(UNUSED)	
20	GND			59	ARINC 453 RX2 B	TAWS	
21	RESERVED			60	PWR GND		
22	RESERVED			61	PWR GND		
23	RESERVED			62	PWR GND		
24	RESERVED			63	ARINC 429 TX1 B		
25	ARINC 429 RX1 B	GPS1		64	RESERVED		
26	ARINC 429 TX2 B			65	ARINC 429 RX2 B	ADS-B or Active Traffic	
27	RESERVED			66	ARINC 429 TX3 B	RADAR	
28	ARINC 429 RX3 B			67	RESERVED		
29	ARINC 429 TX4 B	TAWS		68	ARINC 429 RX4 B		
30	RS232 TX2	TCAD		69	RS232 TX4	Broadcast Weather ,	

						GPS2	
31	RS232 RX2	TCAD		70	RS232 RX4	Broadcast Weather , FIS-B Weather, GPS2	
32	RS232 RTN2	TCAD		71	RS232 RTN4	Broadcast Weather , FIS-B Weather, GPS2	
33	RESERVED			72	RESERVED		
34	RESERVED			73	RESERVED		
35	RESERVED			74	RESERVED		
36	GND			75	ARINC 453 RX1 A	RADAR	
37	GND			76	RESERVED		
38	RESERVED			77	RESERVED		
39	RESERVED			78	ARINC 453 RX1 B	RADAR	

Table 9: Port Pinout Cross-Reference

ARINC 429				
700-0004 Ports	700-00030 Ports	Signal	Pin	Your Setup
1	1	TX A	43	
		TX B	63	
		RX A	5	
		RX B	25	
2	2	TX A	6	
		TX B	26	
		RX A	45	
		RX B	65	
3	3	TX A	46	
		TX B	66	
		RX A	8	
		RX B	28	
4	4	TX A	9	
		TX B	29	
		RX A	48	
		RX B	68	


ARINC 453			
Port	Signal	Pin	Your Setup
1	RX A	75	
	RX B	78	
2	RX A	56	
	RX B	59	

Table 10: RS-232 Port Pinout Cross-Reference

RS232 Port	Signal	Pin	Your Setup
1	TX	10	
	RX	11	
	RTN	12	
2	TX	30	
	RX	31	
	RTN	32	
3	TX	49	
	RX	50	
	RTN	51	
4	TX	69	
	RX	70	
	RTN	71	



Note that the connector assignments are suggested, but not required. If you use different pin assignments, be sure to document the changes.



NOTES:

1. AVAILABLE FOR GPS B WHEN TRAFFIC 429: ARINC 429 RX #2 PORT IS NOT WIRED
2. AVAILABLE FOR GPS B WHEN TAWS 429: ARINC 429 TX #4 PORT IS NOT WIRED

Figure 2: Main Connector Sample Port Assignments

3. MFD Configurations

The following table contains the history of approved hardware and software configurations, including current approved configuration:

Table 11: MFD Hardware and Software Part Numbers

Part Number	Description	Aircraft	Software Part Number
700-00004-010	EX5000 Landscape MFD	Aftermarket installations	530-00235-502
700-00004-10X	EX5000 Portrait MFD	Columbia (Lancair) 350, 400	530-00235-200
700-00030-X05	EX5000 Landscape MFD	Piper PA34, PA46	530-00235-000
		Envision Radar-Capable	530-00235-500
700-00004-00X	EX5000 Landscape MFD	Cirrus SRV, SR20, SR22	530-00235-100
		Piper PA28, PA32, PA44	530-00235-002

If damage occurs during shipping, the damaged shipping carton and packing material will help substantiate your claim to the shipping company. Retain the original shipping carton and packing material in case you need to ship the unit for service.



Do not open the MFD cover in any manner and do not remove the internal Compact Flash memory card, unless the operation is being conducted by authorized personnel using an approved Avidyne Service Bulletin. Otherwise, the Compact Flash memory or MFD may be damaged.

4. Installation Planning

This section contains information for installing and wiring the MFD. All installation procedures should follow the acceptable practices, methods, and techniques of avionics installations as described in FAA Advisory Circulars. Use appropriate appendices for guidance with MFD dimensions and panel cutout requirements.

Installations not identified in applicable STCs may require additional substantiation. See Appendix C: *STC Permission* for information pertaining to STCs. Referring to an STC may assist in securing installation approval.

4.1 Location and Viewing Angle

The MFD is designed to be panel-mounted. Locate the MFD in a position on the panel where the pilot and co-pilot can both easily reach the knobs and controls to operate and view it from the proper viewing angle.

4.2 Cooling

The MFD uses two internal fans; an inlet and outlet fan, to provide adequate cooling.

➔ Be sure that there are at least 2 inches of clearance, top and bottom, to allow for proper air circulation.

4.3 Mounting the MFD

Before installing the MFD, carefully assess how you can most effectively position the MFD given space availability, viewing angle, and wiring considerations. Before starting the installation, develop an installation strategy by carefully reviewing all the installation instructions. The unique requirements of your aircraft will determine the specifics of the installation.

➤ To install the MFD, make a cutout hole in the cockpit panel:

- For a Landscape MFD, see Appendix G: *Landscape Cutout Dimensions*. The Landscape MFD is held in place by four Dzus ¼-turn fasteners.
- For a Portrait MFD, see Appendix H: *Portrait Cutout Dimensions*. The Portrait MFD is held in place by four captive 10-32 screws.

The fasteners require a panel thickness of 0.080" for proper engagement. Hole patterns and placements are illustrated in the corresponding appendices.



Do not exceed the recommended panel thickness, or the MFD may not fully seat. If communication between the MFD and any of the sensor interfaces is not established, ensure that the MFD is fully seated, and then check all sensor connections.

➔ A low resistance (0.5 Ohm) ground path must be established between the MFD chassis and airframe ground.

4.4 Electrical and Sensor Interfaces

28-volt DC electrical power must be supplied to the MFD. In aircraft with a 28-volt system, the MFD is usually connected to a non-essential avionics bus. Non-28-volt systems can use a regulated +28 VDC converter. The MFD does not have an on/off switch and will start as soon as power is applied. The MFD may be wired to the aircraft dimming bus to control front panel LED brightness via the cockpit panel brightness control. The MFD uses a single 78 pin High Density, D-sub connector for all power and electrical interfaces (See Figure 1: Multi-Function Display Landscape and Portrait Rear Views).

4.4.1 Wiring Notes

Table 12: Electrical and Sensor Interface Wiring

Designation	Vendor	Part #	Description
P1	Positronic	DD78F10G00	78-Pin High Density Female D-Sub Connector
J2	Delta Electronics	4205-018-N995	50 Ohm Right Angle Plug BNC Connector

- **Power**—P1- input: 5 A @ 28 vdc.
 - Use 20 AWG for lengths greater than 3ft.
 - Use 22 AWG for P2 high-density sockets. Circuit breaker: 7.5 amp recommended.
 - For 14 vdc A/C, use 14 to 28 vdc converter (KGS Electronics RB-125, Ameri-King AK550-6 or similar with TSO-C71, output 5 A min. @ 28 vdc.)
- **Dimming**—P1-input—Use 22 AWG, connect to a/c instrument dimming bus. Supports any range 0-28 vdc. Connection to dimming-bus ground reference required.
- **ARINC 429**—P1-wire—Use 22 AWG twisted shielded pair, MS22759/18-22-2 or equivalent. Connect shield to P1 connector metallic backshell grounding screw with solder or crimp ring terminal.
- **ARINC 453**—P1-wire—Use 22 AWG twisted double shielded pair (Quadrax), (Bendix/King p/n 024-00064-0000) or equivalent.
 - Connect outer shield to P1 connector metallic backshell grounding screw with solder or crimp terminal ring.
 - Connect inner and outer shield to sensor connector metallic backshell grounding screw with solder or crimp terminal ring.
- **RS-232**—P1-wire—Use 22 AWG shielded triple, MS22759/18-22-3 or equivalent.
 - Connect a dedicated RS-232 signal ground from the sensor to the MFD.
 - Connect shield to P1 connector metallic backshell grounding screw with solder or crimp ring terminal.
- **Shield Terminations**—Make shield termination as close as feasible to the protected signal wire terminations.

For more information, *Wiring Diagram Appendices*.

4.4.2 Weight and Balance

An aircraft Weight and Balance calculation is required as part of installation approval process.

For information about weight and balance, see Table 1: MFD Technical Specifications.

For technical drawings, including center of gravity, see the appropriate appendix:

- Appendix D: *Landscape EX5000 Dimensions*
- Appendix E: *Landscape EX5000 with Integrated Datalink Dimensions*
- Appendix F: *Portrait EX5000 Dimensions*

 Follow the guidelines as established in AC 43.13-1B, Chapter 10, Section 2.

4.5 Electrical Load Analysis

Before installing the MFD, perform an electrical load analysis that is specific to the aircraft. This analysis should be in accordance with AC 43.13-1B, Chapter 11.

Use the following values to support the analysis:

- **28 VDC Nominal Load**—2 A
- **28 VDC Maximum Load**—5 A

Ensure that the power input to the MFD is circuit-protected in accordance with the guidelines of AC 43.13-1B, Chapter 11, Section 2.

➔ A 7.5 amp circuit breaker is recommend for use with the MFD.

4.5.1 Broadcast Antenna Details

- Mount the antenna no closer than 36 inches to VHF-Comm transmitters of 15 Watts or less. For more powerful transmitting antennas, separation should be a minimum of 48 inches.
- If an XM/VHF-Comm combo antenna is being installed and is replacing the operation of an existing approved antenna installation, the existing separations are acceptable. SATCOM antennas transmit at 40 Watts and should be separated by the largest distance possible. This distance must be a minimum of 36 inches.
- When routing the broadcast antenna cable, the maximum possible separation from transmitter antenna feed cables must be considered, especially with SATCOM and other high power transmitters. Antenna feed cables of VHF transmitters of 15 Watts or less should require only a minimal separation.
- Receive-only antennas such as GPS and ADF do not produce interference and require little separation. The broadcast antenna should be placed as close as possible to these types of antennas to gain separation from transmitters.

For further details, including installation pre-testing, please refer to the Heads Up Technologies *XMD076 XM WX Receiver Installation Manual*, document number XMD076-3.

4.6 Wiring External Devices

4.6.1 GPS and FMS Wiring

GPS data may be received via a GAMA 429 Graphics interface or a RS-232 interface. See the appropriate wiring diagram and the specific installation instructions for your particular GPS. For more information, see the wiring diagrams in Appendix J: *Wiring Diagram – GPS/FMS*.

Note: For the EX5000, Avidyne recommends using an GAMA 429 Graphics with intersections connection for FMS/ GPS. The GAMA 429 Graphics input can contain heading data, necessary for overlay capabilities as well as approach procedures and the display of curved segments. For more information, see *GAMA 429 Graphics Setup* .

4.6.2 Dual GPS Setup with GAMA 429

The EX5000 can receive information from two GAMA 429 Graphics capable GPS units. Connect the GPS according to the wiring diagram in Appendix J: *Wiring Diagram – GPS/FMS*.

Select a different ARINC port for GPS 2.

4.6.3 FIS-B Weather and ADS-B Traffic Receiver Wiring

See the wiring diagram in Appendix Q: *Wiring Diagram – FIS-B Weather and ADS-B Traffic and Freeflight Ranger FDL-978-() Installation Manual, Lynx NGT-9000 Installation Manual and Garmin GTX-345 Installation Manual*. Connect the RS-232 port of the ADS-B receiver to any of the available RS-232 ports of the MFD as shown (RS232 #4 is the default assignment, but not mandatory.). Use shielded wiring, terminated at each end to chassis ground. Contact Freeflight Systems at

<http://www.freeflightsystems.com> for information on the Freeflight FDL-978-RX ADS-B Receiver. Contact L3 Lynx at <https://www.l-3lynx.com> for information on the NGT-9000. Contact Garmin at <https://support.garmin.com/en-US/?productID=140949&tab=topics> for information on the GTX-345. Contact Avidyne for information on the SkyTrax 100/100B ADS-B Receiver.

Note: If installing the Avidyne SkyTrax 100 or FreeFlight FDL-978-RX, ensure the software revision is 8.2. or greater.

4.6.4 XM Broadcast Datalink Receiver Wiring

See the wiring diagram in Appendix K: *Wiring Diagram – Lightning and Broadcast Datalink*, and the *HeadsUp XMD076 Installation Manual*. Connect the RS-232 port of the Datalink receiver to any of the available RS-232 ports of the MFD as shown for Broadcast Weather. (RS232 #4 is the default assignment, but not mandatory). Use shielded wiring, terminated at each end to chassis ground. Contact Heads Up Technologies at www.heads-up.com for information on the *HeadsUp XMD076 XM Broadcast Datalink Receiver*.

4.6.5 Lightning Sensor Wiring

See the wiring diagram in Appendix K: *Wiring Diagram – Lightning and Broadcast Datalink*, and the *WX-500 Installation Manual* or *TWX-670 Installation Manual*. Connect the RS-232 port of the lightning sensor to any of the available RS-232 ports of the MFD as shown. Use shielded wiring, terminated at each end to chassis ground. Connect the lightning sensor jumpers for correct stabilization source and antenna position. These settings will be also be set in the MFD and must agree.



Caution: It is extremely important that you perform noise mapping and ensure that the proper grounds have been installed and checked after the Lightning interface is installed. Ensure that the lightning sensor is installed and set up according to its installation instructions. Excessive noise can produce erroneous lightning strike indications.

4.6.6 Traffic Sensor Wiring

The MFD supports a number of different traffic sensors. Be sure to follow the instructions for the specific traffic sensor installed on the aircraft.

- **TAS** (L-3 SkyWatch: SKY497, TRC497 and TRC899)—Connect data and TTL control lines and configure as shown in Appendix L: *Wiring Diagram – Traffic Sensors*. Use shielded wiring and terminate as shown.

Note: If using a TRC 497, ensure the software revision is 1.6 or later.

- **TAS/IHAS** (Avidyne TAS600 Series, Bendix/King Honeywell: KTA 870)—Connect data lines and configure as shown in Appendix L: *Wiring Diagram – Traffic Sensors*. Use shielded wiring and terminate as shown.
- **TCAD** (Avidyne 9900B, 9900BX or Skytrax 6XXA)—Connect aircraft power to the Avidyne TCAD sensor as described in the Avidyne TAS600 Installation manual 600-00282-000 Rev04 or later. Connect and configure as shown in Appendix L: *Wiring Diagram – Traffic Sensors*. Use shielded wiring and terminate as shown.

Note: The TCAD 9900BX is a TAS-type active device. Under Sensor, you can select either TCAD or TAS. However, the EX5000 stores this configuration as a TAS sensor. This does not affect the way the EX5000 receives or displays the traffic information.

Note: Ensure the 9900BX software revision is 1.07 or later.

- **TIS-G** (Garmin: GTX-330, GTX-330D)—Ensure the Garmin software revision is 3.03 or higher. Connect data lines and configure as shown in Appendix L: *Wiring Diagram – Traffic Sensors*. Use shielded wiring and terminate as shown.

Wire power to the Garmin GTX -330 transponder as directed in the *Garmin Installation Manual*.

Note: The MFD does not provide power to the GTX sensor. TIS uses an ARINC 429 data connection between the transponder and the MFD. Make this connection after consulting the wiring diagrams in the appendix of this document and the GTX-330 installation manual.

4.6.7 TAWS Wiring

(Honeywell: KGP 560) – Ensure the Honeywell KGP 560 has part number 965-1198-005. Connect as shown in Appendix M: *Wiring Diagram – TAWS*.

The EGPWS software must support KC Picture Bus (KCPB) Phase 2. See the Honeywell EGPWS documentation for applicable software configurations. If the EGPWS interface is operating properly, there will be no system status messages.

4.6.8 Map Configuration

Wiring for Map can be done in a number of different ways, depending on the aircraft configuration and options. After you determine the appropriate configuration

Configuring Map Heading from the EXP5000 PFD

The EX5000 can receive heading directly from an installed Avidyne Entegra EXP5000 PFD via an ARINC 429 or an RS-232 bus.

For the correct interconnection between the EXP5000 PFD and the EX5000, see Appendix P: *Wiring Diagram – Primary Flight Display (PFD)*.

Configuring Map Heading from a GPS/FMS

The MFD can receive heading from a GPS/FMS via an ARINC 429 bus. The source of heading is usually a gyro transmitting synchro or stepper to SkyWatch or StormScope sensor connected to the GPS/FMS, as shown in Figure 3: Heading Configuration with GPS/FMS.

See Appendix J: *Wiring Diagram – GPS/FMS* for the correct pinouts to the MFD.

When checking the GPS/FMS connection to the EX5000, the GPS/FMS must have a valid position fix (latitude/longitude).




Figure 3: Heading Configuration with GPS/FMS

Configuring Map Heading from StormScope

The MFD is capable of receiving heading data from the WX-500 StormScope via RS-232. Configure the MFD as shown in Figure 4: Heading Configuration with StormScope:

Figure 4: Heading Configuration with StormScope

Configuring Map Heading from TAS (Traffic)

The EX5000 is capable of receiving heading data from a TAS system. Configure the MFD as shown in Figure 5: Heading Configuration with SkyWatch. See Appendix L: *Wiring Diagram – Traffic Sensors* for the correct pin outs to the MFD.

Figure 5: Heading Configuration with SkyWatch

4.6.9 Radar Sensor Wiring

See Appendix N: *Wiring Diagram – Radar Sensor* for the wiring diagram.

5. MFD Feature Setup and Checkout

5.1 Preliminary Test

➤ Power up the MFD for post installation evaluation and configuration. To do so:

1. Turn on the MFD by applying power to the aircraft electrical bus supplying the MFD.

Note: Read the appropriate *Pilot's Guide* for explanations of various functions.

2. The green LED control lights behind all the front panel controls should light up.
3. After the initial power up, the software will load and go through several checks. During this startup sequence the screen displays the text "Initializing-Please Wait...".
4. The startup sequence is finished when the "Press any bezel key to Continue..." message displays.




Figure 6: EX5000 Landscape Front View

5.2 Optional MFD Function Activation Utilities

Avidyne provides the ability to install certain optional functionality using single-use activation utility disks. This section describes the installation procedure for these utilities.


➔ The Activation Utilities are available for use only by avionics repair facilities performing MFD installations, MFD software upgrades, and MFD function activation on installed MFD software.

➤ To activate the TAWS, and Broadcast Datalink MFD features:

1. Obtain the Activation Utility disk for each feature you want to install from Avidyne or an authorized aircraft manufacturer. Be sure to specify the software part number of the MFD for which you want to activate a feature.
 - **MFD Single-Use TAWS Activation Utility**—This utility activates the MFD TAWS function. This utility is for use in FAA-approved aircraft repair stations only.
 - **MFD Single-Use Broadcast Activation Utility**—This utility activates the MFD Broadcast Datalink function. This utility is for use in FAA-approved aircraft repair stations only.

These utility disks can be run only once to activate a single function on an MFD. After a single use they will not run on an MFD.

2. Follow the instructions in the accompanying service bulletin for each Activation Utility.

 After activation, the utility disks may be erased and reused for any purpose.

5.3 Using the Configuration Save and Restore (CSR) Utility

When performing an upgrade or replacement to an existing MFD, you may want to use the Configuration Save and Restore (CSR) Utility. This utility allows you to save off many of the configuration options that had previously been set on the MFD, including:

- Fuel Calibration (where available). Fuel Calibration is described in Fuel Quantity Calibration (Optional).
- Any added-cost utilities such as TAWS, CMax, and Broadcast Datalink (as described in Section 5.2 Optional MFD Function Activation Utilities).

Engine Setup parameters, as described in Section 0

- Engine Instruments Setup.
- Lightning, Traffic, GPS, and MAP parameters, described in this section.

Refer to the applicable software update service bulletin for appropriate configuration save and restore utility availability and use instructions.

5.4 Using the Maintenance Mode Page

The MFD Maintenance Mode Page contains the setup pages for each function.

- To start using the Maintenance Mode Page, apply power to all the sensors that interface with the MFD, including the GPS, the Lightning and Traffic sensors, Engine interface unit, ADS-B receiver, and TAWS sensor.

5.4.1 Entering Maintenance Mode

- To access Maintenance Mode, press the buttons from the Aux or Setup Page as follows:

1. Turn on the MFD by applying power to the aircraft
The system will begin its normal start up sequence
2. At the prompt, "Press any bezel key to continue", press any button.
3. Rotate the left knob clockwise until the Aux or Setup Page displays.
4. Simultaneously press and hold buttons L1 (top left) and L3 (3rd down on the left) (Figure 6: EX5000 Landscape Front View) for at least 5 seconds.

The Maintenance Mode Page displays. Note that the available setup options depend on the specific aircraft.




Figure 7: Example Maintenance Mode Page

5.4.2 Working in Maintenance Mode

As shown in Figure 7: Example Maintenance Mode Page, the Maintenance Mode Page contains setup buttons for the available EX5000 features. When you select a Setup feature, the appropriate page displays. From the Setup page, the following options will always be available:

- **Select Knob**—Rotate to change the highlighted parameter box.
- **Change Knob**—Rotate to select a parameter to modify from the highlighted box.
- **Save**—Store any setup changes made since entering the page and return to the Maintenance Mode Main page.
- **Cancel**—Return to the Maintenance Mode Main page without saving your changes

➤ When working in Maintenance Mode:

1. After making changes to each setup page press *Save* to save your changes and return to the main menu.
To exit without saving your changes, press *Cancel*.
2. Changes in the setup pages do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

 Avidyne suggests that you restart the system after you make changes to each setup page.

If no changes were made, press *Back to Map* to exit Maintenance Mode.

5.5 GPS/FMS Navigators Setup

The MFD can interface with several types of GPS/FMS systems. Table 13 lists the GPS/FMS systems that can interface with the MFD. Table 13: GPS/FMS Manufacturer's Matrix includes information about data formats available and GPS configurations.

Table 13: GPS/FMS Manufacturer's Matrix

GPS/FMS	RS232	RS-232 Formats	ARINC 429	Baud/Data Rate	Heading Output	Configuration Notes	DME ARC
IFD4XX/5XX	No*	No*	Yes	Serial – 9600 ARINC – Low	ARINC only	With ARINC 429 operation use GAMA with Graphics	With ARINC 429 only
KLN-89B	Yes	King/Aviation	No	Serial – 9600	No	—	Flight Plan ends at entry point
KLN-90B	Yes	King/Aviation	Yes	Serial – 9600 ARINC – Low	ARINC only	—	Flight Plan ends at entry point
NorthStar M1, M2, or M3	Yes	NorthStar	No	1200 or 9600	No	The NorthStar default baud rate is 1200. Better performance and extended data is achieved by setting it to 9600 (1200 will work). See the NorthStar manual to change the baud.	—
Trimble 2000, 2101	Yes	King/Aviation	Some models	9600	Not Available	Use RS-232 port 2 No Parity, 8 bits.	Sends multiple waypoints around arc
Garmin 150, 250	Yes	King/Aviation	150- No 250-No	Serial – 9600 ARINC – Low	ARINC only	For the 250 DO NOT use the W/O GAMA mode, use the EFIS mode. If using the NMEA format use the 2nd channel.	—
Garmin 155, 165	Yes	King/Aviation	No	9600	No	—	—
Garmin 400/ 500 Series	No*	No*	Yes	Serial – 9600 ARINC – Low	ARINC only	With ARINC 429 operation use GAMA with Graphics	With ARINC 429 only
Universal UNS-1B	No		Yes	ARINC – High	Yes	—	—
Honeywell GNS-XLS	No		Yes	ARINC – High or Low	Yes	For GNS-XLS Configuration Programming set as follows: GAMA ARINC 329 Bus Data Set= 1. Basic EFIS DME Arc Style=1. Arc as Gap	The arc is depicted as a gap
Morrow Apollo GX-50	Yes	King/Aviation	No	9600	No	Use the Moving Map format.	—
NAVIS CH-4312-02	No		Yes	ARINC: High	ARINC Only		Yes

* Installations of EX5000 MFDs with Garmin or Avidyne 400 and 500 series GPS units under this installation manual must be done using ARINC 429. Existing installations may continue to use RS-232 with the King/Aviation format. See Configuration Options for more information.

Note: Use the matrix as a general guideline only. GPS manufacturers are constantly improving and upgrading their products. Always refer to the *Installation Manuals* that come with the GPS/FMS to confirm configuration and setup parameters. Additionally, keep in mind that not all GPS configurations can be used with all aircraft.

There are two interface configurations that the MFD uses to connect with the GPS:

- GAMA 429
- RS-232

EX5000 MFDs support both GAMA 429 and RS-232. However, GAMA 429 Graphics is the only configuration from the GPS capable of providing heading information if the GPS is being used as the heading source (see Section 5.13 Map Setup for a complete explanation on setting up the various heading configurations within the MFD).

5.5.1 GAMA 429 Graphics Setup

If your GPS is capable of GAMA 429 Graphics output, use the wiring diagram in Appendix J: *Wiring Diagram – GPS/FMS* when installing the MFD.

Note: Using a 429 graphics output allows for the display of curved flight segments and approach data, if that data is available.

➤ To setup a GAMA 429-capable GPS:

1. From the Maintenance Mode Page, press *GPS Setup*. The GPS Setup Page displays:

The screenshot shows the Avidyne GPS / FMS Setup screen. It features a black background with the Avidyne logo at the top. Below the logo, the text "GPS / FMS Setup" is displayed. The screen is divided into two main sections for Receiver 1 and Receiver 2. Each section contains three dropdown menus: "Format" (set to "GAMA 429 Format"), "Port" (set to "ARINC429 Rx 1" for Receiver 1 and "ARINC429 Rx 2" for Receiver 2), and "Speed" (set to "Low"). To the right of the Receiver 1 section is a "Save" button, and to the right of the Receiver 2 section is a "Cancel" button. At the bottom right of the screen is a "Page" button with a circular arrow icon.

Figure 8: GPS Setup, GAMA 429

2. Configure the following:

- **Receiver**—Select GAMA 429 Graphics Format.
- **Port**— Select ARINC1.

Note: Selecting Port=None indicates that a GPS is not connected to the MFD. In this case, the MFD software does not expect GPS input.

- **Speed**—There are two speeds available, High and Low. See Table 13: GPS/FMS Manufacturer's Matrix to determine the correct speed for your system.
3. When you are done, press *Save* to save your changes. Press *Cancel* to exit without saving changes.
 4. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

5.5.2 Dual GPS Setup with GAMA 429

The EX5000 can receive information from two GAMA 429 Graphics capable GPS units. Connect the GPS according to the wiring diagram in Appendix J: *Wiring Diagram – GPS/FMS*, using a different ARINC port for GPS2. Follow the setup instructions in GAMA 429 Graphics Setup .

5.5.3 RS-232 Setup

If your GPS uses an RS-232 configuration, use Appendix J: *Wiring Diagram – GPS/FMS* for wiring information.

Note: An RS-232 interface does not provide for heading data from the GPS/FMS.

➤ To set up the MFD for the RS-232 Interface:

1. From the Maintenance Mode Page, press *GPS Setup*. The GPS Setup Page displays.
2. Configure the interface as follows:
 - **Receiver**—Select the receiver-type for your GPS/FMS system. Determine the RS-232 output format using Table 13: GPS/FMS Manufacturer's Matrix or your GPS/FMS Installation manual. Select one of the following RS-232 formats:
 - NMEA 0183
 - King/Aviation Format
 - Northstar Format
 - **Port**—Select RS232 1, or as wired.
 - **Baud**—Select the highest-possible baud rate for your GPS/FMS system. See the appropriate GPS/FMS Installation manual or see Table 13: GPS/FMS Manufacturer's Matrix to determine for the maximum speed. The following speeds are available: 1200, 2400, 4800, 9600, 19200, or 38400.




Figure 9: Dual GPS Setup, RS-232

3. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
4. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

5.5.4 Dual GPS Setup with RS-232

The MFD can interface with two RS-232 GPS units, or with a combination of one RS-232 GPS unit along with one ARINC 429-capable GPS unit. Connect the MFD ports as appropriate, using Appendix J: *Wiring Diagram – GPS/FMS*. Follow the set up instructions in GAMA 429 Graphics Setup and Avidyne Technical Support and Service.

5.5.5 GPS/FMS Communications Check (Messages)

After the MFD has been restarted, any of the following messages may appear in the main viewing screen or in the message bar and Aux or Setup Page.

Table 14: GPS/FMS Communications Messages

Message	Meaning/Action	Action
Nav Source: Is Not Communicating	No RS-232 or ARINC 429 GPS data is being received.	Check wiring and COM port setting.
Nav Source: Data is Not Valid	Data is being received from the external GPS. However, insufficient information is available to determine position.	Aircraft could be in the hanger or the GPS may not have determined its "fix" or location.
Nav Source: Data is Valid	The MFD is receiving valid position data from the GPS/FMS.	—
Nav Source: Data Format Error	Data is being received, however the MFD does not recognize the data as the format selected.	May indicate a baud rate or receiver type error.
Nav Source: No Port selected	The RS232 port setting in the GPS setup dialog is set to NONE.	To correct this, choose the port to which the GPS is connected, typically RS232 1.
Nav Source: Reconnecting	This message is displayed when data between the MFD and the GPS is being synchronized.	—

Nav Source: Can't Open Port	Another device is configured for the same port.	Check the Setup page for all devices. Typically the GPS/FMS is configured for Port1 (for RS-232) or ARINC1 (for ARINC 429). If a second GPS/FMS is being used it is configured for Port2 or ARINC2.
Heading Data is Not Valid	Heading data is no longer available from the GPS/FMS.	Will only appear if the GPS/FMS is being used as your heading source.
Heading Data is Valid	Heading data has been restored.	—

5.5.6 GPS/FMS Installation-Specific Issues

- **Garmin Installation**—Some Garmin units provide two RS-232 formats for GPS data. One is an “aviation” format. The other is an RS232 “plotting” format. The “aviation” format provides a “King” format 9600 baud output at a higher repetition rate and is the preferred RS-232 output. Consult the specific Garmin GPS installation manual for full details.
- **Garmin GNS480 Installations**—Garmin GNS480 units should be wired and configured for RS-232 instead of ARINC 429 since the GNS480 does not output all of the necessary ARINC 429 labels.
- **Northstar Installations**—Many Northstar units have a hidden setup screen to change configuration parameters to make it difficult to change in flight. See the Northstar installation manual for the specific codes to enter to set this up correctly.
- **Trimble 2000A Installations**—This unit has a hidden setup screen documented in the installation manual to change configuration parameters to make it difficult to change in flight. See the Trimble Installation manual for the specific codes to enter.



Trimble units have been observed to sometimes lose configuration when the aircraft battery is discharged

5.6 Lightning Sensor Setup

The MFD supports the Avidyne TWX-670 and L-3 WX-500 Lightning sensors. Table 11 describes the Avidyne TWX-670 Configuration Options.

Table 15: TWX-670 Configuration Options

Option	Values	Notes
Operating Mode	Weather	Normal operating mode.
	Demo	Used to learn lightning operations.
The options below are available on the “TWX-670 Configuration” page.		
Enable Geo Stabilization	Check/Clear	The TWX-670 uses data from a connected position source (GPS/FMS).
Enable Heading Stabilization	Check/Clear	The TWX-670 uses heading data from a connected heading source (e.g., Synchro, PFD).
Enable Audio Output	Check/Clear	Enables audible alerts from the sensor.

There is a button labelled, "TWX-670 Config," that goes to another menu with the following options (all check boxes):

- Use Position Source
- Use Heading Source
- Enable Audio Output

The TWX-670 will configure these settings automatically, but the check boxes can be used to force particular setups. A red **X** will show next to the check box if the TWX does not agree with the chosen setup.

Table 16: WX-500 Configuration Options describes the WX-500 configuration options.

Table 16: WX-500 Configuration Options

Option	Values	Notes
Operating Mode	Weather	Normal operating mode.
	Noise Monitor	Supports noise mapping tests.
	Demo	Used to learn lightning operations.
Stab Type	Synchro to WX-500	The WX-500 will use the synchro supplied heading data connected directly to the WX500.
	Stepper to WX-500	The WX-500 will use stepper data from a remote compass system.
	Use Map Heading/Track	The WX-500 will use orientation information supplied by the EX5000 based on the Map Heading configuration, described in Section 5.13 Map Setup.
Enable Lightning Ahead Warning?	Check/Clear	When checked, the EX5000 issues lightning ahead warning messages.
Antenna on Top?	Check/Clear	Check if the lightning sensor antenna is located on top of the aircraft and must correspond with the WX-500 jumper settings.

5.6.1 Lightning Sensor Setup

➤ To configure the Lightning sensor:

1. From the Maintenance Mode Page, select Lightning Setup. The selection page is displayed:




Figure 10: Selection Page

2. Choose the sensor to be connected to the MFD. The Setup Page is displayed.

For the WX-500 Setup the screen shown in Figure 11 is displayed.



Figure 11: WX-500 Setup Page

For the TWX-670 Setup, the screen shown in Figure 12 is displayed.




Figure 12: TWX-670 Setup Page

3. For WX-500, set the following options:

- **Sensor** – Select between the lightning sensor and a simulation program (WX-500 only). The normal selection is the sensor name (“Avidyne TWX-670” or “WX-500”). The WX-500 simulation setting is used in conjunction with the demo mode on the sensor to simulate operations on the ground.
- **Operating Mode** – The normal operating mode is weather. Demo is used to simulate lightning operations. For the WX-500, Noise Monitor mode is used during noise mapping tests. See the WX-500 installation manual for testing procedures.
- **Port** – Set the MFD RS-232 port that is connected to the lightning sensor to match the aircraft wiring.
- **Stab Type**—Select the source of stabilization for use by the WX-500. Stabilization aids in correctly positioning strikes when the aircraft is turning. The choices are:
 - **Synchro to WX500**—a remote compass system that generates and transmits synchro signals received by the WX-500. This heading data can also be used by the MFD to orient the map.
 - **Stepper**—a remote compass system that generates and transmits stepper signals received by the WX-500. This heading data can also be used by the MFD to orient the map. See the Map Heading Setup section.
 - **Use Map Heading/Track**—The WX-500 uses orientation information supplied by the EX5000 based on the Map Heading configuration, described in Section 5.13 Map Setup. The WX-500 receives heading or track data from the MFD via RS232. Heading will be sent from the MFD only if GPS/FMS is the heading source via ARINC 429.

The best method of stabilization is a heading source (synchro or stepper input to the WX-500 or Map Heading). The next best method is Track. The wiring and WX-500 jumpers must agree with the setup on the MFD.

- **Enable Lightning Ahead Warning?**—Enables display of the Lightning Ahead warning message in the message bar when checked and disables it when not checked.
- **Antenna on Top?**—Indicates that the sensor antenna is mounted on top of your aircraft when checked and that it is mounted on the bottom of your aircraft when not checked.

Note: The antenna position setting and stabilization source must agree with the WX-500 jumper setting and the physical mounting location of the antenna.

4. For the TWX-670 the following options are available in the TWX-670 Config page:

- Enable geo stabilization – an external position source (GPS or FMS) connected to the sensor will stabilize the lightning strikes to the aircraft position
 - Enable heading stabilization – an external heading source (e.g., a synchro) connected to the sensor will stabilize the lightning strikes to the aircraft heading.
 - Enable Audio Output – if connected to the aircraft audio panel, the TWX-670 will provide audible warnings concerning nearby lightning strikes.
 - These options are only available after the Sensor and Port options have been selected and the MFD restarted. Green check marks will appear next to each option if the TWX-670 agrees with the configuration. If red X's appear, it may be because another display connected to the sensor is trying to set a different configuration. Consult the TWX-670 installation manual for more information.
5. When you are done, press Save. Press Cancel to exit without saving changes.
 6. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press Restart System.

In addition to the settings on the Lightning Setup Page, the following buttons may be available:

- **WX-500/TWX-670 Diags** – allows access to the lightning sensor diagnostic modes. See your sensor's Installation Manual about how to verify software versions, wiring configurations, antenna environment, and fault logs (not available on all software releases).
- **Self Test (WX-500)** – Runs the WX-500 Self Test and reports Pass or Fail. See the WX-500 Installation Manual for information about testing and the interpretation of the results (not available on all software releases).

5.6.2 Lightning Sensor Checkout

After the MFD has been restarted, any of the following messages may appear in the main viewing screen or the message bar and Setup page.

Table 17: Lightning Sensor Messages

Message	Meaning
Lightning Sensor is Operating Normally	Verifies that strike data to the MFD is valid.
Lightning Sensor in Demo Mode	Demo mode has been selected as the operating mode from the Lightning Setup Page.
Lightning Sensor is in Noise-Monitor Mode	Noise-Monitor mode has been selected as the operating mode from the Lightning Setup Page.
Lightning Sensor in Test Mode	Test mode has been selected as the operating mode from the Lightning Setup Page.
Lightning Sensor ERROR	The sensor system has reported an error that may mean current data is incomplete or erroneous. The error may clear.
Lightning Sensor has FAILED	The sensor system has reported an error that may mean current data is incomplete or erroneous. The error will not clear until power is removed from and reapplied to the sensor system.
Message	Meaning
Lightning Sensor is Not Communicating	Communication between the Lightning sensor to the MFD has been lost. The wiring may be incorrect, the MFD setup may not match the wiring or the sensor may have an error.
Lightning Ahead	The Lightning Ahead option has been checked on the Lightning Setup page. Displayed when a Lightning Ahead condition exists.

Lightning Heading Source Failed	Heading data is no longer available from the WX-500. Strike data may still be valid. Will only appear if the WX-500 is used as the heading source.
Lightning Heading Source OK	Heading data has been restored.
Stuck mic-PLEASE CHECK	Check your COM transmitters for indication of a stuck mike.
Lightning Antenna Location Changed	There may be an inconsistency between the antenna location jumper setting and the software configuration. This message should only appear during installation.
Lightning Position Source Failed (TWX-670 only)	The position reporting source (GPS or FMS) connected to the TWX-670 has encountered a fatal fault.
Lightning Position Source OK (TWX-670 only)	The position reporting source (GPS or FMS) connected to the TWX-670 has returned to normal operation.
Noise Present (TWX-670 only)	The TWX-670 has detected excessive noise in the system. Accuracy and efficiency of the lightning sensor may be negatively affected.
Stuck MK (TWX-670 only)	Microphone PTT switch is stuck open. Lightning strikes will not be displayed until the problem is fixed.
No Position Data (TWX-670 only)	The position reporting source (GPS or FMS) connected to the TWX-670 is not sending position data.

Lightning Sensor Noise Mode

When operating the Lightning sensor (WX-500 only) in Noise Monitor mode, the Lightning button on the Map page will display "Noise" as the current Lightning state.

➔ Do not press the button in this state, or it may suppress lightning display unnecessarily.

See the operating guide for the Lightning Sensor for more information.

If no lightning strikes are shown at all during noise testing, press the button until it says Display Off, then press once more to return to the proper Noise mode display.

5.7 Traffic Sensor Setup



The EX5000 only supports the listed Traffic sensors. If a traffic sensor not on the supported list is connected to the MFD some of the data may display but its accuracy and traffic sensor control functions may be incorrect or inoperable. Display of traffic sensor data is not a guaranty of correct traffic sensor installation and configuration.

The aircraft should be equipped with one of the following Traffic Sensors. Follow the setup instructions for the appropriate sensor:

- For TAS, see Section 1 TCAD Setup.
- For TCAD, see Section 5.7.4 TCAD Setup.
- For TIS, Section 5.7.7 TIS-G Setup.

Note: If you need to switch between types of installed traffic sensors, first change the traffic sensor type to *None*, press *Save*, and restart the EX5000. Then select the new traffic sensor type.

Table 18: Traffic Setup Configuration Options describes the system configuration options (option availability depends on the EX5000 configuration ordered):

Table 18: Traffic Setup Configuration Options

Sensor Selection	Options	Notes
TAS	Port	ARINC 429 1 to 4
	TAS Type	TAS600 Series TCAD 9900BX L3 SkyWatch Bendix/KingKTA-870, KMH-880 Other ARINC 735 compliant TAS (Configure as SkyWatch)
	External Controller? (SkyWatch only)	Checkbox
TIS-G	ARINC 429 Port 1 to 4	Garmin GTX-330
TCAS	ARINC 429 Port 1 to 4	Goodrich TCAS 791 Bendix/King CAS-66A, KTA-970
	Maximum Intruders	Display All (31) Specified by Sensor Minimum (8)
	Sensor Range	0 – 128 NM
	External Mode Control	Checkbox
	External Range Control	Checkbox
RS232 Devices	Port	RS232 1 to 4
	Model	TAS600 Series TCAD 9900BX TCAD 9900B
ADS-B	Port	ARINC 429 1-4
	Sensor	SkyTrax 100/100B FDL-978-RX NGT-9000
SkyTrax 100	Do Not Use	
GTX 345	Port	Weather In RS-232 1-4 Traffic In ARINC 429 1-4
	Sensor	Garmin GTX 345

Note: The MFD supports interface to either an ADS-B traffic sensor or active traffic sensor (i.e., TAS), not both.

5.7.1 TAS (Avidyne, SkyWatch, & Bendix/King) Setup, Connected via ARINC 429

SkyWatch uses an ARINC 429 data connection between the TRC (Transmitter/Receiver Computer) and the MFD.

➤ To set up the TAS Traffic Sensor:

1. From the Maintenance Mode Page, select Traffic Setup. The Traffic Setup Page displays:

Figure 13: TAS selection on Traffic Setup Page

2. Set the following options:

- **Sensor**—TAS
- **Port**—Select the MFD ARINC 429 port to which the TAS sensor is wired.
- **TAS Type**—Avidyne TAS600, Avidyne TCAD 9900BX, Skywatch, or Bendix/King.

Note: Check the wiring considerations discussed in Section 4.6.6 Traffic Sensor Wiring.

- **External Controller?** (SkyWatch only)—If this box is checked, control of Standby/Operate and Self Test functions is not performed by the MFD but by the SkyWatch display or a GPS. Only one device may control the Standby/Operate and the Self Test functions; therefore they are not available on the MFD when the External Controller box is selected.
3. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
 4. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*. If needed, see Table 20: Traffic Messages.

5.7.2 TAS (SkyWatch) Checkout

For TAS (SkyWatch), Self Test can only be performed from STANDBY mode and will return to STANDBY mode upon successful completion of the Self Test.

➤ To perform a Self Test:

1. With Traffic in Stand By, rotate the left knob and select the Setup Page.
2. Select Traffic Self Test. The following actions occur:
 - The Map Page displays.
 - The Sensor Status indicates that the sensor is in “Test” and a Traffic test pattern appears on the display.

If the Self Test fails, an error message is generated and displayed on the MFD screen. See the *SKY497 Installation Manual* for explanations and fault isolation procedures.

➤ To test the Sky497 installation:

1. Use the alternate display procedure described in Appendix E of the *SKY497 Installation Manual*. A terminal device using a RS-232 serial data cable is needed for these setup procedures.
2. See Appendix D in the *SKY497 Installation Manual* for information about configuring the terminal device. Any computer with RS-232 terminal emulation software (e.g., Procomm, HyperTerminal, etc.) may be used as the terminal device.

5.7.3 TAS (Bendix/King) Checkout

➤ To test the TAS (Bendix/King) installation, verify correct communication by monitoring the Message List on the Setup page for the following message: “Traffic Sensor Operating Normally”.

Note: The MFD does not command the KTA870 in Self Test mode. Use the KTA870 control panel if installed. See the *KTA870 Installation Manual* for fault isolation procedures.

5.7.4 TCAD Setup, Connected via RS232

The MFD optionally supports Avidyne TAS600 Series 9900BX TCAD sensors.

Note: The MFD does not provide power to the 9900BX sensor. TCAD is interfaced to the MFD via RS232 or ARINC 429 (9900BX only).

➤ To set up the TCAD Traffic Sensor:

1. From the Maintenance Mode Page, select Traffic Setup. The Traffic Setup Page displays:

The screenshot shows a configuration interface with the following fields:

- Sensor:** A dropdown menu with "RS232 Devices" selected.
- Port:** A dropdown menu with "RS232 2" selected.
- Model:** A dropdown menu with "TCAD 9900B" selected, highlighted with a blue border.
- TCAD Shields:** A dropdown menu with "Terminal" selected.
- Range:** A dropdown menu with "1.5" selected.
- Height:** A dropdown menu with "500" selected.

Figure 14: TCAD selection on Traffic Setup Page

2. Set the following options:

- **Sensor**—RS232 Devices.
- **Port**— Select the MFD RS232 port to which the TCAD sensor is wired.
- **TCAD Type**—Select either 9900B or 9900BX, corresponding to the installed TCAD sensor unit.
- **TCAD Shields**—When interfaced with the TCAD 9900B, you can set shield sizes for Terminal, Standard, and Enroute. See Table 19: TCAD Shield Settings in this manual for settings.

Note: TCAD Shield sizes are only adjustable with the TCAD 9900B.

Some software versions do not allow you to select TCAD type. If the option is not available, all TCAD sensors will use the shield size settings described in Table 19: TCAD Shield Settings.

See the *Avidyne TAS600 Series Installation Manual* for wiring procedures and information about shields.

- **Range**—Sets the horizontal range of the shield. The range is in nautical miles and can be set for a value between 0.0 and 10nm, in 0.1nm increments
 - **Height**—Sets the vertical distance in feet with a value between 0 and 5000 ft. in 100 ft. increments
3. Select each shield you want to configure from the Shield drop down menu.
 4. Select the Range and Height for that shield from the drop-down lists.

Table 19: TCAD Shield Settings provides the suggested minimum and maximum values for the range and height of each shield.

Table 19: TCAD Shield Settings

	Range (NM: 0.5)		Height (feet: 100)	
	Min	Max	Min	Max
Terminal	0.5	1.5	200	1000
Standard	1.0	3.0	500	1500
Enroute	2.0	6.0	1000	2000

Note: The Max range values shown above are the largest values that the TCAD processor will accept. Choosing larger values than those shown will cause the processor to default to smaller shield sizes and is not recommended.

5. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
6. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*. If needed, see Table 20: Traffic Messages.

5.7.5 TCAD Dual Display Setup

When installing the MFD with an Avidyne TAS600 9900BX display unit, see the *Avidyne TAS600 Series Installation Manual* for wiring procedures. See Figure 2-15 Wiring Diagram for Dual Displays and Section 7 in the Ryan manual for instructions.

5.7.6 TCAD Checkout

The MFD does not display the TCAD Self Test function. To perform this test, use the Avidyne TAS600 display unit.

- On installations with the TCAD 9900 display unit, follow the checkout procedures shown in the *Avidyne TAS600 Series Installation Manual*.
- On installations without the TCAD 9900 display unit (MFD only), follow the checkout procedures shown in the *Avidyne TAS600 Series Installation Manual* with the exception of the display test.

5.7.7 TIS-G Setup

The EX5000 optionally supports the display of traffic information from a Garmin GTX-330 TIS-capable Mode-S transponder.

- To set up the TIS Traffic Sensor:

1. From the Maintenance Mode Page, select Traffic Setup. The Traffic Setup Page displays:




Figure 15: TIS selection on Traffic Setup Page

2. Set the following options:
 - **Sensor**—TIS-G
 - **Port**—Select the MFD ARINC 429 port to which the TIS transponder is wired.
3. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
4. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*. If needed, see Table 20: Traffic Messages.

5.7.8 TIS-G Checkout

Use a TIS transponder test set to test the combined installation of GTX-330 and the EX5000. If no test set is available, conduct operations in an area that supports TIS data and verify that data is received and traffic is displayed.

5.7.9 Traffic Communications Check (Messages)

After the MFD has been restarted, any of the following messages may appear in the main viewing screen or the message bar and Setup page.

Table 20: Traffic Messages

Message	Meaning
Traffic Sensor is Not Communicating	Traffic data is not being received.
Traffic Sensor is in Stand-By (TAS/TIS)	The traffic sensor has been placed in Standby mode.
Traffic Sensor is in Self-Test (TAS)	The traffic sensor has been placed in Self-Test mode.
Traffic Sensor is Operating Normally	Verification that Traffic data is valid.
TCAD Altitude Unavailable (TCAD)	Occurs when altitude data has been lost from the TCAD sensor.
Traffic Sensor has Failed	The traffic sensor has reported an internal fault, or the RS-232 ports are not configured correctly.

Note: After completing all configuration procedures, confirm that the MFD is configured for the correct Traffic sensor.

5.8 ADS-B Weather and Traffic (Optional)

The MFD can interface to the Avidyne SkyTrax 100/100B, FreeFlight FDL-978-RX, NGT-9000 or Garmin GTX-345 ADS-B Receiver with software release 8.2.2 or later.

Note: The MFD supports interface to either an ADS-B traffic sensor or active traffic sensor (i.e., TAS), not both.

5.8.1 SkyTrax100/100B ADS-B Weather Setup

➤ To set up the ADS-B Weather interface of the SkyTrax 100/100B ADS-B Receiver:

1. From the Maintenance Mode Page, select Aircraft Setup. The Aircraft Setup Page displays:




Figure 16: SkyTrax 100/100B Weather selection on Aircraft Setup Page

2. Set the following options:
 - **Broadcast**—Capstone Radio
 - **Port**—Select the MFD RS232 port to which the ADS-B Receiver is wired (Port 1 shown for example).
 - **Baud** — 38,400 or 115,200.
3. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
4. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

5.8.2 FreeFlight FDL-978-RX, NGT-9000 or Garmin GTX-345 ADS-B Weather Setup

- To set up the ADS-B Weather interface of the FDL-978-RX, NGT-9000 or Garmin GTX-345 ADS-B Receiver:

1. From the Maintenance Mode Page, select Aircraft Setup. The Aircraft Setup Page displays:

AVIDYNE
Aircraft Setup

Checklists: Not installed

Broadcast: Capstone Radio

Port: RS232 1

Baud: 115,200

Aux data: Not installed

Dimming bus voltage: 0.0 volts

Brightest dimming voltage: 24.0 volts

Darkest dimming voltage: 4.0 volts

Change Select

Figure 17: FDL-978-RX, NGT-9000, GTX-345 Weather selection on Aircraft Setup Page

2. Set the following options:
 - **Broadcast**—Capstone Radio
 - **Port**—Select the MFD RS232 port to which the ADS-B Receiver is wired (Port 1 shown for example).
 - **Baud** — 38,400 or 115,200.
3. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
4. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

5.8.3 SkyTrax 100/100B, FreeFlight FDL-987-RX or NGT-9000 ADS-B Traffic Setup

- To set up the ADS-B Traffic interface of the SkyTrax 100/100B ADS-B Receiver:
1. From the Maintenance Mode Page, select Traffic Setup. The Traffic Setup Page displays:



Figure 18: SkyTrax 100/100B, FDL-978-RX or NGT-9000 selection on Traffic Setup Page

2. Set the following options:
 - **Sensor**—ADS-B
 - **Port**—Select the MFD ARINC 429 port to which the ADS-B Receiver is wired (Port 3 shown for example)
3. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
4. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*. If needed, see Table 20: Traffic Messages.

5.8.4 Garmin GTX-345 Traffic Setup

- To set up the ADS-B Traffic interface of the Garmin GTX-345 ADS-B Receiver:
1. From the Maintenance Mode Page, select Traffic Setup. The Traffic Setup Page displays:




Figure 19: GTX-345 selection on Traffic Setup Page

2. Set the following options:
 - **Sensor**—GTX 345
 - **Port**—Select the MFD ARINC 429 port to which the GTX-345 Receiver is wired (Port 3 shown for example)
3. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
4. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*. If needed, see Table 20: Traffic Messages.

5.8.5 ADS-B Weather Interface Checkout

- To test the ADS-B weather interface:

1. After Setup is complete boot the MFD into flight mode and go to the Aux page. Verify the following message is displayed: "FIS-B Receiver is Operating Normally".

5.8.6 ADS-B Traffic Interface Checkout

- To test the ADS-B traffic interface:

After Setup is complete boot the MFD into flight mode and go to the Aux page. Verify the following message is displayed: "Traffic Sensor is Operating Normally"

5.9 TAWS Setup (Optional)

The MFD can interface to the Honeywell Bendix/King EGPWS systems with Phase 2 or later software.

5.9.1 TAWS Setup

➤ To configure the TAWS interface:

1. From the Maintenance Mode Page, select TAWS Setup. The TAWS Setup Page displays:

Figure 20: TAWS Sensor Setup Page

2. Set the following options:
 - **Sensor**—Honeywell EGPWS
 - **ARINC 429 Port**—ARINC 429 4 – TAWS Default
 - **ARINC 453 Port**—ARINC 453 2 – TAWS Default
 - **Altitude Annunciation On**—Select this feature to permit a visual annunciation of GPS altitude on the TAWS display. If selected, a checkmark displays.
3. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
4. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

TAWS Checkout

➤ To test the TAWS installation:

1. From the Maintenance Mode Page, select TAWS Setup.
2. Perform a functional test of the EGPWS system in accordance with manufacturer's instructions. See the *MFD Pilot Guide* for display operation.
3. If the Self Test fails, an error message is generated and displayed on the MFD display. See the *EGPWS System Installation Manual* for explanations and fault isolation procedures.

5.9.2 TAWS Communications Check (Messages)

If there is a communication or data error between the TAWS sensor and the MFD, one of the following messages will display on the bottom of the screen.

Table 21: TAWS Error Messages

Message	Meaning/Action
TAWS Failed	An incorrect system configuration or failure in one of the system components has occurred. <ul style="list-style-type: none"> Verify that the sensor is turned on and valid. Verify system wiring.
TAWS Initializing	If message does not clear within 60 seconds, communication between the MFD and the Terrain sensor has not been established. <ul style="list-style-type: none"> Verify that the sensor is turned on and valid. Verify system wiring. See terrain sensor Installation and User's Manual for troubleshooting guidance.
TAWS Not Communicating	Indicates that the MFD is not receiving data from the Terrain sensor. <ul style="list-style-type: none"> Verify that the sensor is turned on and valid. Verify system wiring. See TAWS sensor Installation and User's Manual for troubleshooting guidance.
TAWS Display Unavailable	The TAWS Sensor has declared itself inoperative. <ul style="list-style-type: none"> Verify system wiring. Verify that the sensor inputs to the TAWS are turned on and valid. See TAWS sensor Installation and User's Manual for troubleshooting guidance.
TAWS Sensor Self-Test	The TAWS Sensor is performing a Self-Test. The message will remain until the self-test is finished. <ul style="list-style-type: none"> Verify that the "Self-Test" mode has been not been selected at the separate TAWS control panel. Verify system wiring. See TAWS sensor Installation and User's Manual for troubleshooting guidance.
TAWS Inhibited	The TAWS sensor is in the "Inhibited" mode. <ul style="list-style-type: none"> Verify that the "Inhibit" mode has been not been selected at the separate TAWS control panel. See TAWS sensor Installation and User's Manual for troubleshooting guidance.

Note: If the EGPWS interface is operating properly, there will be no system status messages.

5.10 Radar Sensor (700-00030-005/-805 only)

Radar support is provided by the Bendix/King RDR-2000 Radar system, including the AlliedSignal ART-2000 sensor, and is an option available only on the 700-00030-005/-805 EX5000. Radar is supported only by software part numbers 530-00235-000/500.

➤ To set up radar support:

1. From the Maintenance Mode Page, select Radar Setup. The Radar Setup Page displays:

AVIDYNE
Radar Setup

Sensor: AlliedSignal ART-2000
ARINC 429 Port: ARINC429 1
ARINC 453 Port: ARINC453 1

Save

Select Radar Sensor Type and, if necessary, Ports
Then Save and Restart the System to Enable the Radar function.
Once the system has re-started, return to Maintenance Mode and select 'Radar Setup' to complete Radar installation

Cancel

Select < Change

Figure 21: ART-2000 Radar Setup Page

2. From the Radar Setup Page, select the radar sensor installed on this aircraft.
3. Press **Save** to return to the Maintenance Mode Page
4. From the Maintenance Mode Page, press *Restart System*.
5. Re-enter Maintenance Mode and select the Radar Setup Page again.
6. Select the following options to finish the installation:
 - ARINC 429 Port—ARINC 429 Tx1
 - ARINC 453 Port—ARINC 453 1
7. When you are done, press **Save**. Press *Cancel* to exit without saving changes.
8. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.


Table 22: ART-2000 Sensor Configuration Options describes the configuration options offered by the ART-2000 sensor. For more information, see the Bendix-King *Radar Installation and Operations Manual*.

Table 22: ART-2000 Sensor Configuration Options

Option	Value	Notes
Park Position	Last position	Set the park/startup position for the radar antenna tilt angle.
	Full up	
	Centered	
	Full down	
Beam Width ▪ 10" Antenna ▪ 12" Antenna	10° 8.1°	Defines the Width and Height of the radar sweep graphical depiction on the EX5000 radar display.
Beam Height	0.0° – 19.5°	
Enable Gain Control	Check/Clear	Enables R/T variable gain control to be commanded from the EX5000.
Enable VP	Check/Clear	When checked, enables Radar Vertical Profile mode.
Enable Auto-Tilt Control	Check/Clear	When checked, enables Radar auto-tilt mode.
Primary Indicator (1)	Check/Clear	When checked, enables EX5000 control of radar functions.
Disable Stabilization	Check/Clear	Disables EX5000 display of the "Stab Off" annunciation
Enable Automatic Standby	Check/Clear	When checked, enables the EX5000 to auto-command the radar to standby when ground is sensed to be below 20 kts.

5.10.1 RADAR System Calibration

Calibrating the Radar R/T unit requires access to the Radar Calibration Page on the Entegra or Envision EX5000 unit. This section explains how to access the calibration page and complete the radar calibration.

 Perform radar R/T calibration according to the procedures and specifications for the specific unit installed in the aircraft.

Calibration can be performed after the Radar has been installed, setup and checked out per the radar manufacturer's instructions.

➤ To calibrate the system:

1. From the Maintenance Mode Page, select *Setup Radar*.
2. From the Radar Setup page, access the Calibration Mode
3. Perform the calibration according to the specifications in the R/T unit's Installation Manual.
4. Press Enter to accept the new values.
5. When you are done, press *Save* from the Radar Setup Page. Press *Cancel* to exit without saving changes.
6. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

Calibrating the AlliedSignal (Bendix/King) 2000 Radar Sensor

This section describes Post-Installation System Configuration and Calibration of the Bendix/King RDR-2000 Radar System using the EX5000 and replaces specific sections of the Bendix/King *Installation Manual* that describe configuration and calibration using the Bendix/King IN-182A Indicator.

- To configure and calibrate the system, follow the original Bendix/King Installation Manual substituting the following two sections with the instructions provided herein:

- 2.4.1 CONFIGURATION PROCEDURE USING RADAR INDICATOR
- 2.4.4.1 Stabilization Calibration with Radar Indicator

Note: If the EX5000 is replacing the indicator of currently installed and previously calibrated RDR 2000 Series Radar, this procedure may not be necessary. The calibration values are contained in the configuration module of the R/T and should remain valid. Avidyne recommends that you check the calibration values after the Avidyne unit has been installed to ensure that nothing has changed.

Bendix/King Installation Manual Replacement Section 1

2.4.1 CONFIGURATION PROCEDURE USING RADAR INDICATOR

The R/T Configuration Module must be configured using the Allied Signal KPA 900 Configuration Module Programmer Kit (Part Number 050-03311-0000) in conjunction with a personal computer. See the configuration module user data for detailed setup instructions. Follow the instructions for the programmer.

2.4.1.1 Antenna Clearance Check

Complete the Antenna Clearance Check by performing the following steps:

- A. From the Aux Page, enter Maintenance Mode, as described Section 5.4, Using the Maintenance Mode Page).
- B. Set the radar park position to Full Up.
- C. Restart the MFD.
- D. From the Radar Setup Page, set the radar Function to SBY.
- E. Set the radar Mode to GND.
- F. Reduce the gain until the gain indicator shows the minimum setting.
- G. Set the Antenna Tilt to full UP (U 15.0).
- H. Set Range to 240 NM.
- I. From the Aux Page, enter Maintenance Mode, as described in Section 5.4, Using the Maintenance Mode Page).
- J. Press *Radar Setup*.
- K. Press *Calibration* to display the RT CALIBRATION DATA page. Upon display of the RT CALIBRATION DATA page with the system in calibration mode, all fault fields will flash briefly. This verifies that the system is in calibration mode.
- L. Starting at -30, slowly adjust the gain downward until the antenna clearance scan begins. This should take place at a gain value no lower than -26. The antenna will move to each of the extreme positions to determine that there is no interference with antenna movement and all scan motors are working properly.

Bendix/King Installation Manual Replacement Section 2

2.4.4.1 Stabilization Calibration with Radar Indicator

➤ To calibrate the radar pitch and roll:


- A. From the Aux Page, enter Maintenance Mode, as described in Section 5.4, Using the Maintenance Mode Page). Select *Radar Setup* to display the Radar Setup Page:

Figure 22: Radar Setup Page

Note: Once the ART-2000 has been installed, the Radar Setup Page will be similar to the Page shown here.

- B. Set Park position to Full up.
- C. Ensure that Enable Automatic Standby is selected.
- D. Restart the MFD, and open the Radar Page.
- E. From the Radar Page:
- Press *Radar Standby* until the GND setting reads STBY.
 - Set *Mode* to GND. The *Knob* button will display in the lower left corner.
 - Set *Knob* to Gain.
 - Use the *Gain* knob (outer left) to reduce the gain until the Gain indicator in the upper right shows the minimum setting. Note that you need to turn the Gain knob *clockwise* to reduce the gain (and counter-clockwise to increase it).
 - Use the Tilt knob (inner left) to set the Antenna Tilt to full UP (U 15.0°).
 - Use the Range knob (inner right) to set the range to 240 NM.

When the Radar Page is ready, it will look similar to the following:



Note: Failure to set any of the settings described in step E will prevent you from entering calibration mode. If more than one radar indicator is installed in the system, all but one indicator must be in the OFF or STBY position in order for the system to enter the calibration mode.

F. Open the Aux Page and enter Maintenance Mode.

G. Press *Radar Setup* to display the Radar Setup Page.

H. From the Radar Setup Page, press *Calibration* to display the Calibration Page (see Figure 2-5 in the Bendix/King Installation Manual). When the system opens in calibration mode, all Fault fields will flash briefly.

If the Fault fields do not flash, the Calibration Page is only open in display mode and you cannot make changes. Make sure that you carefully followed the instructions in step E and try to enter calibration mode again.

I. Once you are in calibration mode, use the left outer knob to set ROLL TRIM to 0°.

J. If desired, copy all displayed values to a notepad in case you need to recall a value that is accidentally changed.

Note: For information about how to adjust the radar settings, see Figures 2-10 and 2-11 in the Bendix-King *Installation Manual*.

➡ If using an ARINC 429 gyro, proceed to Calibrate AHRS ARINC 429 PITCH OFFSET

K. Calibrate 400 Hz REF GAIN

1. Set the tilt table to 0° pitch and roll.
2. Use the GAIN control to set the GAIN POT /2 setting between 28- and 30-.
3. Set the 400 Hz REF field to 0.0 ±1.0°. To adjust the value:
 - To increment the value of 400 Hz REF, use the right inner knob to change the TILT SETTING to between 5 and 10 UP. When the TILT SETTING is set to between 5 and 10 UP, the value of the 400Hz REF field will slowly increase.

- To decrement the value of 400 Hz REF, use the right inner knob to change the TILT SETTING to between 5 and 10 DOWN. When the TILT SETTING is set to between 5 and 10 DOWN, the value of the 400HZzREF field will slowly decrease.
- When you reach the desired setting, quickly adjust the TILT SETTING to above 10 UP to lock in the setting.

4. Proceed to Calibrate PITCH GAIN

Note: If the 400 Hz REF field is zero (0), and does not change when the TILT knob is adjusted, check that the correct gyro has been selected when programming the Configuration Module.

L. Calibrate PITCH GAIN

1. Set the tilt table for 10° pitch up.
2. Use the GAIN control to set the GAIN POT /2 setting to 25- or 26-.
3. Set the PITCH ANGLE field to 10.0 ±1.0°.
 - To increment the value of the PITCH ANGLE, use the right inner knob to change the TILT SETTING to between 5 and 10 UP. When the TILT SETTING is set to between 5 and 10 UP, the value of the PITCH ANGLE field will slowly increase.
 - To decrement the value of PITCH ANGLE, use the right inner knob to change the TILT SETTING to between 5 and 10 DOWN. When the TILT SETTING is set to between 5 and 10 DOWN, the value of the PITCH ANGLE field will slowly decrease.
 - When you reach the desired setting, quickly adjust the TILT SETTING to above 10 UP to lock in the setting.
4. Set for 10° PITCH DOWN. Repeat steps 2 and 3.
5. Set the tilt table to 0° pitch and roll.
6. Proceed to Calibrate PITCH OFFSET

M. Calibrate PITCH OFFSET

1. Use the GAIN controls to set the GAIN POT /2 setting to 18- or 19-.
2. Check that the tilt table is set for 0° pitch.
3. Set the PITCH ANGLE field to 0.0 ±1.0°.
 - To increment the value of the PITCH ANGLE, use the right inner knob to change the TILT SETTING to between 5 and 10 UP. When the TILT SETTING is set to between 5 and 10 UP, the value of the PITCH ANGLE field will slowly increase.
 - To decrement the value of PITCH ANGLE, use the right inner knob to change the TILT SETTING to between 5 and 10 DOWN. When the TILT SETTING is set to between 5 and 10 DOWN, the value of the PITCH ANGLE field will slowly decrease.
 - When you reach the desired setting, quickly adjust the TILT SETTING to above 10 UP to lock in the setting.
4. Set the tilt table to 10° pitch up. The value should be 10.0U ±1.0°. If the value is out of range, repeat Calibrate PITCH GAIN
5. Set the tilt table to 10° pitch down. The value should be 10.0D ±1.0°. If the value is out of range, repeat Calibrate PITCH GAIN
6. Set the tilt table to 0° pitch. The value should be 0.0 ±1.0°. If the value is out of range, repeat this step (Calibrate PITCH OFFSET).
7. Proceed to Calibrate ROLL GAIN

N. Calibrate ROLL GAIN

1. Set the tilt table for 10° roll right.
2. Use the GAIN controls to set the GAIN POT /2 setting between 21- and 23-.
3. Set the ROLL ANGLE field to 0.0 ±1.0°.
 - To increment the value of the ROLL ANGLE, use the right inner knob to change the TILT SETTING to between 5 and 10 UP. When the TILT SETTING is set to between 5 and 10 UP, the value of the ROLL ANGLE field will slowly increase.
 - To decrement the value of ROLL ANGLE, use the right inner knob to change the TILT SETTING to between 5 and 10 DOWN. When the TILT SETTING is set to between 5 and 10 DOWN, the value of the ROLL ANGLE field will slowly decrease.
 - When you reach the desired setting, quickly adjust the TILT SETTING to above 10 UP to lock in the setting.
4. Set the tilt table for 10° roll left. Repeat Steps 2 and 3 of this section.
5. Set the tilt table for 0° pitch and roll.
6. Proceed to Calibrate ROLL OFFSET

O. Calibrate ROLL OFFSET

1. Use the GAIN control to set the GAIN POT /2 setting between 14- and 16-.
2. Check that the tilt table is set for 0° roll.
3. Set the ROLL ANGLE field to 0.0 ±1.0°.
 - To increment the value of the ROLL ANGLE, use the right inner knob to change the TILT SETTING to between 5 and 10 UP. When the TILT SETTING is set to between 5 and 10 UP, the value of the ROLL ANGLE field will slowly increase.
 - To decrement the value of ROLL ANGLE, use the right inner knob to change the TILT SETTING to between 5 and 10 DOWN. When the TILT SETTING is set to between 5 and 10 DOWN, the value of the ROLL ANGLE field will slowly decrease.
 - When you reach the desired setting, quickly adjust the TILT SETTING to above 10 UP to lock in the setting.
4. Set the tilt table to 10° roll right. The value should be 10.0R ±1.0°. If the value is out of range, repeat Calibrate ROLL GAIN
5. Set the tilt table to 10° roll left. The value should be 10.0L ±1.0°. If the value is out of range, repeat Calibrate ROLL GAIN
6. Set the tilt table to 0° roll. The value should be 0.0 ±1.0°. If the value is out of range, repeat this step (Calibrate ROLL OFFSET).
7. Proceed to Save Configuration


P. Save Configuration

1. Adjust the GAIN controls for a GAIN POT /2 setting to 4- or 5-.
2. The FAULTS field will display GYRO.
3. Set the TILT SETTING to 15.0D. The fault fields will flash indicating that your settings are being saved. If the save procedure is successful, the GYRO fault will disappear and the azimuth count will cycle through its entire number range.

Note: For an example, see

Save Configuration

4. If the GYRO fault remains, set TILT to 0 and repeat step 3.
5. After saving the configuration, this section is complete.

 For radar with an ARINC 429 gyro, start here after completing Starting at -30, slowly adjust the gain downward until the antenna clearance scan begins. This sh

Q. Calibrate AHRS ARINC 429 PITCH OFFSET

1. Adjust the GAIN buttons for a GAIN POT /2 setting to 11- or 12-.
2. Check that the tilt table is set for 0° pitch.
3. Set the PITCH ANGLE field to 0.0 ±1.0°.
 - To increment the value of the PITCH ANGLE, use the right inner knob to change the TILT SETTING to between 5 and 10 UP. When the TILT SETTING is set to between 5 and 10 UP, the value of the PITCH ANGLE field will slowly increase.
 - To decrement the value of PITCH ANGLE, use the right inner knob to change the TILT SETTING to between 5 and 10 DOWN. When the TILT SETTING is set to between 5 and 10 DOWN, the value of the PITCH ANGLE field will slowly decrease.
 - When you reach the desired setting, quickly adjust the TILT SETTING to above 10 UP to lock in the setting.
4. Set the tilt table to 10° pitch up. The value should be 10.0U ±1.0°. If the value is out of range, repeat Steps 1, 2 and 3 of this section.
5. Set the tilt table to 10° pitch down. The value should be 10.0D ±1.0°. If the value is out of range, repeat Steps 1, 2, 3 and 4 of this section.
6. Set the tilt table to 0° pitch. The value should be 0.0 ±1.0°.
7. Proceed to Calibrate AHRS ARINC 429 ROLL OFFSET

R. Calibrate AHRS ARINC 429 ROLL OFFSET

1. Adjust the GAIN controls for a GAIN POT setting to between 7- and 9-.
2. Check that the tilt table is set for 0° roll.
3. Set the ROLL ANGLE field to 0.0 ±1.0°.
 - To increment the value of the ROLL ANGLE, use the right inner knob to change the TILT SETTING to between 5 and 10 UP. When the TILT SETTING is set to between 5 and 10 UP, the value of the PITCH ANGLE field will slowly increase.
 - To decrement the value of ROLL ANGLE, use the right inner knob to change the TILT SETTING to between 5 and 10 DOWN. When the TILT SETTING is set to between 5 and 10 DOWN, the value of the ROLL ANGLE field will slowly decrease.
 - When you reach the desired setting, quickly adjust the TILT SETTING to above 10 UP to lock in the setting.
4. Set the tilt table to 10° roll right. The value should be 10.0R ±1.0°. If the value is out of range, repeat Calibrate AHRS ARINC 429 ROLL OFFSET
5. Set the tilt table to 10° roll left. The value should be 10.0L ±1.0°. If the value is out of range, repeat Calibrate AHRS ARINC 429 ROLL OFFSET
6. Set the tilt table to 0° roll. The value should be 0.0 ±1.0°.

7. Proceed to

Save Configuration

S. Save Configuration

1. Adjust the GAIN controls for a GAIN POT /2 setting to 4- or 5-.
2. The FAULTS field will display GYRO.
3. Set the TILT SETTING to 15.0D. The fault fields will flash indicating that your settings are being saved. If the save procedure is successful, the GYRO fault will disappear and the azimuth count will cycle through its entire number range.

Calibration		
GAIN POT /2:	5.0-	FAULTS:
PITCH ANGLE:	0.0U	
TILT SETTING:	15.0D	
ROLL ANGLE:	0.0R	
ROLL TRIM:	0.0R	
400 HZ REF:	0.0+	

4. If the GYRO fault remains, set TILT to 0 and repeat step 3.
5. After saving the configuration, this section is complete.

Bendix/King Replacement Sections END

5.10.2 Roll Trim Adjustment

➤ To adjust the Roll Trim Adjustment:

1. From the Maintenance Mode Page, select *Setup Radar*.
2. From the Radar Setup page, select *Roll Trim*.
3. The Roll Trim value appears on the Radar screen and can be modified by the Roll Trim control knob.
4. When you are done, press *Back* to save the new Roll Trim setting and return to the Radar Setup Page.
5. Press *Save* from the Radar Setup Page. Press *Cancel* to exit without saving changes.
6. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

5.10.3 RADAR Checkout

Perform a functional test of the RADAR system in accordance with manufacturers instructions. See the *MFD Pilot Guide* for display operation.

5.10.4 RADAR Sensor Communications Troubleshooting

If there is a communication or data error between the RADAR sensor and the MFD, one of the following messages will display on the bottom of the screen.

Table 23: Radar Sensor Error Messages

Message	Meaning/Action
Radar Sensor Data Is Invalid	Data received from the RADAR sensor system can not be used by the EX5000 <ul style="list-style-type: none"> ▪ Cycle power on the EX5000. ▪ See RADAR Sensor Installation and User's Manual for troubleshooting guidance.
Radar Sensor Has Failed	The RADAR sensor system has reported an error. <ul style="list-style-type: none"> ▪ Check R/T configuration module error log. ▪ See the RADAR Sensor Installation and User's Manual for troubleshooting guidance.
Radar Sensor Is Not Communicating	Communication of return data from the RADAR sensor to the MFD has been lost. <ul style="list-style-type: none"> ▪ Verify that the RADAR sensor is turned on and valid. ▪ Verify that the EX5000 is properly seat in its tray. ▪ Verify system wiring.
Invalid GPS Data and Radar is ON	The RADAR is ON and the EX5000 has no ground speed data available from the GPS/FMS. <ul style="list-style-type: none"> ▪ Verify the GPS/FMS is ON and valid. ▪ Verify system wiring. ▪ See the RADAR Sensor Installation and User's Manual for troubleshooting guidance.
Radar Automatic Standby Disabled	The RADAR is ON, the EX5000 RADAR automatic standby mode is disabled, and the EX5000 has no ground speed data available from the GPS/FMS. <ul style="list-style-type: none"> ▪ Verify the GPS/FMS is ON and valid. ▪ Verify system wiring. ▪ See the RADAR Sensor Installation and User's Manual for troubleshooting guidance.

5.11 Engine Instruments Setup

The MFD supports engine display on Cirrus, Columbia, Diamond, Lancair, Piper, and Symphony Aircraft by receiving data via RS232 and/or ARINC429 from an engine sensor interface unit specifically designed for each aircraft. Not all display functions are available on all aircraft. For wiring information, see Appendix O: *Wiring Diagram – Engine Sensors*.



Only activate the Engine Instruments Setup for those aircraft specifically included under Avidyne Service Bulletin, STC, or TC authorization. Do not set up the MFD Engine Sensor interface for any unapproved aircraft installation.

5.11.1 Engine Instruments Setup

➤ To set up the Engine Sensor:

1. From the Maintenance Mode Page, select Engine Setup. The Engine Instruments Setup Page displays.

Note: The options available on the Engine Instruments Setup Page can vary widely between different aircraft types and models. In this section, a number of different Engine Instrument Setup Pages are displayed. However, depending on the actual installation, your view may be different.




Figure 23: Engine Instruments Setup Pages

2. Depending on the aircraft type and model, you may need to select the **Sensor Type** installed in this airplane, which will be one of:
 - Avidyne SIU
 - Vision DPU
 - Avidyne DAU
 - Avidyne SIU/DAU

Not all aircraft require that you select the sensor type.

3. Select the model of this plane from the **Aircraft Model** pull-down list.



Ensure that you select the airplane type and model that matches this aircraft. Selecting the wrong model can result in displaying inaccurate data.



After you select the aircraft type, you **must** select a valid port for the connection, or press *Cancel* to cancel the setup. Pressing the *Save* button before you select a Port can cause the MFD to hang in an unusable state that must be factory reset.



For Software Part Number 530-00180-200 only: Ensure that you enter the Aircraft Model before pressing the *Save* button.

If you set the SIU/DAU Type to *Avidyne SIU/DAU* and press *Save* without specifying the Aircraft Type, the MFD will become unusable after restarting. In this case, you will need to replace the Compact Flash for the aircraft.

4. Depending on the aircraft type and model, the appropriate options are displayed. These options may include the following:
 - **Port**—If this option is available, select the MFD RS232 port to which the Engine interface unit is wired.

Note: For twin-engine aircraft, make selections for both the left and right ports.

- **DAU ARINC Port**—Select the ARINC port to which the Engine interface unit is wired.
- **Electrical/Rudder Trim Port**—Select the RS232 port from which electrical and rudder trim information will be received.
- **Fuel Quantity Port**—Select the RS232 port from which fuel quantity will be received.
- **Fuel Units**—Select whether to display fuel information in English or metric units.
- **Fuel Tank Size**—In gallons (Cirrus DAU aircraft only). Select the appropriate tank size for this aircraft.



If Fuel Tank Size displays, it is very important that you select the correct tank size for the aircraft. The MFD uses the selected tank size to determine fuel quantity.

- **Fuel to Tabs**—In gallons (Cirrus DAU aircraft only). Select the appropriate fuel to tabs level for this aircraft.



If Fuel to Tabs is displayed, it is very important that you select the correct fuel to tabs level for the aircraft.

Vacuum System Installed (Optional)—If the MFD software version supports a display of vacuum system pressure on the Engine Page, a checkbox displays on the Engine Setup page. *If a vacuum system with compatible vacuum pressure sensor is installed in the aircraft*, select this checkbox and use the knob to check the box.

- **Electrical (Optional)**—If this option is available, select the type of electrical system: Single Bus, Single Alternator; Single Bus, Dual Alternator; or Dual Bus, Dual Alternator. (Note that not all selections are available with all aircraft.)
- **Voltage (Optional)**—If this option is available, select 14V or 28V, as appropriate, for the aircraft installation. Only determines Engine Page display ranges for electrical system information.

5. When instructed, proceed to the Aircraft Setup Page to complete the Engine Setup.

Note: Upon completion of all configuration procedures, confirm that the MFD is communicating properly with the corresponding engine interface unit. This can be verified after the Engine Sensor setup is completed.

The MFD uses an RS232 data connection to receive data from the Engine Sensor Unit. An ARINC 429 connection is also used for specific aircraft.

Note: The data box at the bottom of the page shows the configuration of the SIU/DAU and whether data is being properly received.

If the Engine Setup settings do not match with the configuration settings of the SIU/DAU, you will see a yellow annunciation alerting you to recheck configuration of this page and/or the configuration settings of the SIU/DAU.

If the SIU/DAU was off or not properly connected when you entered the Engine Setup page, but subsequently was properly selected and operating correctly, the Engine Setup Page status box may not be properly refreshed to reflect this.

Confirm that the correct Engine Setup options are selected, press **Save**, and restart the MFD. After restarting, confirm that the MFD is properly receiving the engine data from the SIU/DAU.

Note: In the event that the aircraft model and type are configured correctly, but the DAU Status box displays a configuration error, press the 'Re-Sync' button. This will fix the problem.

Note: Under certain circumstances, the Engine Page may continue to indicate normal DAU communication even when communication is lost between the MFD and DAU. Additionally, the calibration buttons remain on the page, even though they are inactive. If this occurs, exit the Engine Page. When you reselect the Engine Page, the appropriate status messages will display.

Fuel Quantity Calibration (Optional)

Fuel quantity indicator calibration is used to compensate for aircraft-to-aircraft variations in the fuel quantities reported by the Engine Data Acquisition Unit (DAU). If available, select the *Fuel Cal* button d from the Engine Instruments Setup Page.



When upgrading an MFD, be sure to use the Configuration Save and Restore Utility instead of recalibrating the fuel quantity. See Section 5.3 Using the Configuration Save and Restore (CSR) Utility for more information.

Note: This option is not available on all aircraft. This option is only available with software part numbers 530-00137-000, 530-00137-001, 530-00170-000, 530-00170-002, 530-00180-002, , 530-00201-002 and 053-00235-002.

➔ The fuel quantity indicator can only be calibrated if the DAU is communicating with the MFD and sending valid fuel quantity data. If the DAU is not communicating with the MFD, a DAU failure screen is displayed when the Fuel Cal Page is selected. In this case, the only available selection is to exit the page.

The Fuel Quantity Indicator Calibration Page displays the current fuel quantity indicator calibration values. Different options are available depending on the state of the fuel quantity indicator calibration. The three states of the fuel quantity indicator calibration are:

1. Not Calibrated

2. Calibration Underway

3. Calibrated

➤ To calibrate fuel quantity for 530-00137-() and most 530-00170-(), 530-00180-(), 530-00195-(), 530-00201-(), and 053-00235-() software:

1. From the Engine Instruments Setup Page, select *Fuel Cal*.

2. From the Not Calibrated state, select *Begin Cal*.

- The state of fuel calibration changes to Underway and the fuel quantity indicator can be calibrated.
- If you press *Exit*, the Engine Instruments Setup Page displays with the calibration state unchanged.

3. Use the right knob to select the current calibration point. The selected calibration point is highlighted and the value displayed is the current reported quantity from the DAU. A message at the bottom of the screen prompts you to add the appropriate amount of fuel. Then press *Accept Value* once the value reported from the DAU has stabilized.

If the DAU reported value is not within 2 gallons of the test point value, the value is not accepted and the message "DAU Reported Fuel Quantity Out Of Tolerance" is displayed. Recalibrate the current calibration point.

If you cannot correctly calibrate the fuel quantity, inspect the fuel tank and fuel level sensor for problems.

4. Repeat this process for all the calibration points.

5. To pause the calibration process and turn off power to the MFD, press *Save* to save the interim calibration values.

6. Once all points have been calibrated, press *Calibration Complete*. The calibration factors are computed and applied to DAU reported fuel quantity.

7. When you are done, press *Save*. Press *Cancel* to exit without saving changes.

8. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

Other options from the Underway state are to *Restore Last Cal* and *Clear Cal*:

- Press *Restore Last Cal* to restore the calibration values from the last completed calibration. The calibration state is change to Calibrated.
- Press *Clear Cal* to clear all calibration values. The state changes to Not Calibrated.

An *Are You Sure?* prompt gives you the chance to reconsider the decision to either restore or clear the fuel calculations.

- ➔ Pressing *Cancel* from the Underway state causes the current calibration session to end without saving any interim calibration values.

Note: For the fuel calibration procedure for the 530-00170-000, 530-00180-000, 530-00195-000, 530-00195-001, 530-00195-010, 530-00201-000 and 053-00235-000 software, see the Piper Process Specification document PPS60185.

Torque Calibration (Optional)

For some aircraft, the MFD provides an interface to the Torque Calibration feature. If this feature is available, the *Torque Cal* button displays.

For information about using the Torque Calibration feature, see the factory procedures for the aircraft.

5.11.2 Engine Sensor Checkout

After restarting the MFD, view the Engine page to verify data communication. Operate the aircraft engine to confirm correct operation of all sensors.

- ➔ The Percent Power function will not operate correctly on some models until the Aircraft Setup has been completed.

5.12 Aircraft Setup

The options on the Aircraft Setup Page depend on the aircraft model and selected options for that aircraft. These options may include:

- Auxiliary Data
- XM and FIS-B Broadcast Weather Datalink
- Long Range Tanks
- Checklists
- Dimming Bus

Note: The available options depend on the aircraft model, additional purchased features and installed software. Your aircraft will not have all options available.

- To configure the Aircraft Setup Page:

1. From Maintenance Mode, select Aircraft Setup. The Aircraft Setup Page displays:





Figure 24: Aircraft Setup Page with XM Broadcast Datalink



Sky Trax 100/100B, FDL-978-RX, NGT-9000, GTX-345 Weather selection on Aircraft Setup Page

2. Set the options that appear on the Aircraft Setup Page. These options will vary depending on the aircraft model and optional features selected.
3. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
4. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

5.12.1 Auxiliary Data Setup

On some aircraft, you can optionally configure the MFD to receive pressure altitude and outside air data (OAT) from the PFD via a ARINC 429 interface.

If Aux Data is available, configure it as follows:

- **Aux Data**—Select Entegra PFD. This allows the MFD to receive ARINC 429 data from the PFD for input to the % Power calculations.
- **Port**—Select the MFD ARINC port to which the PFD is wired.

Auxiliary Data Checkout

After the MFD has been restarted, any of the following messages may appear in the message bar on any page and in the message list on the Setup page.

Table 24: Auxiliary Data Messages

Message	Meaning
PFD is Operating Normally	Verifies that pressure altitude and OAT data received by the MFD is valid.
PFD is Not Communicating	Pressure altitude or OAT data are not being received by the MFD.

5.12.2 XM Broadcast Datalink and FIS-B Setup

Note: MLB 700 is no longer supported with software release 8.2.

Configure Broadcast as follows:

Broadcast—XM Radio, SkyTrax 100 Radio, Capstone Radio, or None. This enables the weather datalink functionality. **Do Not Use SkyTrax 100 Radio, Use Capstone Radio instead.**

Port—Select the RS-232 port wired to the Broadcast Datalink receiver.

Baud (Applicable only for FIS-B) — Select 38,400 or 115,200.

5.12.3 XM Broadcast Datalink and FIS-B Checkout

XM Broadcast Datalink Checkout

To check the XM Broadcast Datalink Installation:

1. Power up the MFD and Broadcast Datalink Receiver and select the Trip Page.
2. From the Trip Page, press *Display* to view Broadcast Status (down pointing arrow). If the MFD reports a Receiver ID or Serial Number, the receiver is communicating with the MFD and the RS-232 wiring is correct.
3. Position the aircraft in an area open to the sky.
4. Power up the MFD and Broadcast Datalink Receiver and select the Trip Page.
5. Check the Signal Quality, as displayed on the lower half of the Trip Page.

Good—Confirms the receiver is detecting the satellite signals.

Marginal or **Weak**—May require repositioning the aircraft to better location.

None—Indicates a bad antenna, cable, connection or receiver.

For more information, see the *XMD076 XM Receiver Installation Manual and Activation Instructions* from Heads Up Technologies or contact Heads Up Technologies at service@heads-up.com or (972) 407-1131.

Note: If Broadcast Datalink does not connect because the XM trial period has expired, call Heads Up Technologies at (972) 407-1131 to activate the account for testing. For information about customer activation, see the *EX5000 Multi-Function Display Pilot's Guide*.

FIS-B Checkout


To check the XM Broadcast Datalink Installation:


1. After Setup is complete boot the MFD into flight mode and go to the Aux page. Verify the following message is displayed: "FIS-B Receiver is Operating Normally".

After restarting the MFD, either of the following messages may appear in the message bar on any page and in the message list on the Aux or Setup Page.

Table 25: Broadcast Datalink and FIS-B Messages

Message	Meaning
Broadcast is Operating Normally	Verifies that the MFD is communicating with the Broadcast Datalink Receiver
FIS-B Receiver is Operating Normally	Verifies that the MFD is communicating with the Broadcast Datalink Receiver
Broadcast is Not Communicating. (After 5 minutes of no communication).	The MFD is not communicating with the Broadcast Datalink Receiver. Check power and signal wiring.
FIS-B Receiver is Not Communicating. (After 5 minutes of no communication).	The MFD is not communicating with the FIS-B Receiver. Check power and signal wiring.

 Make a note of the Receiver ID for the aircraft owner, who will need it to begin Broadcast Datalink service.

 To finish the checkout process, see Section 6.6 XM Broadcast Datalink Satellite Reception Confirmation.

5.12.4 Long Range Tanks Setup

Some aircraft are equipped with long range fuel tanks. If the Long Range Fuel Tanks feature is available on this aircraft, the **Long Range Tanks Installed?** checkbox will be available from the Aircraft Setup Page. Check **Long Range Tanks Installed?** to allow the MFD to track long range fuel usage.

5.12.5 Checklists Setup (Cirrus & Columbia Only)

EX5000 MFDs in Cirrus & Columbia aircraft support Checklists. If Checklists are available for this aircraft, the Checklist pull-down will be available from the Aircraft Setup Page.

Use the Checklist pull-down to select the appropriate aircraft and serial number range. Checklists are only available for aircraft listed in the Checklist pull-down.



Caution: The checklist function is only authorized for use specifically with the aircraft types that are listed on the Aircraft Setup page. **Do not select any aircraft type that does not match the installation aircraft.** If the installation aircraft type is not listed as a checklist option on the Aircraft Setup page, then the checklist function is not available for that aircraft. **Selecting an inappropriate aircraft type can lead to incorrect operation of the aircraft by the pilot.**

Note: This option is only available with software part numbers 530-00117-000, 530-00130-000, 530-00148-000, 530-00162-000/002, 530-00180-100/200, 530-00195-100/110/210, 530-00201-100/200, and 530-00235-100/200..

Note: The current revision of the installed checklists will appear on the splash screen on restarting the MFD. If you modify the Checklist settings in the Aircraft setup page, restart the MFD and observe the splash screen to verify the current revision of the Checklist.

Note: If you are using an OEM-supplied build of Checklist Loader, follow the instructions in the manual, "Multi-Function Display Checklist Editor - User's Guide" (600-00144-000, Latest Revision).

5.12.6 Dimming Bus Setup

On all aircraft, you can configure the LEDs on the bezel to better match the other cockpit instrument lights on the aircraft dimming bus.

➤ To set the dimming bus:

1. Highlight the Brightest dimming voltage selection. An additional button, *Set Voltage*, appears below the *Save* button.
2. Adjust the Airplane dimming bus (usually a knob) to the full bright level. Monitor the dimming bus voltage on the MFD below the selection boxes. When at full bright, press *Set Voltage* to update the highlighted field.
3. Highlight the Darkest dimming voltage selection and adjust the airplane dimming bus to a level so that the other cockpit instruments are at their lowest brightness level.
4. Press *Set Voltage* again to update the Darkest dimming voltage field.

5.12.7 Dimming Bus Checkout

Restart the MFD. Adjust the aircraft dimming bus and verify that the MFD bezel LEDs match the rest of the cockpit instrument lamps and lights.

5.13 Map Setup

The MFD can overlay Traffic intruders and Lightning strikes on the Map pages. To utilize this feature, configure Map Heading with the appropriate source of heading or ground track to match the aircraft wiring. For more information about wiring, see Figure 3, Figure 4, and Figure 5.

Table 26: Map Heading Source Options

Values	Notes
None (Use GPS Track)	The GPS/FMS track will be used as the Map orientation reference.
Entegra	Uses the Avidyne EXP5000 Primary Flight Display (PFD) for heading. Can also use another low-speed ARINC429 heading source that provides label 320, magentic heading.
GPS/FMS	The EX500/EX600 will use the GPS/FMS sensor ARINC 429 input for heading information. The GPS/FMS system may require supplemental signal converters to generate heading information usable to the EX500/EX600. Refer to GPS/FMS system installation manuals for configuration options.
Synchro	The EX500/EX600 will use ARINC 407 synchro input for heading information.
Stormscope	The EX500/EX600 will use the lightning sensor input for heading information. (WX500 must be configured for synchro)
Traffic	The EX500/EX600 will use the traffic sensor input for heading information. (only present with TAS/TCAS sensors)

The MFD can receive heading data transmitted from one of the following sources:

- Avidyne Entegra Primary Flight Display (PFD).
- GPS/FMS (via 429) capable of providing heading information
- L-3 StormScope (via RS -232)
- TAS L-3 SkyWatch (must have 1.6 software level or higher)

The MFD can receive aircraft ground track from one of the following sources.

- GPS/FMS (via 429)
- GPS (via RS-232)

5.13.1 Setup with Entegra PFD as Heading Source

➤ To configure the MFD with the PFD as a heading source:

1. From the Maintenance Mode Page, select Aircraft Setup.
2. Ensure that the Aux Data field on the MFD Aircraft Setup Page is configured to read data from the Entegra PFD.
3. Return to the Maintenance Mode Page and select Map Setup.
4. Set the following option:

Map Heading—Entegra

When you are done, press *Save*. Press *Cancel* to exit without saving changes.

5. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

5.13.2 Setup with GPS/FMS as Heading Source

- To configure the MFD with the GPS/FMS as a heading source:
 1. From the Maintenance Mode Page, select GPS Setup.
 2. Ensure that GAMA 429 GPS has been selected in the GPS Setup.
 3. Return to the Maintenance Mode Page and select Map Setup.
 4. Set the following option:
Map Heading—GPS/FMS
 5. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
 6. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

5.13.3 Setup with StormScope as Heading Source

- To configure the MFD with the StormScope as a heading source:
 1. From the Maintenance Mode Page, select Lightning Setup.
 2. Ensure that StormScope is configured for Synchro or Stepper Stabilization in the Lightning Setup Page.
 3. Return to the Maintenance Mode Page and select Map Setup.
 4. Set the following option:
Map Heading—StormScope
 5. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
 6. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

5.13.4 Setup with Traffic (TAS) as Heading Source

- To configure the MFD with the Traffic as a heading source:
 1. From the Maintenance Mode Page, select Traffic Setup.
 2. Ensure that TAS is selected as the traffic sensor in the Traffic Setup Page.
 3. Return to the Maintenance Mode Page and select Map Setup.
 4. Set the following option:
Map Heading—Traffic (TAS)
 5. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
 6. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.



If SkyWatch is used as the heading source, the SkyWatch software level must be 1.6 or higher. SkyWatch software levels lower than 1.5 can cause the heading to be off by a significant factor.

5.13.5 Map Orientation with Track

If heading information is unavailable, Track data can be used for Map, Lightning, and Traffic overlays. Track data comes from the GPS/FMS. Track is the actual direction the aircraft is moving relative to the earth's surface.

Note: Avidyne recommends using a Heading reference for the overlay feature. Only use Track if Heading is not available. Track does not compensate for the “crab” angle of the aircraft.

➤ To configure the MFD with GPS track in place of a heading source:

1. From the Maintenance Mode Page, select Map Setup. The Map Setup Page displays:




Figure 25: Map Setup Page for Track

2. Set the following option:

Map Heading—None (Use GPS Track)

3. When you are done, press *Save*. Press *Cancel* to exit without saving changes.
4. Changes do not take effect until the MFD has been restarted. From the Maintenance Mode Page, press *Restart System*.

5.13.6 Map Heading/Track Status

➤ To check the operational status of your heading or track:

1. Return the MFD to normal operation, that is, save all changes and restart the MFD. The GPS/FMS must be on and locked onto a valid position. The selected heading source (GPS, StormScope, SkyWatch, must be on and operational.
2. From the Map Page, look for the following:
 - **Heading**—The box at the top center of the Map display should contain the letters HDG and the value should match the aircraft compass system.
 - **Track**—The box at the top center of the Map display should contain the letters TRK and an appropriate value.



Fault Conditions: The loss of Heading will cause the Center and Forward views of Map to be oriented to Track and the Heading indicator at the top of the Map Page will switch to a Track indicator. Loss of Heading and Track will cause the Heading indicator to display 3 dash lines. The airplane symbol will be replaced by a white “+” sign and the map will be in a north up orientation.

6. Post-Installation Check

After installing the MFD, you need to perform a post-installation check to ensure that all components are working properly.

6.1 System Info Pages

Avidyne provides three System Info pages to help you determine if system settings are correct and functioning.

6.1.1 System Info Platform Page

The Platform Page provides information about the hardware platform and settings of your MFD.




Figure 26: System Info—Platform Page

6.1.2 System Info Port Page

The Port Page displays the ports selected for various features during the setup process.




Figure 27: System Info—Port Page

6.2 Electro-Magnetic Compatibility (EMC) Check

The EMC check verifies that all of the electronic systems installed on the aircraft are compatible. Operating the MFD should not result in Nav flags, constant location lightning strikes on the WX-500 sensor, noise on COMM channels, or other phenomena.

- **COM Radios**—Scan through radio channels to ensure there is no interference caused by the MFD. Check random frequencies from 118.00 MHz through 136.975 MHz as well as your local ground and tower frequencies to ensure there is no break in squelch due to the installation.
- **GPS**—Ensure that correct position is displayed and that there is no change in satellite signal strength with the MFD powered off.
- **Autopilot**—Ensure that autopilot Self Test passes OK with the MFD powered on.
- **Other Instruments**—Verify there is no adverse effect on other instruments with the MFD powered on.

6.3 TWX670 Lightning Sensor Strike Test

With a TWX670 lightning sensor installed and set up, the Maintenance Mode page will have a *Lightning Strike Test* key which enables you to test the lightning sensor.

To perform the Lightning Strike Test:

1. On the Maintenance Mode page, press *Lightning Strike Test*.
2. The Map page opens and displays the following strike test pattern.




Figure 28: TWX670 Lightning Sensor Strike Test Pattern

3. Verify the following:

The display shows four boxes (one at each of the four cardinal directions). A tight cluster of test strikes within each of these boxes is a “pass” condition.

One or more boxes lacking a cluster of test strikes is an indication of a “fail” condition.

The display shows strikes from thunderstorms as well as test strikes; therefore it is not unusual to see strikes outside the boxes. Look for a cluster of test strikes within each of the boxes to make a pass/fail determination, not at the presence of strikes outside the boxes.

A poorly clustered set of test strikes, whether within or outside of the bounding box, may be an indication of noise.

6.4 WX-500 Lightning Sensor Strike Test

With a WX-500 lightning sensor installed and set up, the Maintenance Mode page will have a *Lightning Strike Test* key which enables you to test the lightning sensor.

To perform the Lightning Strike Test:

2. On the Maintenance Mode page, press *Lightning Strike Test*.
2. The Map page opens and displays a single strike on the 15 mile range and 45 degrees relative bearing. If the strike does not appear in that position, there may be a heading source, wiring, or MFD setup problem.
3. Rotate the aircraft to the 4 cardinal compass points and perform the strike test. The strike should display at 45 degrees relative bearing at each heading point

6.5 Traffic Test

After completing all configuration procedures, confirm that the MFD is configured for the correct Traffic sensor.

6.6 XM Broadcast Datalink Satellite Reception Confirmation

The broadcast satellite network transmits signals that are received by an external Datalink receiver, which sends the information on to the MFD through a serial connection. If the Datalink antenna is not properly installed, or if there is excessive electromagnetic interference (such as a nearby radio transmitter or inadequately grounded electronics), the system will not achieve consistent reception.

➤ To assess system performance.

1. Bring the aircraft to an area that has as few obstacles to line-of-sight viewing to the southern horizon as possible.
2. Select the Trip page on the MFD.
3. Press *Display* until Broadcast (down-pointing arrow) Status is selected.
4. The Signal Quality will be reported as Good, Marginal, Weak, or None. If the Broadcast Receiver is working, the antenna and cabling are correct, and the aircraft is in view of at least one Broadcast datalink satellite, the Signal Quality will be “Good” and the Receiver ID will be reported.
5. If the Signal Quality is not reported as Good, check for possible causes and solutions:

Possible Cause	Possible Solution
The antenna field of view is obstructed.	<p>Try moving or rotating the aircraft.</p> <p>Note: If rotation works, the antenna location on the aircraft may not be optimal</p>
There is a local source of electromagnetic interference.	<ul style="list-style-type: none"> ▪ Try shutting off any nearby sources (such as VHF radios, alternators and magnetos). ▪ Relocate the aircraft away from potential nearby sources. ▪ Check electrical connections to ensure there is no improper grounding. ▪ The antenna and cable are not properly installed. ▪ The antenna may not be properly connected to the ground plane. ▪ The cable may not be properly connected to the antenna or the EX5000.

See www.avidyne.com for additional information.

6.7 Magnetic Compass Swing

After installation and EMI checks are complete, perform a magnetic compass “swing” in accordance with the aircraft installation manual for updating the heading correction card in accordance with 14 CFR 23.1327 and 23.1547.

7. MFD General Maintenance

This section briefly describes maintenance procedures that are done by the aircraft owner (or pilot). This information is also available in the MFD Pilot's Guides for all aircraft.

7.1 Cleaning the EX5000 Screen

If your EX5000 screen should become dirty due to fingerprints or dust, clean the screen using the following materials and methods:

- A clean, soft lint free cloth such as 3M Ultra-Brite Cloth # 2011 or similar.
- A cleaning solution composed of de-ionized water or isopropyl alcohol (IPA).

Always apply the cleaning solution directly onto the cloth. **Never** spray cleaner directly onto the screen.

Note: Use caution when using IPA as it is flammable.

Using any other chemicals or materials voids the warranty.

The EX5000 screen is made of a plastic film that is vulnerable to scratches, damage by sharp articles or improper cleaners. Use care when cleaning.

7.2 MFD Data Updates

Avidyne makes use of three different types of data that can optionally be uploaded to or downloaded from your EX5000:

- **NavData**—For the Map Page, Avidyne uses NavData from Jeppesen Sanderson, Inc. it is your duty as pilot in command to ensure that the data you fly with remains up to date.
- **CMax™ Chart Data**—An optional Avidyne feature that allows you to view JeppView chart data on your EX5000.
- **EMax™ Total Engine Management**—EMax tracks engine and other data, which you can download from the EX5000 to a PC for analysis.

Note: For software part numbers 530-00180-() and above, you can use a Zip Drive or USB Flash Memory Drive to move data between your PC and the EX5000.

For software part numbers prior to 530-00180-(), only a Zip Drive Dataloader can be used.

➔ The Zip Drive or USB Flash Memory Drive are referred to here as a *Portable USB Device*.

For more information about the databases, and about loading data from your PC to a Portable USB Device, see the *Avidyne Data Update Guide*.

This section describes moving data from your Portable USB Device to the EX5000.



If using a Zip Drive Dataloader:

- Allowing the portable Zip Drive to dangle by the cable can result in damage to your MFD, or the Drive, as well as a data load failure.
- Do not insert the Zip disk into the Zip Drive until the regular start screen displays on the MFD. The disk may be damaged if it is already in the Zip Drive when power is applied.
- After loading the CMax data into your MFD, wait until the disk is ejected from the drive before unplugging the Drive, or powering off the MFD. Unplugging the Zip Drive with the disk still engaged may cause damage to the disk.


If using a USB Flash Memory:

- USB Flash Memory is only available for software part numbers 530-00180-() and later releases.
- Avidyne strongly suggests that, to avoid confusion, you reserve a USB Flash Memory Drive solely for EX5000 database transfers.
- After uploading data, do not remove the USB Flash Memory Drive until you see and acknowledge the regular EX5000 Startup screen.

Note: When removing the rubber cap from the data port, pull the cap gently **from the top** until it pops out. Make sure the cap is all the way out before plugging anything into the USB port.

Do not tug on the tab at the bottom of the cap, this could separate the cap from the EX5000 bezel.

7.2.1 Loading NavData (the Navigation Database)

Your new EX5000 will be loaded with an up-to-date navigation database. Updates to the EX5000 NavData database are available from Jeppesen Sanderson, Inc. every 28 days and can be purchased either individually or on a subscription basis.

Once you have downloaded the Nav from your PC to a Portable USB Device, as described in the *Avidyne Data Update Guide*, you will need to upload the data to your EX5000.

➤ To load NavData to your EX5000:

1. Bring the Portable USB Device to the EX5000 at the aircraft.
2. Turn power OFF to the EX5000.
3. Connect the data source to the EX5000:
 - If using a USB Flash Memory Drive, plug it into the data port on the front of the EX5000.
 - If using a Zip Drive Dataloader, put the Zip disk into the Zip Drive. Connect one end of the cable to the Zip Drive and the other end to the EX5000 data port.

Note: Ensure that the Dataloader is supported and not dangling by the cable. Letting the Dataloader dangle can cause permanent damage to the data port. It can also cause an intermittent connection, which will result in an unsuccessful data update

4. Turn on the master switch to power up the EX5000. The Dataloader Page displays.

Note: If the regular start screen displays, the EX5000 did not detect the Portable USB Device. Check the connection between the Portable USB Device and the EX5000, then restart the procedure.

5. Press *Proceed*. Do not turn off the EX5000 or disconnect the cable during a data load. The data load is complete when the regular startup Page displays.
6. After the startup Page displays, turn off power to the EX5000, remove your Portable USB Device, and then turn the EX5000 power back on.
7. This step ensures that all data has been checked in self-test and the MFD is ready for use.
8. Store the Portable USB Device in a safe place.

7.2.2 Loading CMax Chart Data

Once you have downloaded the CMax data from your PC to a Portable USB Device, as described in the *Avidyne Data Update Guide*, you will need to upload the data to your EX5000.

➤ To load CMax Data to your EX5000:


1. With the MFD power OFF:

- If using a USB Flash Memory Drive, plug it into the data port on the front of the EX5000.
- If using a Zip Drive Dataloader, connect one end of the cable to the Zip Drive and the other end to the EX5000 data port. Do not insert the Zip disk into the Zip Drive until after you turn on the MFD (in step 2).

Note: Ensure that the Dataloader is supported and not dangling by the cable. Letting the Dataloader dangle can cause permanent damage to the data port. It can also cause an intermittent connection, which will result in an unsuccessful data update.

2. Turn on the MFD. If you are using a Zip Drive, insert the Zip disk into the Zip Drive when the initial Avidyne logo screen displays.

3. The Dataloader Page displays.

 If this is the first-ever update, you may see a warning that you are about to load older data than the MFD already contains. This is because the preloaded demo charts expire in the year 2020, so the warning message is normal.

Press *Proceed* to start the chart data load.

4. The Dataloader Page shows the progress as it loads the data into the MFD. After loading the data, the Dataloader performs an integrity check on the data and displays a successful data load message if all data is valid.

5. When the operation is complete, the EX5000 will continue to the normal startup Page.

6. At this point, turn off power to the EX5000, remove your Portable USB Device, and then turn the EX5000 power back on.

This step ensures that all data has been checked in self-test and the MFD is ready for use

7. Confirm the valid dates of the Chart data as reported on the Startup Screen.

8. Go to the Chart Page and select a chart from an airport known to be in your subscription coverage area. Confirm that the chart is available.

9. Store the Portable USB Device in a safe place.

7.2.3 Downloading EMax Data

You can download the engine log files from the EX5000 using either a Zip Drive and Zip disk or a USB Flash Memory Drive.

Note: If any of the downloaded engine log files contains file format errors, you may receive an erroneous caution that the data transfer failed. Check your Portable USB Device for the transferred files.

➤ To download the stored engine data log files:

1. Turn power OFF to the EX5000

2. Connect the data source to the EX5000:

- If using a USB Flash Memory Drive, plug it into the data port on the front of the EX5000.
- If using a Zip Drive Dataloader, connect one end of the cable to the Zip Drive and the other end to the EX5000 data port. The Zip Drive must be empty.

Note: Ensure that the Dataloader is supported and not dangling by the cable. Letting the Dataloader dangle can cause permanent damage to the data port. It can also cause an intermittent connection, which will result in an unsuccessful data download.

4. If using a Zip Drive, put a compatible blank disk into the Zip Drive when the Avidyne screen displays.
5. The EX5000 will display a message similar to the following:
Ready to Write Engine/Narrowcast Data to Removable Media.
6. To begin the download, press *Proceed*. Do not turn off the EX5000 or disconnect the Portable USB Device during data transfer.
To cancel the download, press *Cancel*.
7. When the data transfer is complete the regular start screen displays. If you are using a Zip Drive, the disk is automatically ejected from the Zip Drive.
8. At this point, turn off power to the EX5000, remove your Portable USB Device, and then turn the EX5000 power back on. This step ensures that all data has been checked in self-test and the MFD is ready for use
9. You can now bring the Portable USB Device to a PC and download the EMax data. See the *Avidyne Data Update Guide* for more information.

8. Avidyne Technical Support and Service

8.1 Technical Support

Avidyne's web site contains information that may assist the operator and installer with questions or problems with their Avidyne product.

www.avidyne.com

Technical support questions may be submitted, 24 hours per day, via the following.

- Email: techsupport@avidyne.com
- Fax: 781-402-7599
- Voice: 1-888-723-7592
- Internet: www.Avidyne.com

An Avidyne Technical Support Representative will respond as soon as possible. Avidyne business hours are:

- Monday through Friday: 8:00 AM to 5:00 PM Eastern Time

Please include the part number, revision number and serial number of the unit in all correspondences. For problem reporting, please provide as many details associated with the problem as possible.

8.2 Service

Before you return the unit for service, contact Avidyne at 888-723-7592 to obtain a Return Merchandise Authorization (RMA) number.

Securely pack the unit in the original Avidyne shipping carton, write the RMA number on the outside of the carton, and return it to the address provided by the Avidyne Customer Service Representative.

Include your name, complete shipping address, daytime telephone number, a complete description of the problem, the desired return date, and shipping method.

If the original shipping carton or other suitable foam packing is not available, contact Avidyne to arrange for packaging materials. Avidyne is not responsible for damage due to poorly packaged

Appendix A: Environmental Qualification Data

RTCA/DO-160E Environmental Qualification Form

NOMENCLATURE: MFD

PART NO: 700-00004-001/002/003/004/005/006/007/008/009/010/103/104

MANUFACTURER: AVIDYNE CORPORATION

ADDRESS: 4 Middlesex Green - Suite 221, 561 Virginia Road, Concord MA 01742

Table 27: RTCA/DO-160E Environmental Qualification Form Part No. 700-00004-()

Environmental Tests	RTCA/DO-160E Section	Conducted Test Category
Temperature and Altitude		
I Low Temp	4.5.1	Equipment qualified to Category D1
I High Temp	4.5.2 & 4.5.3	Equipment qualified to Category D1
I In-Flight Loss of Cooling	4.5.4	Equipment qualified to Category V
I Altitude	4.6.1	Equipment qualified to Category D1
I Decompression	4.6.2	Equipment qualified to Category D1
I Overpressure	4.6.3	Equipment qualified to Category D1
Temperature Variation	5	Equipment qualified to Category B
Humidity	6	Equipment qualified to Category A
Operational Shock	7.2	Equipment qualified to Category B
Crash Safety	7.3	Equipment qualified to Category B
Vibration	8	Equipment qualified to Category S, Curve M
Explosive Proofness	9	Category X, no test performed
Waterproofness	10	Category X, no test performed
Fluids Susceptibility	11	Category X, no test performed
Sand and Dust	12	Category X, no test performed
Fungus Resistance	13	Category X, no test performed
Salt Spray	14	Category X, no test performed
Magnetic Effects	15	Equipment qualified to Category Z
Power Input	16	Equipment qualified to Category B
Voltage Spike	17	Equipment qualified to Category A
Audio Frequency Conducted Susceptibility	18	Equipment qualified to Category Z
Induced Signal Susceptibility	19	Equipment qualified to Category AC
Radio Frequency Susceptibility	20	Equipment qualified to Category D (Conducted) /Z (Radiated)
Emission of Radio Frequency Energy	21	Equipment qualified to M
Lightning Induced Transient Susceptibility	22	Equipment qualified to A3E3X (Signal Inputs), A4E4X (Power Input)
Lightning Direct Effects	23	Category X, no test performed
Icing	24	Category X, no test performed
Electrostatic Discharge	25	Equipment qualified to Category A
Fire/Flammability	26	Category X, no test performed

RTCA/DO-160E Environmental Qualification Form

NOMENCLATURE: MFD

PART NO: 700-00030-005/805

MANUFACTURER: AVIDYNE CORPORATION

ADDRESS: 4 Middlesex Green - Suite 221, 561 Virginia Road, Concord MA 01742

Table 28: RTCA/DO-160E Environmental Qualification Form Part No. 700-00030-()

Environmental Tests	RTCA/DO-160E Section	Test Category
Temperature and Altitude		
I Low Temp	4.5.1	Equipment qualified to Category D1
I High Temp	4.5.2 & 4.5.3	Equipment qualified to Category D1
I In-Flight Loss of Cooling	4.5.4	Equipment qualified to Category V
I Altitude	4.6.1	Equipment qualified to Category D1
I Decompression	4.6.2	Equipment qualified to Category D1
I Overpressure	4.6.3	Equipment qualified to Category D1
Temperature Variation	5	Equipment qualified to Category B
Humidity	6	Equipment qualified to Category A
Operational Shocks	7.2	Equipment qualified to Category B
Crash Safety	7.3	Equipment qualified to Category B
Vibration	8	Equipment qualified to Category S, Curve M
Explosive Proofness	9	Category X, no test performed
Waterproofness	10	Category X, no test performed
Fluids Susceptibility	11	Category X, no test performed
Sand and Dust	12	Category X, no test performed
Fungus Resistance	13	Category X, no test performed
Salt Spray	14	Category X, no test performed
Magnetic Effects	15	Equipment qualified to Category Z
Power Input	16	Equipment qualified to Category B
Voltage Spike	17	Equipment qualified to Category A
Audio Frequency Conducted Susceptibility	18	Equipment qualified to Category Z
Induced Signal Susceptibility	19	Equipment qualified to Category AC
Radio Frequency Susceptibility	20	Equipment qualified to Category D (Conducted) / Z (Radiated)
Emission of Radio Frequency Energy	21	Equipment qualified to Category M
Lightning Induced Transient Susceptibility	22	Equipment qualified to A3E3X (Signal Inputs), A4E4X (Power Input)
Lightning Direct Effects	23	Category X, no test performed
Icing	24	Category X, no test performed
Electrostatic Discharge	25	Equipment qualified to Category A
Fire/Flammability	26	Category X, no test performed

Appendix B: Flight Manual Supplement Information

A flight manual supplement should be created for each installation, using Avidyne's FAA approved AFMS as a guideline. Hard and electronic copies are available by any of the following means:

Calling Avidyne Technical Support at 1-800-AVIDYNE

E-mail: techsupport@avidyne.com


Web: www.avidyne.com

Appendix C STC Permission

Avidyne Corporation hereby grants permission to all National Aviation Authority (FAA, CAA, JAA) approved installers to use data from all STCs and amendments Avidyne has received to modify aircraft. Copies of the STCs and amendments are available upon request or at the Avidyne web site Technical Publication page.

Appendix D: Landscape EX5000 Dimensions


Dimensions for the EX5000 (700-00004-002)



Note: Dimensions for EX5000 (700-00004-008 and -010 and 700-00030-805) are identical as shown, but without BNC connector J1.


Appendix E: Landscape EX5000 with Integrated Datalink Dimensions

Dimensions for the EX5000 (700-00004-004 & -006, 700-00030-005)




Appendix F: Portrait EX5000 Dimensions


Dimensions for the EX5000 (700-00004-104)




Appendix G: Landscape Cutout Dimensions



Appendix H: Portrait Cutout Dimensions




Appendix I: Wiring Diagram – Power, Dimming Bus, and Exceedance Horn




Note: Port assignments shown are nominal assignments. You can select ports as required in Maintenance Mode setup pages, as long as sensors are wired to the corresponding pins.


Appendix J: Wiring Diagram – GPS/FMS



GPS/FMS SOURCE 1 INTERCONNECT (NOTE 2)



GPS/FMS SOURCE 2 INTERCONNECT (NOTE 3)




NOTES:

1. PORT ASSIGNMENTS SHOWN ARE FOR EXAMPLE ONLY. SELECT PORTS IN MFD MAINTENANCE MODE SETUP PAGES TO MATCH AIRCRAFT WIRING.
2. ALL WIRE SHALL BE MIL-W-22759/16 (NON-SHIELDED) OR MIL-C-27500 (SHIELDED) OR EQUIVALENT UNLESS OTHERWISE NOTED.
3. ALL WIRE SHALL BE MINIMUM 24 AWG MIN UNLESS OTHERWISE NOTED.
4. TERMINATE SHIELDS TO THE CONNECTOR BACK SHELL OR CHASSIS GROUND AS CLOSE TO CONNECTOR AS POSSIBLE.
5. FOR ADDITIONAL ROUTING, BONDING, AND GROUNDING GUIDANCE REFER TO AC 43-13-1B, CHAPTER 11, SECTIONS 9, 10, 11, AND 15.
6. REFER TO EACH SENSOR'S INSTALLATION INSTRUCTIONS FOR SPECIFIC CONNECTION REQUIREMENTS.
7. SOME SENSOR INTERFACES ARE NOT AVAILABLE ON ALL SOFTWARE PART NUMBERS.
8. MFD RS-232 PORTS 3 AND 4 ARE ONLY AVAILABLE WITH S/N > 1200.
10. GPS/FMS INTERFACES MAY BE EITHER ARINC 429 OR RS-232. ARINC 429 IS THE PREFERRED GPS/FMS INTERFACE. USE RS-232 IF ARINC 429 IS UNAVAILABLE.
11. GPS/FMS SOURCE 2 MAY BE INTERFACED TO ANY OF THE ABOVE IDENTIFIED INTERFACES, IF AVAILABLE. IF A SECOND ARINC 429 PORT IS UNAVAILABLE, USE GPS2 232 INPUT PORT. REFER TO THE GPS/FMS CONFIGURATION SETUP GUIDE IN THIS MANUAL FOR SETUP INSTRUCTIONS.

AVIDYNE CORPORATION

EX5000 INSTALLATION WIRING:
DIAGRAM
GPS, FMS

Appendix K: Wiring Diagram – Lightning and Broadcast Datalink




NOTES:

1. PORT ASSIGNMENTS SHOWN ARE FOR EXAMPLE ONLY. SELECT PORTS IN MFD MAINTENANCE MODE SETUP PAGES TO MATCH AIRCRAFT WIRING.
2. ALL WIRE SHALL BE MIL-W-22759/16 (NON-SHIELDED) OR MIL-C-27500 (SHIELDED) OR EQUIVALENT UNLESS OTHERWISE NOTED.
3. ALL WIRE SHALL BE MINIMUM 24 AWG MIN UNLESS OTHERWISE NOTED.
4. TERMINATE SHIELDS TO THE CONNECTOR BACK SHELL OR CHASSIS GROUND AS CLOSE TO CONNECTOR AS POSSIBLE.
5. FOR ADDITIONAL ROUTING, BONDING, AND GROUNDING GUIDANCE REFER TO AC 43-13-1B, CHAPTER 11, SECTIONS 9, 10, 11, AND 15.
6. REFER TO EACH SENSOR'S INSTALLATION INSTRUCTIONS FOR SPECIFIC CONNECTION REQUIREMENTS.
7. SOME SENSOR INTERFACES ARE NOT AVAILABLE ON ALL SOFTWARE PART NUMBERS.
8. MFD RS-232 PORTS 3 AND 4 ARE ONLY AVAILABLE WITH S/N >1200.


AVIDYNE CORPORATION

EX5000 INSTALLATION WIRING:
LIGHTNING AND BROADCAST XM DATALINK


Appendix L: Wiring Diagram – Traffic Sensors



Appendix M: Wiring Diagram – TAWS



Appendix N: Wiring Diagram – Radar Sensor




NOTES:

1. PORT ASSIGNMENTS SHOWN ARE FOR EXAMPLE ONLY. SELECT PORTS IN MFD MAINTENANCE MODE SETUP PAGES TO MATCH AIRCRAFT WIRING.
2. ALL WIRE SHALL BE MIL-W-22759/16 (NON-SHIELDED) OR MIL-C-27500 (SHIELDED) OR EQUIVALENT UNLESS OTHERWISE NOTED.
3. ALL WIRE SHALL BE MINIMUM 24 AWG MIN UNLESS OTHERWISE NOTED.
4. TERMINATE SHIELDS TO THE CONNECTOR BACK SHELL OR CHASSIS GROUND AS CLOSE TO CONNECTOR AS POSSIBLE.
5. FOR ADDITIONAL ROUTING, BONDING, AND GROUNDING GUIDANCE REFER TO AC 43-13-1B, CHAPTER 11, SECTIONS 9, 10, 11, AND 15.
6. REFER TO EACH SENSOR'S INSTALLATION INSTRUCTIONS FOR SPECIFIC CONNECTION REQUIREMENTS, ON/OFF CONTROL AND CONFIGURATION FOR USE WITH AN ALTERNATE DISPLAYS.
7. SOME SENSOR INTERFACES ARE NOT AVAILABLE ON ALL SOFTWARE PART NUMBERS.
8. MFD RS-232 PORTS 3 AND 4 ARE ONLY AVAILABLE WITH S/N >1200.
9. MFD DISCRETE OUT 1 IS AN OPEN COLLECTOR OUTPUT. WHEN IN A HIGH IMPEDANCE STATE THE RADAR IS OFF. WHEN IN A LOW IMPEDANCE STATE THE MFD SUPPLIES A CURRENT PATH TO GROUND AND THE RADAR IS ON.

AVIDYNE CORPORATION

EX5000 INSTALLATION WIRING :
DIGITAL RADAR

Appendix O: Wiring Diagram – Engine Sensors




NOTES:

1. PORT ASSIGNMENTS SHOWN ARE FOR EXAMPLE ONLY. SELECT PORTS IN MFD MAINTENANCE MODE SETUP PAGES TO MATCH AIRCRAFT WIRING.
2. ALL WIRE SHALL BE MIL-W-22759/16 (NON-SHIELDED) OR MIL-C-27500 (SHIELDED) OR EQUIVALENT UNLESS OTHERWISE NOTED.
3. ALL WIRE SHALL BE MINIMUM 24 AWG MIN UNLESS OTHERWISE NOTED.
4. TERMINATE SHIELDS TO THE CONNECTOR BACK SHELL OR CHASSIS GROUND AS CLOSE TO CONNECTOR AS POSSIBLE.
5. FOR ADDITIONAL ROUTING, BONDING, AND GROUNDING GUIDANCE REFER TO AC 43-13-1B, CHAPTER 11, SECTIONS 9, 10, 11, AND 15.
6. REFER TO EACH SENSOR'S INSTALLATION INSTRUCTIONS FOR SPECIFIC CONNECTION REQUIREMENTS, ON/OFF CONTROL AND CONFIGURATION FOR USE WITH AN ALTERNATE DISPLAYS.
7. SOME SENSOR INTERFACES ARE NOT AVAILABLE ON ALL SOFTWARE PART NUMBERS.
8. MFD RS-232 PORTS 3 AND 4 ARE ONLY AVAILABLE WITH S/N >1200.

AVIDYNE CORPORATION

EX5000 INSTALLATION WIRING:
ENGINE SENSORS

Appendix P: Wiring Diagram – Primary Flight Display (PFD)





NOTES:


1. PORT ASSIGNMENTS SHOWN ARE FOR EXAMPLE ONLY. SELECT PORTS IN MFD MAINTENANCE MODE SETUP PAGES TO MATCH AIRCRAFT WIRING.
2. ALL WIRE SHALL BE MIL-W-22759/16 (NON-SHIELDED) OR MIL-C-27500 (SHIELDED) OR EQUIVALENT UNLESS OTHERWISE NOTED.
3. ALL WIRE SHALL BE MINIMUM 24 AWG MIN UNLESS OTHERWISE NOTED.
4. TERMINATE SHIELDS TO THE CONNECTOR BACK SHELL OR CHASSIS GROUND AS CLOSE TO CONNECTOR AS POSSIBLE.
5. FOR ADDITIONAL ROUTING, BONDING, AND GROUNDING GUIDANCE REFER TO AC 43-13-1B, CHAPTER 11, SECTIONS 9, 10, 11, AND 15.
6. CONFIGURATION FOR USE WITH AN ALTERNATE DISPLAYS.
7. SOME SENSOR INTERFACES ARE NOT AVAILABLE ON ALL SOFTWARE PART NUMBERS.
8. MFD RS-232 PORTS 3 AND 4 ARE ONLY AVAILABLE WITH S/N >1200.

AVIDYNE CORPORATION

EX5000 INSTALLATION WIRING:
PFD

Appendix Q: Wiring Diagram – FIS-B Weather and ADS-B Traffic






NOTES:

1. ALL WIRES TO BE 22 AWG OR GREATER UNLESS OTHERWISE NOTED.
2. AT EX5000 UNIT, TERMINATE SHIELD GROUNDS TO THE CONNECTOR BACKSHELL OR USE CARD-EDGE CONNECTOR TO TERMINATE SHIELD GROUNDS TO BACK PLATE.
3. WIRE HARNESS OVERBRAID IS NOT SHOWN BUT MAY BE REQUIRED.
4. REFER TO MANUFACTURER'S DOCUMENTATION TO VERIFY SYSTEM IS "INSTALLED IN ACCORDANCE WITH MANUFACTURERS APPROVED INSTALLATION DATA.
5. IF RS232 OR ARINC429 PORTS ARE UNAVAILABLE, USE ANY OTHER AVAILABLE PORT.
6. CONFIGURE THE GTX345 FOR "OPTIMIZED LEGACY ADS-B" AND THE EX5000 FOR CAPSTONE RADIO FOR WEATHER AT 115,200 BAUD.

Garmin GTX-345 Interconnect drawing



NOTES:

1. ALL WIRES TO BE 22 AWG OR GREATER UNLESS OTHERWISE NOTED.
2. WIRE HARNESS OVERBRAID IS NOT SHOWN BUT MAY BE REQUIRED
3. REFER TO THE INSTALLATION MANUAL OF THE ALTITUDE ENCODER FOR PINOUT AND FORMAT SETTINGS.
4. CONFIGURE NGT9000 RS-422 OUT BAUD TO 115,200.
5. CONFIGURE MFD RS-232 INPUT TO CAPSTONE RADIO.
6. CONFIGURE THE MFD ARINC 429 TO RECEIVE TAS SKYWATCH.
7. CONFIGURE NGT9000 ARINC 429 OUTPUT ONE TO CDTI AND ENABLE THE CTDI OUTPUT.
8. CONFIGURE NGT9000 TO ENABLE ADSB OUT AND ENABLE FIS-B Wx OUT.

L3 NGT-9000 Interconnect drawing

Appendix R: 3rd Party Avionics System Interconnect

Note: Sensor assignments shown are nominal assignments. You can select ports as required in Maintenance Mode Setup pages (for example. ARINC 429 RX1 is usually used for GPS1. However, if you wire a different sensor to pins 5 & 25, that sensor should be set up for port ARINC1 on the corresponding Setup Page, and GPS1 should use a different port selection.).

Table 29: P1 Pin Assignments

Pin	Pin Name	I/O
5	GPS1 (GPS A) ARINC 429 RX 1A	I
25	GPS1 (GPS A) ARINC 429 RX 1B	I
45	GPS2 (GPS B) ARINC 429 RX 2A	I
65	GPS2 (GPS B) ARINC 429 RX 2B	I
50	RS232 RX 3 (nominally WX-500)	I
49	RS232 TX 3 (nominally WX-500)	O
51	RS232 RTN 3	I
8	ARINC 429 RX 3A (nominally TRAFFIC)	I
28	ARINC 429 RX 3B (nominally TRAFFIC)	I
7	TRAFFIC Command Discrete	O
47	TRAFFIC Command Discrete	O
9	ARINC 429 TX 4A (nominally TAWS)	O
29	ARINC 429 TX 4B (nominally TAWS)	O
56	ARINC 453 RX 2A (nominally TAWS)	I
59	ARINC 453 RX 2B (nominally TAWS)	I
70	RS232 RX 4 (nominally Broadcast)	I
69	RS232 TX 4 (nominally Broadcast)	O
71	RS232 RTN 4 (nominally Broadcast)	I

Table 30: GPS ARINC429 Receive Messages (GAMA Communication Protocol)

Label	Message
310	PPOS LAT
311	PPOS LON
312	GS
313	TRK
147G	MAGVAR
074G	DATA RECORD HEADER
075G	ACTIVE WPT TO/FROM
113G	CHECKSUM
300G	STATION INFO
303	MSG INFO
304G	MSG CHARS 1-3
305G	MSG CHARS 4-6
306G	WPT LAT
307G	WPT LON
330	CONIC ARC INBOUND CRS
331	CONIC ARC RADIUS
332	CONIC ARC CRS CHANGE

125	UTC TIME
-----	----------

Table 31: Traffic ARINC 429 Messages (ARINC 735A communication protocol)

Label	Message
013	DITS Control
015	Altitude Select Limits
016	DITS Control
203	Own Aircraft Altitude
270	Vertical Resolution Advisory
274	TCAS SL, RI
320	Own Aircraft Heading
350	TCAS Faults Summary
357	Intruder Files
377	Equipment Identifier

Table 32: TAWS ARINC 429 Transmit Messages

Label	Message
011	Query Response
012	Key Press/Display Mode
271	Range Data

Copyright

This document is applicable to Software Part Number 530-00193-(), 530-00201-() AND 053-00235-().

Copyright © 2019 Avidyne Corporation. All rights reserved. All trademarks and trade names are the property of their respective owners. All materials are copyrighted including images that represent this software. This manual has been provided pursuant to an agreement containing restrictions on its use. This manual is also protected by United States and worldwide copyright laws. No part of this manual may be reproduced or distributed, transcribed, stored in a retrieval system, translated into any spoken or computer language or transmitted in any form or by any means whatsoever without the prior written consent of:

Avidyne Corporation Lincoln Office 4 Middlesex Green - Suite 221, 561 Virginia Road, Concord MA 01742

781-402-7400 www.avidyne.com

AVIDYNE EXCLUSIVE LIMITED WARRANTY and LIMITATIONS ON LIABILITY Avidyne war-

rants the Product manufactured by it against defects in material and workmanship for a period of twenty-four (24) months from delivery for new products and twelve (12) months for overhauled products. If Avidyne's Product fails to conform to this warranty, Avidyne, in its sole discretion, will either repair or replace the Product or provide a refund of the purchase price paid for the Product. This warranty is made upon the express conditions that: (a) Avidyne is given prompt written notice of any claimed non-conformity in the Product, with a reasonable explanation thereof; (b) The Product is returned to Avidyne or to an Avidyne authorized service facility; (c) The Product has not been altered in any manner other than as previously authorized by Avidyne in writing; and (d) Repairs to the Product have not been made by anyone other than Avidyne or an Avidyne authorized service facility. This warranty does not apply to any Product which is not installed, maintained and operated in accordance with Avidyne's written instructions or which is otherwise misused, including, without limitation, to any Product which is damaged due to improper installation, maintenance or operation, tampering, alteration of serial numbers or other manufacturers data, lightning or other electrical source, or otherwise. If warranty protection is applicable to the Product, Avidyne will use reasonable efforts to repair or replace Product within ten (10) business days of its receipt of the Product. Any Product that has been repaired by Avidyne or replaced by Avidyne under this warranty will be subject to remainder of the original warranty term applicable to the repaired or replaced Product or will be warranted under the warranty terms above for ninety days from the date of repair or replacement, whichever period is longer. **THIS EXCLUSIVE LIMITED WARRANTY APPLIES IN LIEU OF AND EXPRESSLY SUPERCEDES AND EXCLUDES ALL OTHER REPRESENTATIONS, AFFIRMATIONS AND/OR WARRANTIES, WHETHER EXPRESS OR IMPLIED, ORAL OR WRITTEN, INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY, OF FITNESS FOR A PARTICULAR PURPOSE, OF TITLE AND/OR OF NON-INFRINGEMENT. PURCHASER EXPRESSLY AND KNOWINGLY AGREES THAT NO OTHER REPRESENTATIONS, AFFIRMATIONS OR WARRANTIES, WHETHER EXPRESS OR IMPLIED, ORAL OR WRITTEN, FORM PART OF ANY PURCHASE AND SALE TRANSACTION RELATED TO THE PRODUCT. AVIDYNE'S (AND ITS AFFILIATES') AND ANY PRODUCT COMPONENT SUPPLIER'S SOLE RESPONSIBILITY AND LIABILITY RELATED TO THE PRODUCT OR ARISING OUT OF OR RELATED TO ITS PURCHASE, SALE, PERFORMANCE, RELIABILITY OR USE ARE LIMITED TO ITS REPAIR OR REPLACEMENT, OR TO A REFUND OF THE PURCHASE PRICE, IN AVIDYNE'S SOLE DISCRETION. IN NO EVENT WILL AVIDYNE (OR ITS AFFILIATES) OR ANY SUPPLIERS OF PRODUCT COMPONENTS BE RESPONSIBLE OR LIABLE FOR ANY OTHER DAMAGE OF ANY NATURE WHATSOEVER, INCLUDING DIRECT, INDIRECT, INCIDENTAL, CONSEQUENTIAL, SPECIAL, LOSS OF USE, LOSS OF REVENUE OR PROFIT, PROPERTY DAMAGE, PERSONAL INJURY, WRONGFUL DEATH, OR OTHER DAMAGE (WHETHER OR NOT AVIDYNE (OR ITS AFFILIATES) WERE NOTIFIED OF THE POSSIBILITY THAT ANY DAMAGE MIGHT BE INCURRED), ARISING OUT OF OR RELATED TO THE PRODUCT, ITS PURCHASE OR SALE, ITS PERFORMANCE OR RELIABILITY, OR THE USE OR INABILITY TO USE THE PRODUCT, FOR ANY REASON, INCLUDING DUE TO ANY PRODUCT DEFECT OR DEFECTS OR ANY ACTION OR INACTION OF ANY NATURE (INCLUDING CLAIMED OR ACTUAL NEGLIGENCE OR GROSS NEGLIGENCE) BY AVIDYNE OR ANY SUPPLIERS OF PRODUCT COMPONENTS. NEITHER THIS EXCLUSIVE LIMITED WARRANTY NOR AVIDYNE'S OR ANY PRODUCT COMPONENT SUPPLIER'S RESPONSIBILITY OR LIABILITY WILL IN ANY WAY BE ENLARGED OR OTHERWISE ALTERED DUE TO AVIDYNE'S PROVISION OF TECHNICAL SUPPORT OR TRAINING RELATED TO THE PRODUCT. WITHOUT LIMITING THE FOREGOING, NEITHER AVIDYNE (NOR ITS AFFILIATES) MAKE ANY REPRESENTATIONS, AFFIRMATIONS OR WARRANTIES REGARDING OR RELATED TO PRODUCTS NOT MANUFACTURED BY AVIDYNE OR REGARDING OR RELATED TO THE PERFORMANCE OR RELIABILITY OF ANY SUCH PRODUCT, EITHER ALONE OR WHEN USED WITH ANY PRODUCT MANUFACTURED BY AVIDYNE, OR THE SUITABILITY OF ANY SUCH PRODUCT FOR USE WITH ANY PRODUCT MANUFACTURED BY AVIDYNE. AVIDYNE (AND ITS AFFILIATES) EXPRESSLY DISCLAIM ANY AND ALL REPRESENTATIONS, AFFIRMATIONS AND/OR WARRANTIES REGARDING OR RELATED TO ANY SUCH PRODUCTS. IN NO EVENT WILL AVIDYNE (OR ITS AFFILIATES) BE RESPONSIBLE OR LIABLE FOR ANY DAMAGE OF ANY NATURE**

WHATSOEVER, INCLUDING DIRECT, INDIRECT, INCIDENTAL, CONSEQUENTIAL, SPECIAL, LOSS OF USE, LOSS OF REVENUE OR PROFIT, PROPERTY DAMAGE, PERSONAL INJURY, WRONGFUL DEATH, OR OTHER DAMAGE (WHETHER OR NOT AVIDYNE (OR ITS AFFILIATES) WERE NOTIFIED OF THE POSSIBILITY THAT ANY DAMAGE MIGHT BE INCURRED), ARISING OUT OF OR RELATED TO PRODUCTS NOT MANUFACTURED BY AVIDYNE, THE PURCHASE OR SALE OF SUCH PRODUCTS, THEIR PERFORMANCE OR RELIABILITY, EITHER ALONE OR WHEN USED WITH ANY PRODUCT MANUFACTURED BY AVIDYNE, OR THE SUITABILITY OF ANY SUCH PRODUCT FOR USE WITH ANY PRODUCT MANUFACTURED BY AVIDYNE. THIS EXCLUSIVE LIMITED WARRANTY ALSO APPLIES IN LIEU OF AND EXPRESSLY SUPERCEDES AND EXCLUDES ALL OTHER RIGHTS ANY PURCHASER HAS OR MAY HAVE RELATED TO THE PRODUCT AND/OR ARISING OUT OF OR RELATED TO ITS PURCHASE, SALE, PERFORMANCE, RELIABILITY OR USE, EITHER ALONE OR WITH ANY OTHER PRODUCT OR PRODUCTS, WHETHER IN CONTRACT, IN TORT (INCLUDING RIGHTS SOUNDING IN NEGLIGENCE, STRICT LIABILITY AND MISREPRESENTATION), UNDER STATUTE, AT LAW, IN EQUITY, OR OTHERWISE, AND PURCHASER EXPRESSLY AND KNOWINGLY WAIVES ALL SUCH RIGHTS TO THE FULLEST EXTENT PERMITTED BY LAW. PURCHASER ALSO EXPRESSLY AND KNOWINGLY AGREES THAT THE PRODUCT IS NOT A CONSUMER GOOD. THE FOREGOING PARAGRAPHS DEFINE AND LIMIT AVIDYNE'S SOLE RESPONSIBILITY AND LIABILITY AND PURCHASER'S SOLE AND EXCLUSIVE REMEDIES RELATED TO THE PRODUCT. Some jurisdictions may not allow the exclusion or limitation of warranties or liabilities, in which case the above limitations or exclusions, or some of them, may not apply in those jurisdictions.

Software License

Avidyne Corporation ("Avidyne") is willing to license this software, pilot's guide, and related materials (the "Software") only on the condition that you agree to all the terms of this agreement. Please read these terms carefully.

Trademarks

Avidyne and the Avidyne logo are trademarks of Avidyne Corporation. Other brands or products are the trademarks or registered trademarks of their respective holders and should be treated as such.

License and Certain Restrictions

You may use the Software on the EX500 on which it was delivered. You may not copy the Software for any purpose. You may not transfer the Software or any rights under this Agreement to another party without this Agreement. The other party must agree to accept the terms of this Agreement. The Software contains trade secrets. You may not decompile, reverse engineer, disassemble, or otherwise reduce the Software to human-readable form. You may not modify, adapt, translate, rent, sublicense, assign, lease, loan, resell for profit, distribute, or network the Software, disk or related materials or create derivative works based upon the software or any part thereof. Title, ownership rights, and intellectual property rights in and to the Software belongs to Avidyne and its licensors. The Software is protected by the copyright laws of the United States and by international copyright treaties. Title, ownership rights and intellectual property rights in and to the content accessed through the Software is the property of Avidyne, and where applicable, to the licensor content owners and may be protected by applicable copyright or other law. This Agreement gives you no rights to such content.

Note, the Software includes an internal capability to record certain of the operations and data generated by or provided to the EX5000, hereinafter referred to as "data files". These data files are an integral part of the Software as they assist Avidyne in testing and assessing the performance of the Software and the EX500. You agree in partial consideration for this license that such data files are the property of Avidyne and that you will neither tamper with nor destroy such data files. Further you agree to make such data files (or the EX5000) available to Avidyne at reasonable times and upon reasonable notice. Avidyne will endeavor to keep the information contained in the data files confidential, except to the extent required by reasonable exercise of its obligations to the FAA or other governmental agency or as a part of a court order. Avidyne makes no commitment to review or share the information contained within the data files with you, and you agree that you have no expectation that this information will be reviewed or shared.

Government Licensee

If you are acquiring the Software on behalf of any unit or agency of the United States Government, this provision applies. The Government acknowledges Avidyne's representation that the Software and its documentation were developed at private expense and no part of them is in the public domain. The Government acknowledges Avidyne's representation that the Software is "Restricted Computer Software" as that term is defined in Clause 52.227-19 of the Federal Acquisition Regulations (FAR) and is "Commercial Computer Software" as that term is defined in Subpart 227.401 of the Department of Defense Federal Acquisition Regulation Supplement (DFARS). The Government agrees that: If the Software is supplied to the Department of Defense (DoD), the Software is classified as "Commercial Computer Software" and the Government is acquiring only "restricted rights" in the Software and its documentation as that term is defined in Clause 52.227-7013(c)(1) of the DFARS, and If the Software is supplied to any unit or agency of the United States Government other than DoD, the Government's rights in the Software and its documentation will be as defined in Clause 52.227-19(c)(2) of the FAR.

Restricted Rights Legend

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 52.227-7013, and when applicable subparagraphs (a) through (d) of the Commercial Computer-Restricted rights clause at FAR 52.227-19, and in similar clauses in the NASA FAR Supplement. - Avidyne Corporation, 4 Middlesex Green - Suite 221, 561 Virginia Road Concord MA 01742.

Export Law Assurances

You acknowledge and agree that the Software is subject to restrictions and controls imposed by the United States Export Administration Act and Arms Export Control Act (the "Acts") and the regulations thereunder. You agree and certify that neither the Software nor any direct product thereof is being or will be acquired, shipped, transferred or exported, directly or indirectly, into any country prohibited by the Acts and the regulations thereunder or will be used for any purpose prohibited by the same.

Miscellaneous

This Agreement will be governed by the internal laws of the State of Massachusetts. If any provision of this Agreement is held to be unenforceable, that provision will be removed and the remaining provisions will remain in full force. This Agreement is the complete and exclusive statement of the agreement between us which supersedes any other communications between us in relation to the subject matter of this Agreement. This Software contains dated information. Use of the Software is based on your understanding that this Software may not include all the information or the most current information relevant to your particular situation. If you have any questions concerning this Agreement, you may contact Avidyne by writing to Avidyne Corporation, 4 Middlesex Green - Suite 221 561 Virginia Road, Concord MA 01742. You acknowledge that, in providing you with the Software, Avidyne and its licensors rely upon you to read this Agreement, understand it, and agree to be bound by its terms and not those contained in your purchase order. If you do not agree to the terms of this license, Avidyne is unwilling to license the product to you. In such event, you may not use or copy the product, and you should promptly contact Avidyne for instructions on return of the unused product(s) for a refund.

Copyright

© 2019 Avidyne Corporation. All rights reserved. Reproduction of this publication or any portion thereof by any means without the express written consent of Avidyne Corporation is prohibited. For further information contact Avidyne Corporation, 4 Middlesex Green - Suite 221, 561 Virginia Road, Concord MA 01742, 781-402-7400. Information in this document is subject to change without notice. Avidyne reserves the right to change or improve their products and to make changes in the content of this material without obligation to notify any person or organization of such changes or improvements.



AVIDYNE CORPORATION

4 Middlesex Green - Suite 221
561 Virginia Road
Concord MA 01742
Telephone: +1-781-402-7400
Toll Free: 800-AVIDYNE (800-284-3963)
FAX: 781-402-7599
www.avidyne.com
P/N 600-00073-001 Rev 02, June 07, 2019

©2019 Avidyne Corporation All Rights Reserved
Avidyne®, FlightMax® and CMax™ are trademarks of Avidyne Corp.