

Dell Pro 14 Plus PB14250 2-in-1 Touchscreen Touchpad Gestures

Touchpad Gestures (Windows 11)

- Tap / Double-Tap: Left-click or open an item
 - Two-Finger Tap: Right-click
 - Two-Finger Scroll: Scroll vertically or horizontally
 - Pinch / Zoom: Zoom in or out using two fingers
 - Three-Finger Swipe Up: Open Task View (all windows)
 - Three-Finger Swipe Down: Show desktop
 - Three-Finger Swipe Left / Right: Switch between recent apps
 - Four-Finger Swipe Left / Right: Switch virtual desktops
-

Common Windows 11 Touchscreen Gestures

- Tap: Select an item (equivalent to a left mouse click).
- Double-tap: Open an item.
- Press and hold: Right-click.
- Swipe (one finger): Scroll up or down.
- Flick: Move objects or scroll quickly.
- Swipe from right edge: Open the Notification Center.
- Swipe from left edge: Show Windows widgets.
- Pinch/Spread (two fingers): Zoom in or out.
- Swipe up (three fingers): Open Task View (all open windows).
- Swipe down (three fingers): Minimize all windows (show desktop).
- Swipe left/right (three fingers): Switch between recently opened apps.
- Swipe left/right (four fingers): Switch between virtual desktops.