

# Installation, Service and Operating Instructions

for use by heating contractor



**Vitocal 100-AW AM2V**

**Models 020028, 0340043 and 051078**


Outdoor Air to Water Heat Pump

Indoor Distribution and Control Unit

**Heating Capacity:** 20.5 to 58 MBH  
6 to 17 kW

**Cooling Capacity:** 1.4 to 4.3 Ton  
5 to 15 kW

## VITOCAL 100-AW



*Product may not be exactly as shown*

### IMPORTANT

**Read and save these instructions  
for future reference.**

## About these Instructions



Take note of all symbols and notations intended to draw attention to potential hazards or important product information. These include "WARNING", "CAUTION", and "IMPORTANT". See below.



### WARNING

Indicates an imminently hazardous situation which, if not avoided, could result in death, serious injury or substantial product/property damage.

► Warnings draw your attention to the presence of potential hazards or important product information.



### CAUTION

Indicates an imminently hazardous situation which, if not avoided, may result in minor injury or product/property damage.

► Cautions draw your attention to the presence of potential hazards or important product information.

### IMPORTANT



► Helpful hints for installation, operation or maintenance which pertain to the product.

► This symbol indicates that additional, pertinent information is to be found.

► This symbol indicates that This symbol indicates that other instructions must be referenced.

## Safety, Installation and Warranty Requirements

Please ensure that these instructions are read and understood before commencing installation. Failure to comply with the instructions listed below and details printed in this manual can cause product/property damage, severe personal injury, and/or loss of life. Ensure all requirements below are understood and fulfilled (including detailed information found in manual subsections).

### ■ Product documentation

Read all applicable documentation before commencing installation. Store documentation near heat pump in a readily accessible location for reference in the future by service personnel.




► *For a listing of applicable literature, please see section entitled "Important Regulatory and Safety Requirements".*

### ■ Advice to owner

Once the installation work is complete, the heating contractor must familiarize the system operator/ultimate owner with all equipment, as well as safety precautions/requirements, shutdown procedure, and the need for professional service annually before the heating season begins.

### ■ Licensed professional heating contractor

The installation, adjustment, service and maintenance of this equipment must be performed by a licensed professional heating contractor.



► *Please see section entitled "Important Regulatory and Installation Requirements".*

### ■ Warranty



Information contained in this and related product documentation must be read and followed. Failure to do so renders the warranty null and void.

## Safety, Installation and Warranty Requirements

### Fiberglass wool and ceramic fiber materials



#### WARNING

**Inhaling of fiberglass wool and/or ceramic fiber materials is a possible cancer hazard. These materials can also cause respiratory, skin and eye irritation.**

The state of California has listed the airborne fibers of these materials as a possible cancer hazard through inhalation. When handling these materials, special care must be applied.

#### Suppliers of ceramic fiber products recommend the following first aid measures:

- Respiratory tract (nose and throat) irritation: If respiratory tract irritation develops, move the person to a dust free location.
- Eye irritation: If eyes become irritated, flush immediately with large amounts of lukewarm water for at least 15 minutes. Eyelids should be held away from the eyeball to ensure thorough rinsing. Do not rub eyes.
- Skin irritation: If skin becomes irritated, remove soiled clothing. Do not rub or scratch exposed skin. Wash area of contact thoroughly with soap and cold water (as warm or hot water may worsen the irritation). Using a skin cream or lotion after washing may be helpful.
- Gastrointestinal irritation: If gastrointestinal tract irritation develops, move the person to a dust free environment.

**Suppliers of fiberglass wool products recommend the following precautions be taken when handling these materials:**

- Avoid breathing fiberglass dust and contact with skin and eyes.
- Use NIOSH approved dust/mist respirator.
- Wear long-sleeved, loose fitting clothing, gloves and eye protection.
- Wash work clothes separately from other clothing. Rinse washer thoroughly.
- Operations such as sawing, blowing, tear-out and spraying may generate airborne fiber concentration requiring additional protection.

#### First aid measures

- If eye contact occurs, flush eyes with water to remove dust. If symptoms persist, seek medical attention.
- If skin contact occurs, wash affected areas gently with soap and warm water after handling.

#### Operating and Service Documentation

It is recommended that all product documentation such as parts lists, operating and service instructions be handed over to the system user for storage. Documentation is to be stored near the heat pump in a readily accessible location for reference by service personnel.



## Safety, Installation and Warranty Requirements

The outdoor unit contains flammable refrigerant R32. If there is a leak, the escaping refrigerant may form a flammable or explosive atmosphere in the ambient air.



### WARNING

Risk of explosion: Escaping refrigerant may form a flammable or explosive atmosphere in the ambient air.

Take the following measures to prevent fire and explosion:

- Keep ignition sources away, e.g. naked flames, hot surfaces, electrical devices not free of ignition sources, mobile devices with integrated batteries (e.g. mobile phones, fitness watches, etc.).
- Permissible tools: All tools for working must be designed and explosion protected in accordance with the applicable standards and regulations for refrigerant in safety groups A2L and A3, e.g. brushless machines (cordless screwdrivers), extraction equipment, disposal containers, installation aids, vacuum pumps, conductive hoses, mechanical tools of non-sparking material, etc.

#### Note:

The tools must also be suitable for the pressure ranges in use. Tools must be in good working order.

- Do not use flammable materials, e.g. sprays or other flammable gases.
- Discharge static: Before beginning work, touch earthed objects, such as heating or water pipes.
- Do not remove, block or bridge safety equipment.
- Do not make any changes: Do not modify the outdoor unit, inlet/outlet lines, electrical connections/cables or the surroundings. Do not remove any components or seals.

#### Working on the system

- Switch off the power supply to the indoor unit and outdoor unit, e.g. at a breaker. Check that the system is no longer live.

#### Note:

In addition to the control circuit there may be several power circuits.



### WARNING

Contact with live components can result in severe injuries. Some components on PCB's remain live even after the power supply has been switched off. Prior to removing covers from the appliances, wait at least 4 minutes until the voltage has completely dropped out.



### WARNING

- Safeguard the system against reconnection.
- Wear suitable personal protective equipment when carrying out any work.



### WARNING

Hot surfaces and fluids can result in burns or scalding. Cold surfaces may cause frostbite.

- Prior to servicing or maintenance tasks, switch off and allow the equipment to cool down or warm up.
- Do not touch hot or cold surfaces on the appliance, fittings or pipework.

#### Note:

Electronic assemblies can be damaged by electrostatic discharge. Before beginning work, touch earthed objects, such as heating or water pipes, to discharge any static. R32 refrigerant is an air displacing, colorless, flammable gas which forms explosive mixtures with air. Refrigerant drained must be properly disposed of by authorised contractors. Perform the following measures before beginning work on the refrigerant circuit:

- Check the refrigerant circuit for leaks.
- Ensure very good ventilation especially in the floor area and sustain this for the duration of the work.
- Secure the area surrounding the work area.
- Inform the following persons of the type of work to be carried out:
  - All maintenance personnel
  - All persons in the vicinity of the system.
- Inspect the area immediately around the heat pump for flammable materials and ignition sources: Remove all flammable, movable materials and any ignition sources from the safety zone.
- Before, during and after the work, check the surrounding area for escaping refrigerant using an explosion-proof refrigerant detector suitable for R32. This refrigerant detector must not generate any sparks and must be suitably sealed.
- A CO<sub>2</sub> or powder extinguisher must be to hand in the following cases:
  - Refrigerant is being drained.
  - Refrigerant is being topped up.
  - Soldering or welding work is being carried out.
- Display signs prohibiting smoking.

## Safety, Installation and Warranty Requirements

### WARNING

Escaping refrigerant can lead to fire and explosions that result in very serious injuries or death.

- Do not drill or apply heat to a refrigerant circuit filled with refrigerant.
- Do not operate Schrader valves unless a fill valve or extraction equipment is attached.
- Take measures to prevent electrostatic charge.
- No smoking! Prevent naked flames and sparks. Never switch lights or electrical appliances on or off.
- Components that contain or contained refrigerant must be labelled, and stored and transported in well ventilated areas in accordance with the applicable regulations and standards.

### WARNING

Direct contact with liquid and gaseous refrigerant can cause serious damage to health, e.g. frostbite and/or burns. There is a risk of asphyxiation if it is breathed in.

- Prevent direct contact with liquid and gaseous refrigerant.
- Wear personal protective equipment when handling liquid and gaseous refrigerant.
- Never breathe in refrigerant vapors.

### WARNING

Refrigerant is under pressure:  
Mechanical loading of lines and components can cause leaks in the refrigerant circuit. Do not apply loads to the lines and components, e.g. by supporting or placing tools.

### WARNING

Hot and cold metallic surfaces of the refrigerant circuit may cause burns or frostbite if skin contact is made. Wear personal protective equipment to protect against burns or frostbite.

#### Note:

When refrigerant is being removed, hydronic components may freeze. Drain heating water from the heat pump beforehand.

### WARNING

Damage to the refrigerant circuit can cause refrigerant to enter the hydronic system. After completion of the work, vent the hydronic system correctly. When doing so, ensure the area is sufficiently ventilated.

#### Note:

Freezing can cause damage to the heat pump.

- Thermally insulate all the hydronic lines.
- In order to activate the frost protection function, electrically connect the heat pump before filling the secondary circuit. Switch on the power supply. Switch on the ON/OFF switch on the indoor unit.

### WARNING

With short electrical cables, should there be leakage in the refrigerant circuit, gaseous refrigerant may reach the inside of the building. Min. length of the electrical connecting cables between the indoor and the outdoor unit: 3 m

#### Note:

Repairing components that fulfil a safety function can compromise the safe operation of the system.

- Replace faulty components only with genuine Viessmann spare parts.
- Do not undertake any repairs on the inverter. Replace the inverter if there is a defect.

#### Note:

Spare and wearing parts that have not been tested together with the system can compromise its function. Installing non-authorised components and making non-approved modifications or conversions can compromise safety and may invalidate our warranty. For replacements, use only original spare parts supplied or approved by Viessmann.

## Safety, Installation and Warranty Requirements



### WARNING

Escaping refrigerant can lead to fire and explosions that result in very serious injuries or death.

- Ensure very good ventilation especially in the floor area of the outdoor unit.
- No smoking! Prevent naked flames and sparks. Never switch lights or electrical appliances on or off.
- Evacuate any people from the danger zone.
- From a safe position, switch off the electricity supply for all system components.
- Remove ignition sources
- Let the system user know that no ignition source may be brought into area for the duration of the repair.
- Repair work must be carried out by an authorised contractor.
- Only recommission the system after it has been repaired.



### WARNING

Direct contact with liquid and gaseous refrigerant can cause serious damage to health, e.g. frostbite and/or burns. Prevent direct contact with liquid and gaseous refrigerant.



### WARNING

Breathing in refrigerant may cause suffocation. Never breathe in refrigerant vapors.



### WARNING

If water escapes from the appliance there is a risk of electric shock. Switch off the heating system at the external isolator (e.g. fuse box, domestic distribution board).



### WARNING

If water escapes from the appliance, there is a risk of scalding. Never touch hot heating water.

### Note:

A build-up of ice in the condensate pan and in the fan area of the outdoor unit can cause damage to the equipment.

Please note the following:

- Do not use mechanical items/aids for the removal of ice.
- Before using electrical heating appliances, check the refrigerant circuit for leaks with a suitable measuring device.
- The heating appliance should not be a source of ignition.
- If ice regularly builds up on the outdoor unit (e.g. in areas where frost and heavy fog occur frequently), install fan ring heating (accessories) that is suitable for refrigerant R32 and/or an electric ribbon heater in the condensate pan (accessories or factory-fitted).
- The outdoor unit is charged at the factory with refrigerant R32.



### WARNING

Escaping refrigerant can lead to fire and explosions that result in very serious injuries or death. There is a risk of asphyxiation if it is breathed in.

Store the outdoor unit in the following conditions:

- An explosion prevention plan must be in place for storage.
- Ensure there is sufficient ventilation at the storage location.
- Temperature range for storage: -13°F to 158°F (-25°C to 70°C)
- Only store the outdoor unit in its factory protective packaging.
- Protect the outdoor unit against damage.
- The maximum number of outdoor units that may be stored in one place is determined by local conditions.

## Safety, Installation and Warranty Requirements

### Qualification of workers

Every working procedure like maintenance, service and repair operations that affects safety means shall only be carried out by competent persons.

Examples for such working procedures are:

- Breaking into the refrigerating circuit;
- Opening of sealed components;
- Opening of ventilated enclosures.

### Checks to the area

Prior to beginning work on systems containing FLAMMABLE REFRIGERANTS, safety checks are necessary to ensure that the risk of ignition is minimized.

### Work procedure

Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapor being present while the work is being performed.

### General work area

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.

### Checking for presence of refrigerant

The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i. e. non-sparking, adequately sealed or intrinsically safe.

### Presence of fire extinguisher

If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO<sub>2</sub> fire extinguisher adjacent to the charging area

### No ignition sources

No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.

### Ventilated area

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

## Safety, Installation and Warranty Requirements

### Checks to the refrigerating equipment

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.

The following checks shall be applied to installations using FLAMMABLE REFRIGERANTS:

- The actual REFRIGERANT CHARGE is in accordance with the room size within which the refrigerant containing parts are installed;
- The ventilation machinery and outlets are operating adequately and are not obstructed;
- If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant
- Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
- Refrigerating pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

### Checks to electrical devices

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised. Initial safety checks shall include:

- That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- That no live electrical components and wiring are exposed while charging, recovering or purging the system;
- That there is continuity of earth bonding.

### Repairs to sealed components

Sealed electrical components shall be replaced.

### Repair to intrinsically safe components

Intrinsically safe components must be replaced.

### Cabling

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

### Detection of flammable refrigerants

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

The following leak detection methods are deemed acceptable for all refrigerant systems.

Electronic leak detectors may be used to detect refrigerant leaks but, in the case of FLAMMABLE REFRIGERANTS, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed.

Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

If a leak is suspected, all naked flames shall be removed/extinguished.

If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. Removal of refrigerant shall be according to Removal and evacuation.

## Safety, Installation and Warranty Requirements

### Removal and evacuation

When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed, since flammability is a consideration. The following procedure shall be adhered to:

- Safely remove refrigerant following local and national regulations;
- Evacuate;
- Purge the circuit with inert gas (optional for A2L);
- Evacuate (optional for A2L);
- Continuously flush or purge with inert gas when using flame to open circuit; and
- Open the circuit.

The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems.

For appliances containing flammable refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum (optional for A2L). This process shall be repeated until no refrigerant is within the system (optional for A2L). When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.

The outlet for the vacuum pump shall not be close to any potential ignition sources, and ventilation shall be available.

### Charging procedures

In addition to conventional charging procedures, the following requirements shall be followed.

- Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in them.
- Cylinders shall be kept in an appropriate position according to the instructions.
- Ensure that the REFRIGERATING SYSTEM is earthed prior to charging the system with refrigerant
- Label the system when charging is complete (if not already).
- Extreme care shall be taken not to overfill the REFRIGERATING SYSTEM.

Prior to recharging the system, it shall be pressure-tested with the appropriate purging gas. The system shall be leak-tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.



## Safety, Installation and Warranty Requirements

### Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.

- a) Become familiar with the equipment and its operation.
- b) Isolate system electrically.
- c) Before attempting the procedure, ensure that:
  - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
  - all personal protective equipment is available and being used correctly;
  - the recovery process is supervised at all times by a competent person; recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with instructions.
- h) Do not overfill cylinders (no more than 80 % volume liquid charge).
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another REFRIGERATING SYSTEM unless it has been cleaned and checked

### Labelling

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing FLAMMABLE REFRIGERANTS, ensure that there are labels on the equipment stating the equipment contains FLAMMABLE REFRIGERANT.

### Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i. e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of the flammable refrigerant. If in doubt, the manufacturer should be consulted. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition.

The recovered refrigerant shall be processed according to local legislation in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The compressor body shall not be heated by an open flame or other ignition sources to accelerate this process. When oil is drained from a system, it shall be carried out safely.

## Index

### Safety

About these Instructions .....	2
Safety, Installation and Warranty Requirements .....	3

### Table of Contents

Index .....	12
-------------	----

### General Information

Important Regulatory and Installation Requirements .....	14
Mechanical Room .....	14
Applicability .....	15
Product Information .....	16
Intended Use .....	18
System Examples .....	18
Fittings and Sealing Points .....	18
Prior to Installation .....	18

### Indoor Unit Installation

Dimensions .....	19
Recommended Minimum Service Clearances .....	20
Mounting the Indoor Unit .....	20
Accessing the Indoor Unit .....	21
Piping Connections .....	22
Domestic Hot Water .....	23
Safety Valve .....	24
Installation Fittings .....	25
Electrical Connections .....	26
Power Supply Indoor Unit .....	29

### Outdoor Unit Installation

Dimensions .....	30
Recommended Minimum Service Clearances .....	32
Outdoor Unit Sound Pressure .....	34
Prior to Installation .....	35
Mounting on a Concrete Pad .....	36

### Condensate Drain Fittings

Mounting using a Mounting Curb .....	37
Mounting on Stand .....	38
Safety Valve .....	39
Piping Connections .....	40
Accessing the Outdoor Unit .....	41
Power Supply Outdoor Unit .....	42
Communication .....	43

### Installation Examples

Installation Examples .....	44
System Example 1 .....	45
System Example 2 .....	46

### Operating

User Interface .....	47
Display Symbols and Indications .....	48
Initial Start-up .....	49
Diagnostics Menu .....	49
Settings Menu .....	49
Setting the Room Temperature .....	50
Setting the DHW Temperature .....	50



**Index**

	Setting a Time Schedule .....	51
	DHW Tank Hygiene Function .....	54
	Setting Time and Date .....	55
	Adjusting the Interface .....	55
	Setting the Language.....	56
	System Information .....	56
	Time Schedule Override .....	57
	Service/Configuration Menu.....	58
	Adjusting the Heating Curve .....	63
Service		
	Troubleshooting .....	65
	Fault Codes Indoor Unit .....	67
	Fault Codes Outdoor Unit.....	67
	Preparing for Service .....	70
	Check Sensors.....	70
	Checking Fuses.....	71
	Maintenance.....	72
Wiring		
	Indoor Unit Wiring Diagram .....	76
	Outdoor Unit Wiring Diagram .....	78
Parts		
	Parts List .....	81
Technical Data		
	Indoor Unit Technical Data .....	92
	Outdoor Unit Technical Data.....	93
Water Quality		
	Filling the System .....	94

## Important Regulatory and Installation Requirements

### Codes

In Canada all electrical wiring is to be done in accordance with the latest edition of CSA C22.1 Part 1 and/or local codes. In the U.S., use the National Electrical Code ANSI/NFPA 70.

### Instructing the system user

The installer of the system is responsible to ensure the system operator/ultimate owner is made familiar with the system functioning, its activation, and its shut-down.

### Initial start-up

Initial start-up must be performed by a qualified heating contractor. Proper completion of the Maintenance Record by the heating contractor is also required.

### Working on the equipment

The installation, adjustment, service, and maintenance of this heat pump must be done by a licensed professional heating contractor who is qualified and experienced in the installation, service, and maintenance of heat pumps. There are no user serviceable parts on the heat pump. Ensure main power supply to equipment, the heating system, and all external controls has been deactivated. Take precautions in all instances to avoid accidental activation of power during service work.

### Technical literature

Leave all literature at the installation site and advise the system operator/ultimate owner where the literature can be found. Contact Viessmann for additional copies.

This product comes with several safety instruction labels attached. Do not remove! Contact Viessmann immediately if replacement labels are required.

### Literature for the Vitocal 100-AW AM2V Series:

- Technical Data Manual
- Installation, Service and Operating Instructions
- Instructions of other products utilized and installed
- Installation codes mentioned in this manual and as locally applicable

The completeness and functionality of field supplied electrical controls and components must be verified by the heating contractor. These include flow switches (if used), staging controls, pumps, motorized valves, air vents, thermostats, etc.

Leave all literature at the installation site and advise the system operator/ultimate owner where the literature can be found. Contact Viessmann for additional copies. This product comes with several safety instruction labels attached.

### Do not remove!

Contact Viessmann immediately if replacement labels are required.

## Mechanical Room

During the early stages of designing a new home, we recommend that proper consideration be given to constructing a separate mechanical room dedicated to the heat pump equipment and domestic hot water storage tank(s).

The indoor unit must be located in a heated indoor area, near a floor drain. Whenever possible, install the unit near an outside wall so that it is easy to connect the indoor unit to the outdoor unit. Locate the indoor unit on a wall capable of supporting 100 lb. (45 kg) [the weight of the indoor unit].

The maximum room temperature of the mechanical room where the indoor unit is located must not exceed 95°F (35°C).

## Applicability

### CAUTION

The serial number must be provided when ordering replacement parts. Some replacement parts are not reverse compatible with previous versions of the Vitocal 100-AW AM2V.

### IMPORTANT

When ordering replacement parts, provide the 16-digit serial number which is found on either the indoor unit rating plate or outdoor unit rating plate.

Indoor Unit:

Model No.	Serial No.
AM2V 020028	7228973 <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>
AM2V 034043	7228974 <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>
AM2V 051078	7228975 <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>

Outdoor Unit:


Model No.	Serial No.
AM2V 020028	7986309 <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>
AM2V 034043	7986310 <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>
AM2V 051078	7986311 <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>

### Certifications

Outdoor Unit



Intertek



Product may not be exactly as shown

- 1** Integrated resistive heating element
- 2** Integrated Space Heating/DHW Production diverting valve
- 3** Integrated system pump
- 4** Integrated system expansion tank
- 5** Monochrome digital interface



Product may not be exactly as shown

- 1** Coil
- 2** Fan
- 3** Compressor
- 4** Brazed plate heat exchanger

## Product Information

The Vitocal 100-AW AM2V heat pump is designed for heating/cooling of a building and heating domestic hot water. The unit consists of two modules:

### Outdoor Unit

The working principle of the unit is to capture heat from the environment and to transfer it to the heating circuit in the building. The low-temperature heat of the air is transferred through an evaporator to the heat pump system filled with a refrigerant, which turns into a gas as it evaporates. From the evaporator, the gas is drawn in by the compressor, which raises its temperature during its compression and directs it to the condenser. In the condenser, heat is transferred to the water, which fills the central heating system, and the cooled liquid flows through the expansion valve and returns to the evaporator, after which the whole process starts again. In the case of cooling, this cycle is reversed and the heat is extracted from the building and discharged outside.

### Refrigeration circuit

All the components of the refrigeration circuit are located in the outdoor module, including the refrigeration circuit controller with an electronic expansion valve. Depending on the operating conditions, the compressor power is adjusted by means of an inverter. When the space cooling function is activated, the refrigeration circuit is reversed.

### Plumbing system

The indoor and outdoor modules are connected to each other via heating medium hydronic lines. A high-efficiency circulation pump (secondary pump) built into the indoor module supplies the heating medium to the secondary circuit. A central 3-way diverter valve: "space heating/DHW heating" is responsible for switching between space heating and DHW heating.

### Heat pump controller

The entire heating system is monitored and controlled by the heat pump controller. The heat pump controller is integrated into the indoor module. Communication between the indoor and outdoor modules takes place via a communication bus.

### Indoor Unit

The working principle of the unit is based on the demand-dependent capacity control of the heat pump compressor with an activation of the electrical auxiliary heater via the controller of the indoor module. The indoor module controller regulates the heating output according to a pre-set heating curve. If the heat pump is not able to cover the building's heating demand on its own, the controller automatically activates the electrical auxiliary heater which, together with the heat pump produces the desired heating medium temperature.

### Outdoor temperature ranges for air-to-water heat pumps

Air-to-water heat pumps use the outdoor air as the heat source. Operation is only efficient within certain outdoor temperature ranges, e.g. between -13°F and 113°F (-25°C and +43°C). If the upper temperature limit is exceeded or the lower temperature limit has been reached, heat pumps switch off periodically. A corresponding notification appears on the heat pump controller. To cover the heat demand for space heating and DHW heating beyond the temperature limits, the heat pump controller automatically switches on the available auxiliary heating equipment, e.g. electric auxiliary heating, if necessary.

### Required equipment

A communication bus cable between the outdoor unit and the indoor unit.

Recommended: LiYY 2 X 22 AWG (0.34mm<sup>2</sup>)

Maximum: LiYY 2 X 18 AWG (1.5mm<sup>2</sup>)

### Installation with heating/cooling buffer storage tank


#### ■ Space heating

The heat pump may heat up to 2 heating/cooling circuits: 1 heating/cooling circuit without a mixing valve and 1 heating/cooling circuit with a mixing valve.

#### ■ Space cooling

The heat pump may cool via up to 2 heating/cooling circuits.

## Product Information



Ⓐ Rating plate for indoor unit registration

Wall mounted indoor unit in combination with air to water outdoor unit heat pump, with the following integrated components:

- Heating or cooling operation
- Hydronics with 3-way diverter valve and variable speed high efficiency circulation pump
- Weather-compensated or constant temperature control unit
- DHW production

Heat pump model must be selected based on an accurate heat loss calculation of the building. Ensure heat pump model is compatible with connected heating/cooling loads.

The rating plate of the Vitocal 100 AW contains extensive product information and is heat pump-specific. Access code with the marking "i" for direct access to product-specific information and product registration on the internet. The access code contains the credentials for the registration and product information portal, as well as the 16-digit serial number.

## Intended Use

The Vitocal 100 is only intended to be installed and operated in sealed unvented heating systems with due attention paid to the associated installation, service and operating instructions. The heat pump is only designed for:

- Space Heating
- Space Cooling
- DHW Heating

Commercial or industrial use for a purpose other than the heating of heating water shall be deemed inappropriate.

Intended use presupposes that a permanent installation in conjunction with permissible components designed for this purpose has been carried out. All other use is deemed inappropriate. Any resulting losses are excluded from the manufacturer's liability. Any usage beyond this must be approved by the manufacturer in each individual case. Intended use also includes adherence to maintenance and inspection intervals.

## System Examples

System examples with hydronic and electrical connection schemes and function descriptions are available to help setting up the heating system, refer to "Installation Examples" on page 44.

## Fittings and Sealing Points

All connections must be fitted with new gaskets/seals after opening or loosening.



### WARNING

Risk of electric shock from escaping heating water or DHW. When commissioning and after carrying out maintenance work, check all water side connections for leaks.

## Prior to Installation


Before placing Vitocal 100 AW in its installation location, ensure all necessary accessories are installed.



### CAUTION

The indoor unit must be installed in such a way that the system components are protected from water (spraying, splashing, etc.) during operation and service.

## Dimensions




### Dimensions in. (mm)

A	16- <sup>1</sup> / <sub>4</sub> (416)	F	5- <sup>1</sup> / <sub>2</sub> (138)
B	28- <sup>1</sup> / <sub>2</sub> (723)	G	2 (48)
C	12- <sup>3</sup> / <sub>4</sub> (323)	H	11- <sup>1</sup> / <sub>4</sub> (283)
D	28- <sup>1</sup> / <sub>4</sub> (717)	I	7- <sup>1</sup> / <sub>2</sub> (190)
E	11- <sup>1</sup> / <sub>4</sub> (285)	J	2- <sup>1</sup> / <sub>4</sub> (55)

### Legend

- (A) <sup>3</sup>/<sub>4</sub> in. Electrical Knockouts (2 per side)
- (B) <sup>1</sup>/<sub>2</sub> in. Electrical Knockouts (8 per side)
- (C) Return to Heat Pump (1-<sup>1</sup>/<sub>4</sub> in. NPT)
- (D) Supply to Space Heating (1-<sup>1</sup>/<sub>4</sub> in. NPT)
- (E) DHW/Space Heating Return (1-<sup>1</sup>/<sub>4</sub> in. NPT)
- (F) Supply from Heat Pump (1-<sup>1</sup>/<sub>4</sub> in. NPT)
- (G) DHW Tank Heating Supply (1-<sup>1</sup>/<sub>4</sub> in. NPT)

## Recommended Minimum Service Clearances



### Recommended minimum service clearances

For typical installation, it is recommended to install the indoor unit with the clearances shown in the illustration.

A - 12 in. (300 mm)

B - 20 in. (500 mm)

Front Clearance 39 in. (1000 mm)

These dimensions reflect the recommended service clearance for the indoor unit only, ensure adequate clearance is left for the installation of piping and electrical connections.


### Minimum Clearances to Combustibles

Top	Front	Rear	Left	Right
0	0 AL, CL	0	0	0

AL = Alcove

CL = Closet

## Mounting the Indoor Unit



The indoor unit can be wall-mounted on a concrete wall. Note: The enclosed screws and rawl plugs are only suitable for concrete. For other construction materials, use bolts and anchors that are suitable for 100 lb. (46 kg) loads.

### Installation of mounting bracket on brick/concrete wall:

1. Mark out the rawl plug holes.
2. Drill holes  $\phi \frac{3}{8}$  in. ( $\phi 10$  mm) and insert the rawl plugs supplied.
3. Fit the wall mounting bracket with the screws supplied.
4. Mount the indoor unit on the wall mounting bracket. Ensure that both tabs have locked into the indoor unit.

**Note:** Check the condition of the wall where the indoor unit is to be installed. For the suitability of the supplied rawl plugs for various building materials, see the manufacturer's instructions. For other construction materials, use fixing materials with sufficient load bearing capacity.

### CAUTION

Whichever mounting method is used, ensure that the bracket is tightly and securely fastened to wall. Failure to secure indoor unit properly could cause indoor unit to loosen, posing a severe safety hazard.




## Accessing the Indoor Unit

### Accessing the Indoor Unit for Installation

1. Remove the two door retaining screws.
2. Swing the door open to the right.


**Note:** If required the mid jacketing panel can be removed to offer addition clearance for installation, refer to "Preparing for Service" on page 70 for instructions on removing the mid panel.




## Piping Connections

2 imperfect threads

Use moderate  
amount of dope



Leave 2 threads bare



### Legend

- Ⓐ DHW tank heating return
- Ⓑ Heating system return
- Ⓒ Supply from the heat pump outdoor unit
- Ⓓ Return to the heat pump outdoor unit
- Ⓔ Heating system supply
- Ⓕ DHW tank heating supply

**Note:** All fittings shown are field supplied

**Note:** Install temperature gauge (field supplied) anywhere in the supply piping near the indoor unit (not shown).

### Proper piping practice

Support piping by proper suspension method. Piping must not rest on or be supported by indoor unit.

### Connections on the heating water and DHW sides

If the connections have not been fitted previously, make the connections on the heating water and DHW sides.

**Note:** If no tank is connected, close off the DHW tank supply connection with a cap.

### Heating water connections

1. Thoroughly flush heating system (particularly before connecting the heat pump to an existing system).
2. Connect indoor unit to the heating system.

**Note:** Use an approved pipe sealant or Teflon tape when connecting the installation fittings.

Maximum allowable working pressure (MAWP):  
30 psig (2 bar)



### WARNING

Exposing the Vitocal to pressures and temperatures in excess of those listed will result in damages, and will render warranty null and void.

- Use a two-hand wrench method when tightening fittings or piping onto the indoor unit connectors. Use one wrench to prevent the indoor unit pipes from twisting and the second wrench to tighten the fitting or piping. Failure to support the indoor unit connection could damage the heat pump and its internal piping.

- All plumbing must meet or exceed all local state and national plumbing codes.

**SUPPORT ALL PIPING USING HANGERS. DO NOT support piping by the indoor unit or its components.**


- Use isolation valves to isolate system components.

### General

A distance of 2 in. (50 mm) from uninsulated hot water pipes to combustible components must be maintained.

If the pipes are provided with a suitable pipe insulation of sufficient thickness and insulation, the distance mentioned above is not necessary (see also local regulations).

## Domestic Hot Water




The Vitocal-AW AM2V series can be used in conjunction with the stand-alone indirect DHW storage tanks offered by Viessmann.

For the connection of a stand-alone indirect DHW tank, installation fittings (field supplied), and a DHW temperature sensor (supplied with heat pump) is required.

Size and select the indirect DHW storage tank based on the forecasted indirect DHW consumption of the building in question.

For further technical information on indirect DHW storage tanks, see the Vitocell Technical Data Manuals.

If no domestic hot water tank is being connected to the indoor unit, the domestic hot water tank port needs to be capped. In addition to capping the DHW tank port the indoor unit must be configured for operation without domestic hot water tank, refer to "DHW Tank:" on page 60 to adjust the setting in the "Service/Configuration Menu".



### DHW storage tank information

The DHW temperature sensor is required when using a stand-alone DHW storage tank with the heat pump. The heat pump is supplied with a DHW temperature sensor (all other fittings are field supplied).

### Making the DHW connections

1. With a Vitocell tanks, locate the DHW temperature sensor well and install the DHW temperature sensor using the installation instructions provided with the DHW storage tanks.



### IMPORTANT


Follow the Installation Instructions supplied with the Viessmann DHW storage tank when mounting and securing DHW tank temperature sensor.



### WARNING

If a DHW storage tank other than a Viessmann Vitocell tank is used, the installer must verify proper operation of the Viessmann DHW tank temperature sensor with original manufacturer of the tank. Viessmann strongly recommends the installation of a temperature tempering valve in the DHW supply line.

## Safety Valve



### Legend

- Ⓐ Supply from Outdoor Unit
- Ⓑ 1-1/4 X 1 X 1 Inch Brass Reducing Tee
- Ⓒ 1 X 6 Inch Long Brass Nipple
- Ⓓ 1 X 3/4 Inch Brass Reducing Elbow
- Ⓔ 3/4 Inch Brass Close Nipple
- Ⓕ 30 PSI Pressure Relief Valve

Installing the pressure relief valve:

1. Use the supplied fittings to install the pressure relief valve on the Supply from Outdoor Unit Connection of the Indoor Unit refer to "Piping Connections" on page 22.

Minimum connection diameters:

Pressure relief valve..... 3/4 in.

Discharge pipe ..... 3/4 in.

Maximum operating pressure: 30 PSI (2 bar)

Minimum operating pressure: 8 PSI (0.5 bar)

Installing the discharge pipe:

1. Install discharge pipe on pressure relief valve in such a way that...

- the end of the pipe is not threaded.
- the pressure relief discharge pipe extends to a floor drain and ends approximately 6 in. (150 mm) above the drain.

Ensure that...

- there is no shutoff valve installed in the discharge pipe.
- discharge pipe diameter is not reduced.
- discharge is not piped to outdoors.



### IMPORTANT

Install the (approved) factory supplied pressure relief valve. Removal of air from the system must occur via use of air vent(s) in the system supply. To ensure the heat pump can be purged of all air, ensure supply/return water lines do not contain restrictive piping where air could be trapped.




### WARNING

Do not install an isolation valve between heat pump and pressure relief valve. The discharge pipe for the pressure relief valve must be oriented to prevent scalding of attendants. Pipe pressure relief valve discharge pipe close to floor drain. Never pipe discharge pipe to the outdoors.

## Installation Fittings

### Installation Fittings


The indoor unit is supplied with the installation fittings described.



### Legend

- (A) Supply from Outdoor Unit
- (B) 1-1/4 X 1 X 1 Inch Brass Reducing Tee
- (C) 1 X 6 Inch Long Brass Nipple
- (D) 1 X 3/4 Inch Brass Reducing Elbow
- (E) 3/4 Inch Brass Close Nipple
- (F) 30 PSI Pressure Relief Valve
- (G) 1 Inch Brass Close Nipple
- (H) Drain/Fill/Isolate Ball Valve
- (I) Return to Outdoor Unit
- (J) 1-1/4 X 1 Inch Brass Reducing Coupling

## Electrical Connections



### Legend:

- (A) DHW Recirculation Pump (PHWC)
- (B) Glycol Circuit Pump (PGC)
- (C) Cooling/Heating Divertering Valve (VCH)
- (D) Heating Circuit 1 Pump (PHC1)
- (E) Heating Circuit 2 Pump (PHC2)
- (F) Heating Circuit 2 Mixing Valve (VMHC2)
- (G) MODbus Communication with ODU (EU)
- (H) Heating Circuit 2 Temperature Sensor (THC2)
- (I) Heating Circuit 1 Temperature Sensor (THC1)
- (J) DHW Tank Temperature Sensor (TCYL)
- (K) Room Temperature Sensor (TR)
- (L) Outdoor Temperature Sensor (TO)
- (M) Backup Heat Activation - Dry Contact (OUT)
- (N) Blocking Central Heating (FN1)
- (O) Blocking Central Cooling (FN2)

### Note:

- 120VAC outputs rated current 2FLA
- Maximum output 5FLA shared between all 120V outputs.

## Electrical Connections

### Outdoor Temperature Sensor:

Installation location for outdoor temperature sensor

- North or north-westerly wall, 6 - 8 ft. (2 - 2.5 m) above ground level; in multi storey buildings, in the upper half of the second floor
- Not above windows, doors or vents
- Not immediately below balconies or gutters
- Never plaster over

Connect the outdoor temperature sensor using a two wire cable, with a length up to 150 ft. (50 m) and cross-section of 22 AWG (0.34 mm<sup>2</sup>).


### Room Temperature Sensor:

Installation location for room temperature sensor

- In the main living room on an internal wall
- Distance from floor: Min. 5 ft. (1.5 m)
- Not near windows or doors
- Not above radiators
- Not near heat sources (direct sunlight, fireplace, TV set, etc.)

Connect the room temperature sensor using a two wire cable, with a length up to 150 ft. (50 m) and cross-section of 22 AWG (0.34 mm<sup>2</sup>).

## Electrical Connections



### Input FN1:

Input FN1 is supplied with a factory installed jumper across the terminals. The jumper can be replaced with a normally closed dry contact relay. When in heating mode if the relay is in the open position central heating is blocked.


### Input FN2:

Cooling is not enabled from factory, refer to "Cooling:" on page 59 to active cooling in the "Service/Configuration Menu".

If cooling has been enabled a field supplied jumper must be installed across the FN2 terminals. The jumper can be replaced with a normally closed dry contact relay. When in cooling mode if the relay is in the open position central cooling is blocked. An optional field supplied humidity switch/sensor can be wired in series with the relay to protect the cooling system from condensation.




# Power Supply Indoor Unit




## Legend

- Ⓐ 230V/1Ph/60Hz Power Supply Connection

## AM2V 020028/034043 Power Supply



## AM2V 051078 Power Supply



## WARNING

Incorrectly executed electrical installations can lead to injuries from electrical current and result in appliance damage.



## WARNING

The control must be grounded. Ensure that 'L1', 'L2', 'N' and 'G' are not interchanged.







## IMPORTANT

Electrical installations must comply with the latest edition of:

- In the U.S.A., the National Electrical Code (NEC), ANSI/NFPA 70 and any other state, local codes and/or regulations.
- In Canada, the Canadian Electrical Code (CEC), CSA C22.1 Part 1 and any other province, territory, local codes and/or regulations.

## Dimensions

### AM2V 020028/034043 Outdoor Unit



#### Dimensions in. (mm)


	AM2V 020028	AM2V 034043
A	46 (1165)	50- <sup>3</sup> / <sub>4</sub> (1285)
B	31- <sup>1</sup> / <sub>4</sub> (795)	36- <sup>1</sup> / <sub>2</sub> (928)
C	15- <sup>3</sup> / <sub>4</sub> (400)	18- <sup>1</sup> / <sub>8</sub> (460)
D	17 (428)	18- <sup>1</sup> / <sub>2</sub> (470)
E	17- <sup>3</sup> / <sub>4</sub> (450)	20 (500)
F	32- <sup>5</sup> / <sub>8</sub> (830)	38- <sup>3</sup> / <sub>8</sub> (975)
G	9- <sup>1</sup> / <sub>8</sub> (232)	8- <sup>5</sup> / <sub>8</sub> (220)
H	13 (330)	14- <sup>1</sup> / <sub>8</sub> (360)
I	6- <sup>1</sup> / <sub>2</sub> (166)	4- <sup>5</sup> / <sub>8</sub> (118)

#### Legend

- Ⓐ - Electrical Connections
- Ⓑ - Heat Pump Hydronic Return (1 in. NPT Male)
- Ⓒ - Heat Pump Hydronic Supply (1 in. NPT Male)

Dimensions

AM2V 051078 Outdoor Unit




Dimensions in. (mm)			
A	49-1/4 (1250)	F	31-1/2 (800)
B	52-3/8 (1329)	G	6-1/8 (155)
C	19-1/2 (495)	H	37-3/4 (983)
D	20-1/4 (515)	I	8-1/2 (215)
E	21-1/4 (540)	J	10 (252)

- Legend**
- Ⓐ - Electrical Connections
  - Ⓑ - Heat Pump Hydronic Return (1 in. NPT Male)
  - Ⓒ - Heat Pump Hydronic Supply (1 in. NPT Male)

Recommended Minimum Service Clearances

AM2V 020028/034043 Outdoor Unit




AM2V 020028/034043 Outdoor Unit

- Legend**  
(A) - Air outlet  
(B) - Air inlet

Dimensions in. (mm)	
a	59 (1500)
b	20 (500)
c	39 (1000)
d	20 (500)

Recommended Minimum Service Clearances

AM2V 051078 Outdoor Unit



AM2V 051078 Outdoor Unit

Legend


- (A) - Air outlet
- (B) - Air inlet

Dimensions in. (mm)


a	59 (1500)
b	20 (500)
c	39 (1000)
d	20 (500)

## Outdoor Unit Sound Pressure


Outdoor Unit	Power level acoustic L <sub>w</sub> [dB (A)]	Directivity Factor Q	Distance from the noise source ft (m)									
			3.3 (1)	6.6 (2)	9.8 (3)	13.1 (4)	16.4 (5)	19.7 (6)	26.2 (8)	32.8 (10)	39.4 (12)	49.2 (15)
			Sound pressure level [dB (A)]									
AM2V 020028	60	2	52	46	42	40	38	36	34	32	30	28
		4	55	49	45	43	41	39	37	35	33	32
		8	58	52	48	46	44	42	40	38	36	35
AM2V 034043	63	2	55	49	45	43	41	39	37	35	33	31
		4	58	52	48	46	44	42	40	38	36	35
		8	61	55	51	49	47	45	43	41	39	38
AM2V 051078	64	2	56	50	46	44	42	40	38	36	34	32
		4	59	53	49	47	45	43	41	39	37	36
		8	62	56	52	50	48	46	44	42	40	39



Q = 2: freestanding heat pump on the outside of the building.



Q = 4: heat pump on the building's wall.



Q = 8: heat pump on the building's wall situated in the corner

## Prior to Installation

### Mounting:

- Mount the outdoor module in a free-standing position on a fixed supporting structure.
- In areas with snowfall, ensure the outdoor unit has been installed using a snow stand or wall mounting bracket that will elevate the outdoor unit above the anticipated snow load.
- The weight of the outdoor unit must be taken into account: see "Outdoor Unit Technical Data" on page 93.

### Setting:

- Do not install the exhaust side upwind.
- Carry out wall ducts and protective conduits for plumbing and electrical connection lines without using bent pipes and without changing the direction of the lines.

### Impact of weather conditions:

- When installing in areas exposed to wind, pay attention to wind loads. When the outdoor unit is mounted on a flat roof, significant wind loads may arise depending on the wind load zone and the height of the building. Include the outdoor unit in the lightning protection system.
- When designing rain protection or canopy, pay attention to the heat input (heating mode) and heat output (cooling mode) of the unit.

### Condensate:

- Ensure free drainage of the condensate away from the outdoor unit.

### Damping of sound and vibration between the building and the outdoor unit:

- Make the hydronic connection to the outdoor unit using flexible connections.
- Electrical cables should be installed without tension.



### IMPORTANT

Strong impacts may lead to a damage to the jacketing of the unit. Do not press against the outdoor unit jacketing.



### IMPORTANT

Tilting the outdoor module sharply may lead to the oil from the compressor entering the refrigeration circuit and to a consequent failure during the start-up. Maximum tilt angle: 45° for approximately 4 min., otherwise 30°

### Placement of the outdoor unit:

- Select a location with good air circulation so that cooled air can flow out and warm air can flow in.
- Do not install in corners, recesses or between walls. This may lead to a recirculation of exhaust air.



### IMPORTANT



Restricting the free flow of air may lead to cooled air (or heated in the cooling mode) being drawn back in and lead to disruptions in the operation of the unit, a loss of efficiency and a consequent increase in electrical consumption.

- If set up in an area exposed to strong winds, prevent the wind from affecting the fan area. Strong winds may disrupt the air flow through the evaporator.
- Select the installation location so that the evaporator is not clogged by leaves, snow, etc.
- Consider sound propagation and reflection when selecting the mounting location.

### Design guidelines


- Do not mount the device under windows or next to bedroom windows.
- Do not install the device in basement sumps or depressions in the ground.
- Maintain a min. 10 ft. (3 m) distance from basement sumps and windows.
- Maintain a distance from terraces, gutters or surfaces with a protective coating of min. 10 ft. (3 m). At outdoor temperatures below 50°F (10°C), cooled air blown out causes a risk of icing.
- Avoid "short circulating" of air streams with ventilation equipment. Maintain a min. 10 ft. (3 m) distance from the intake area of ventilation units.
- The installation location must be easily accessible, e.g. for service work

## Mounting on a Concrete Pad



### Dimensions in. (mm)

A	2 (50)
B	4 (100)



### Legend

- (A) - Outdoor Unit
- (B) - Concrete anchor bolt
- (C) - Rubber vibration isolator
- (D) - Concrete pad

### Concrete Pad Mounting


1. A concrete pad cast in place or a single piece pre-cast concrete or composite slab may be used. Select the size of the pad based on the dimensions provided
2. Center the outdoor unit on the pad
3. Place the rubber vibration isolators provided under the mounting feet.
4. Anchor the unit to the concrete pad.

### Note:

Ensure that the condensate drains freely.

### Condensate Drain Fittings

Prior to mounting the outdoor unit, install the condensate drain fittings into the base pan of the outdoor unit.




1. Locate the drain relief openings in the base of the outdoor unit and install the supplied condensate drain connectors.

### Note:

The AM2V 020028 and 051078 outdoor units are equipped with two condensate drain relief openings, the AM2V 034043 outdoor unit is equipped with three condensate drain openings.



## Mounting using a Mounting Curb



### Curb Mounting

1. Slide two mounting bolts into each channel.
2. Align the mounting screws with the retaining tabs on the outdoor unit, place the outdoor unit over the bolts and secure in place.


### Legend

- Ⓐ - Curb mounting bracket (field supplied)
- Ⓑ - Gravel bed to facilitate condensate absorption
- Ⓒ - Concrete foundation (if required)

### Note:

Ensure that the condensate drains freely, refer to "Condensate Drain Fittings" on page 36

## Mounting on Stand



### Stand Mounting

1. Assemble and secure stand (field supplied), ensure that spacing aligns with mounting feet of the outdoor unit.
2. Secure outdoor unit to the stand.

### Legend

- Ⓐ - Outdoor Unit
- Ⓑ - Mounting Stand


### Note:

Ensure that the condensate drains freely, refer to "Condensate Drain Fittings" on page 36




### IMPORTANT

Ensure that the stand or wall mount bracket is rated to support the weight of the outdoor unit. Follow the manufactures instructions for assembly and mounting requirements.



## Safety Valve



### Legend

- (A) Supply from Outdoor Unit
- (B) 1 Inch Brass 90 Degree Elbow
- (C) 1 X 8 Inch Long Brass Nipple
- (D) Microbubble Air Separator
- (E) 1 X 1 X  $\frac{3}{4}$  Inch Brass Reducing Tee
- (F)  $\frac{3}{4}$  Inch Brass Close Nipple
- (G)  $\frac{3}{4}$  Inch Brass 90 Degree Street Elbow
- (H) 30 PSI Pressure Relief Valve
- (I) Return to Outdoor Unit



### WARNING

Do not install an isolation valve between heat pump and pressure relief valve. The discharge pipe for the pressure relief valve must be oriented to prevent scalding of attendants. Pipe pressure relief valve discharge pipe close to floor drain. Never pipe discharge pipe to the outdoors.



### IMPORTANT

Install the (approved) factory supplied pressure relief valve. Removal of air from the system must occur via use of air vent(s) in the system supply. To ensure the heat pump can be purged of all air, ensure supply/return water lines do not contain restrictive piping where air could be trapped.

### Installing the pressure relief valve:

1. Use the supplied fittings to install the pressure relief valve on the Supply from Outdoor Unit.

Minimum connection diameters:

Pressure relief valve.....  $\frac{3}{4}$  in.


Discharge pipe .....  $\frac{3}{4}$  in.

Maximum operating pressure: 30 PSI (2 bar)

Minimum operating pressure: 8 PSI (0.5 bar)

### Installing the discharge pipe:


1. Install discharge pipe on pressure relief valve in such a way that...
    - the end of the pipe is not threaded.
    - the pressure relief discharge pipe approximately 6 in. (150 mm) above the ground.
- Ensure that...
- there is no shutoff valve installed in the discharge pipe.
  - discharge pipe diameter is not reduced.

**Piping Connections**

Connection between Indoor and Outdoor Unit


This is a simplified schematic of the connection points between the Indoor Unit and the Outdoor Unit, and does not represent all the required components.

## Accessing the Outdoor Unit



### Accessing the Outdoor Unit


1. Remove the two access panel retaining screws and set aside.
2. Slide the access panel down and pull out to remove.



### Connection Overview

- (A) - Outdoor unit electrical connections board
- (B) - Grommet for low voltage connections
- (C) - 3/4 Inch knockout for power supply

## Power Supply Outdoor Unit



### Power Supply Requirements

AM2V 020028  
208/230V-1Ph-60Hz Maximum 25 Amp Breaker

AM2V 034043  
208/230V-1Ph-60Hz Maximum 45 Amp Breaker

AM2V 051078  
208/230V-1Ph-60Hz Maximum 70 Amp Breaker

### WARNING

Incorrectly executed electrical installations can lead to injuries from electrical current and result in appliance damage.

### WARNING


The control must be grounded.  
Ensure that 'L1', 'L2', 'N' and 'G' are not interchanged.

### IMPORTANT

Electrical installations must comply with the latest edition of:

- In the U.S.A., the National Electrical Code (NEC), ANSI/NFPA 70 and any other state, local codes and/or regulations.
- In Canada, the Canadian Electrical Code (CEC), CSA C22.1 Part 1 and any other province, territory, local codes and/or regulations.

## Communication



### IMPORTANT

Do not use any solid core communication wires to connect the indoor unit to the outdoor unit, this includes the use of thermostat wires.

### Communication

Ⓐ - End of Line Resistor

The indoor unit communicates with the outdoor unit through Modbus protocol. Use a stranded two wire twisted pair, shielded 22 AWG cable to connect the following terminals;

Indoor Unit terminal EU 'A' to Outdoor Unit DIN rail terminal 1.

Indoor Unit terminal EU 'B' to Outdoor Unit DIN rail terminal 2.

Install the supplied end of line resistor Ⓐ across terminals EU A and B with communication wires to the outdoor unit.

## Installation Examples

### Connection to the hydronic system

The Vitocal 100-AW AM2V series heat pump can operate in a closed-loop hydronic system (the minimum heating medium pressure is 8 PSI [0.5 bar]). The hydronic installation must be carried out in compliance with the applicable standards. The pipes connecting the heat pump outdoor unit to the indoor unit must be sized to ensure an adequate flow of the heating medium (see technical data table).

Flexible piping must be used to connect the heat pump to the hydronic system to prevent the transmission of vibrations to the system. The heating medium pipes and connections must be thermally insulated. Do not switch off the unit when the outdoor air temperature is below freezing. Leaving the outdoor unit powered will protect the condenser of the outdoor unit from damage. If there is a risk of power failure, the heat pump heating circuit must be isolated from the hydronic module by means of an additional exchanger and the heat pump heating circuit must be filled with an antifreeze. A prerequisite for the warranty is an installation of a solids separator at the unit inlet.

The hydronic installation must be made in such a way that the indoor unit can be operated in the heating circuit without the outdoor unit (according to the following installation diagrams). This will ensure the operation of the heating system in the event of a failure of the outdoor unit.

Please note that in the following piping layout examples all pumps are field supplied.



### WARNING

If a DHW storage tank other than a Viessmann Vitocell tank is used, the installer must verify proper operation of the Viessmann DHW tank temperature sensor with the original manufacturer of the tank. Viessmann strongly recommends the installation of a temperature tempering valve in the DHW supply line.



### IMPORTANT

The examples on the following pages depict possible piping layouts of the Vitocal 100 AW heat pump equipped with Viessmann System Technology. For heat pump and tank combinations, please install only feasible combinations listed in the Viessmann Price List. Please note that the following examples are simplified conceptual drawings only! Piping and necessary componentry must be field verified.



### IMPORTANT


DHW supply and return piping between Vitocal DHW connections on the indoor unit and the Viessmann DHW tank connections, shall be a minimum of outlet sizes provided on the Vitocal. This will ensure the residual head of the integral pump is fully utilized to overcome the resistance of the DHW heat exchanger coil and to provide sufficient water flow to the Vitocal. In non-Viessmann DHW tank applications, perform, in addition to the above, accurate calculations for DHW tank coil pressure drop versus Vitocal internal pump residual head to ensure sufficient water flow to the Vitocal heat exchanger. Failure to heed the above instructions may inadequate DHW supply.



## System Example 1

Vitocal 100-AW AM2V with:

- One direct-connected heating circuit
- One heating circuit with a mixing valve
- Vitocell System Buffer Tank
- Vitocell DHW Storage Tank



### Legend:

- (A) Indoor Unit
- (B) Outdoor Unit
- (C) Outdoor Temperature Sensor
- (D) System Feed
- (E) Expansion Tank
- (F) Wye Strainer
- (H) DHW Temperature Sensor
- (I) DHW Storage Tank
- (J) Temperature and Pressure Relief Valve
- (K) Potable Water Inlet
- (L) DHW Recirculation Pump
- (M) DHW Outlet
- (N) Room Temperature Sensor
- (O) Low Temperature Heating Circuit
- (P) Heating Circuit Temperature Sensor

- (Q) Heating Circuit Pump
- (R) Heating Circuit Mixing Valve
- (S) High Temperature Heating Circuit
- (T) Heating Circuit Temperature Sensor
- (U) Heating Circuit Pump
- (V) Vitocell MSCA 20USG (75L) Buffer Tank




### IMPORTANT

System separation is required of underfloor heating systems employing non-oxygen diffusion barrier tubing. All components on the secondary side of the heat exchanger must be made of corrosion-resistant materials.

## System Example 2

Vitocal 100-AW AM2V with:

- One direct-connected heating circuit
- One heating circuit with a mixing valve
- One fan coil
- Vitocell System Buffer Tank
- Vitocell DHW Storage Tank



### Legend:


- (A) Indoor Unit
- (B) Outdoor Unit
- (C) Outdoor Temperature Sensor
- (D) System Feed
- (E) Expansion Tank
- (F) Wye Strainer
- (H) DHW Temperature Sensor
- (I) DHW Storage Tank
- (J) Temperature and Pressure Relief Valve
- (K) Potable Water Inlet
- (L) DHW Recirculation Pump
- (M) DHW Outlet
- (N) Room Temperature Sensor
- (O) Low Temperature Heating Circuit
- (P) Heating Circuit Temperature Sensor

- (Q) Heating Circuit Pump
- (R) Heating Circuit Mixing Valve
- (S) High Temperature Heating Circuit
- (T) Heating Circuit Temperature Sensor
- (U) Heating Circuit Pump
- (V) Vitocell MSCA 20USG (75L) Buffer Tank
- (W) Fan Coil

### IMPORTANT

System separation is required of underfloor heating systems employing non-oxygen diffusion barrier tubing. All components on the secondary side of the heat exchanger must be made of corrosion-resistant materials.

## User Interface





### Legend

- Ⓐ - Display
- Ⓑ - Navigation Dial
- Ⓒ - Mode Selector Dial

Use the mode selection dial Ⓒ to set one of the modes:

Winter (Space heating + DHW)  + 


Summer (Space Cooling + DHW)  + 

Standby (Frost Protection Active) 


Turning the navigation dial Ⓑ (left or right), with the winter or summer mode being active, switches the function screens on the display Ⓐ. To select the desired menu item press on the navigation dial Ⓑ.

- Home Screen: indicates the basic parameters of the heat pump (see the table for details),
- Diagnostics Menu: allows the input and output signals of the heat pump to be viewed.
- Settings Menu: allows the heat pump parameters to be adjusted to the user's preferences.
- Service Menu: allows for heat pump configuration to object's conditions (available to the installer and service contractors through an access code) and preview of input and output heat pump's signals and current parameters.
- Time Schedule Override: Allows the homeowner to override the active heating/cooling function without needing to adjust the time schedule

Pressing and holding the navigation dial when in any menu will return you to the home screen.

The individual functions are accessed by selecting the relevant menu screen and pressing the navigation dial. If an error or warning in the system occurs, the home screen will display either a **Err** or . By pressing on dial Ⓑ, a list of detected errors and warnings will be displayed.

# Display Symbols and Indications



## Legend

- (A) - Signalling of heat take-up
- (B) - Heating Program 'ON' Indication
- (C) - Heater 'ON' Indication
- (D) - Compressor Operation Indicator
- (E) - Set Room Temperature
- (F) - Actual Room Temperature
- (G) - Outdoor Temperature
- (H) - DHW Tank Temperature

## Indication of the running program

	According to a pre-set daily/weekly schedule
	Disinfection of the storage tank
	Defrost cycle running
	PARTY - maintaining a comfortable temperature in the room and the cylinder
	HOLIDAYS - maintaining an economic or frost-free temperature in the room and the storage tank
	Implementation of the frost protection program
	MANUAL - maintaining the desired temperature in the room



## Indication of Operating Mode

	Signalling of space heating
	Signalling of DHW heating
	Cooling operation indication

## Other Symbols

	Error indication
	Warning indication
	Electric heat element is active
	Indicates that the compressor is active. Flashing symbol indicates bivalent mode.
	Back-up Heating On

## Initial Start-up




When first powering up the indoor unit, you will be prompted to select the operating language, and the model of connected outdoor unit.

1. Scroll with the navigation dial to select the desired language and press the dial to select.
2. Scroll with the navigation dial to select the connected outdoor unit and press the dial to accept

## Diagnostics Menu


This menu displays the current operating conditions of the heat pump indoor and outdoor units. Parameters displayed are based on the configuration of the system

## Settings Menu



This menu provides access to the user adjustable settings of the heat pump. These settings include room temperature setpoint, DHW temperature setpoint, time schedules, etc. Available menu items may change depending on system configuration.

## Setting the Room Temperature



There are four different programmable room temperature setpoints for heating, these are used when configuring the time schedule. The four temperature setpoints are:

- Economy Temp. ☾
- Com. Minus Temp. ☼
- Comfort Temp. ☼
- Com. Plus Temp. ☼

The 'Temporary Hold' temperature setpoint uses the selected comfort temperature setting for space heating when the party mode is active.


The 'Holiday Override' temperature setpoint uses the selected economy or frost protection temperature setting for space heating when the program is active.

The 'Cooling' temperature setpoint is for space cooling (only available with panel cooling).

Scroll through the menu with the navigation dial and press the navigation dial to select. When complete select 'End' to return to the settings menu.

**Note:** Frost protection (☼) in the standby and summer modes, if the room temperature falls below 45°F (7°C), the central heating circuit will be activated. A room temperature sensor is required to activate the function.

## Setting the DHW Temperature




DHW heating activates when the DHW tank temperature is 7°F (4°C) under setpoint, DHW heating ends once tank temperature reaches setpoint. There are two different programmable DHW temperature setpoints for heating, these are used when configuring the time schedule. The two temperature setpoints are:

- Economy Temp. ☾
- Comfort Temp. ☼

Scroll through the menu with the navigation dial and press the navigation dial to select. When complete select 'End' to return to the settings menu.

**Note:** With frost protection (☼) enabled and DHW temperature falls below 45°F (7°C), DHW tank heating will be enabled.

## Setting a Time Schedule



The control allows for a maximum of 8 space heating time schedules, Sched. 1 through Sched. 8, which and be applied to each day of the week.

Each of the 8 time schedules has five editable time frames, which can have different temperature setpoints.

For space heating, there are four selectable room temperature setpoints (☀, ☀, ☀, or ☀). The default setting of the space heating schedule is the economy temperature setpoint (☀).

For DHW, there are two selectable DHW temperature setpoints (☀ or ☀). The default setting and times between temperature setpoints of the DHW heating schedule is the economy temperature setpoint (☀).


For DHW recirculation, only a start time and end time for DHW recirculation are programmable.

For space cooling, only a start time and end time for space cooling are programmable.

The 'Weekly Sched.' setting option assigns one of the eight daily time schedules to a selectable day of the week, each day of the week can have a different time schedule.

## Setting a Time Schedule


### Space Heating Time Schedule



#### Legend

- Ⓐ - active time frame
- Ⓑ - no. of time frame according to schedule (max 5)
- Ⓒ - starting time of the selected temperature
- Ⓓ - finishing time of the selected temperature
- Ⓔ - temperature selection (☀, ⚡, ☀, or ☀)
- Ⓕ - command (active when editing):
  - ☑ accept
  - ☒ delete
  - ⊕ add

### DHW Time Schedule



#### Legend

- Ⓐ - active time frame
- Ⓑ - no. of time frame according to schedule (max 5)
- Ⓒ - starting time of the selected temperature
- Ⓓ - finishing time of the selected temperature
- Ⓔ - temperature selection (☀ or ☀)
- Ⓕ - command (active when editing):
  - ☑ accept
  - ☒ delete
  - ⊕ add

In daily schedule the heating circuits have a defined starting time Ⓒ and finishing time Ⓓ of maintaining selected temperature value Ⓔ in the room. Outside defined time frames economy temperature will be maintained in the room temperature.

In daily schedule the DHW heating has a defined starting time Ⓒ and finishing time Ⓓ of maintaining selected temperature value Ⓔ in the DHW tank. Outside defined time frames economy temperature will be maintained in the reduced temperature.

#### Adjusting the time schedule


1. Select chosen program number and press navigation dial. The first parameter flashes (start time).
2. Use the navigation dial to set the new time frame value (hour and minutes separately) by turning the dial, and confirm it by pressing the dial.
3. Repeat the process for finishing time.
4. Use the navigation dial to set the new temperature selection by turning the dial, and confirm it by pressing the dial.
5. Use the navigation dial to select the command column. To save changes select ☑ command and press the dial to finish editing. To delete selected time frame select ☒ and press the dial.
6. To add new time frame, select last defined time frame and by pressing the dial go to command position, select command ⊕ and press the dial to add new time frame (edition of new time frames described above).

The entire day program is saved in the controller's memory when you exit the day program by pressing the "Save and end" command.



## Setting a Time Schedule

### DHW Recirculation Time Schedule



#### Legend

- Ⓐ - no. of time frame according to schedule (max 5)
- Ⓑ - start time of recirculation pump operation
- Ⓒ - finish time of recirculation pump operation
- ☒ accept
- ☐ delete

In daily schedule the DHW Recirculation a defined starting time Ⓑ and finishing time Ⓒ of operating the DHW recirculation pump. Outside defined time frames the DHW recirculation pump will not be active.


In daily schedule the Space Cooling has a defined starting time Ⓑ and finishing time Ⓒ of Space Cooling. Outside defined time frames the Space Cooling will not be active.

#### Adjusting the time schedule

1. Select chosen program number and press navigation dial. The first parameter flashes (start time).
2. Use the navigation dial to set the new time frame value (hour and minutes separately) by turning the dial, and confirm it by pressing the dial.
3. Repeat the process for finishing time.
4. Use the navigation dial to select the command column. To save changes select ☒ command and press the dial to finish editing. To delete selected time frame select command ☐ and press the dial.
5. To add new time frame, select last defined time frame and by pressing the dial go to command position, select command ☐ and press the dial to add new time frame (edition of new time frames described above).

The entire day program is saved in the controller's memory when you exit the day program by pressing the "Save and end" command.


### Space Cooling Time Schedule



#### Legend

- Ⓐ - active time frame (max. 5)
- Ⓑ - cooling function start time
- Ⓒ - cooling function completion time
- ☒ accept
- ☐ delete

DHW Tank Hygiene Function




DHW Hygiene function is only available in systems with installed indirect DHW storage tanks. You can heat the water in the DHW tank to above 140°F (60°C) once a week for an hour on the selected day. This function is regularly carried out at the specified time.


The following parameters can be set for operation of the tank cleansing function;

- Day of the week: the day of the week (Monday - Sunday) hygiene function operates
- Start time: Time of the selected day of the week the hygiene function will run.
- Duration: additional runtime of the hygiene function in minutes (5 to 30 additional minutes), for hygiene functions being carried out according to the schedule, not available to hygiene functions started manually.
- Run Sched.: Select 'Yes' to have the hygiene function run automatically on the select time and day of the week. Select 'No' for no hygiene function.
- DHW recirculation: DHW recirculation pump is active during hygiene function
- Manual Operation: Manual start of hygiene function, which will terminate when the working time has expired.

Scroll through the menu with the navigation dial and press the navigation dial to select. When complete select 'End' to return to the settings menu.

**WARNING**  
High DHW temperatures can cause scalding, e.g. if the DHW temperature is above 140°F (60°C). Mix with cold water at the draw-off points.

## Setting Time and Date




The following parameters can be set for time and date;

- Date Format
- Year
- Month
- Day
- Time Format
- Hour
- Minute
- Daylight Savings: When set to 'Yes' Controller automatically switches over for daylight savings, when set to 'No' Controller does not automatically switch over for daylight savings

Scroll through the menu with the navigation dial and press the navigation dial to select. When complete select 'Save and End' to return to the settings menu.

## Adjusting the Interface




The following parameters can be set for the interface;

- Brightness Min: setting of the brightness of the display in stand-by mode.
- Brightness Max: setting of the brightness of the display while interacting with the IDU.
- Sound: When set to 'Yes' rotating the dials will generate a sound, when set to 'No' there is no sound generated when rotating the dials.
- Dial Sensitivity: sets how fast or how slow the cursor will scroll through menu items.

Scroll through the menu with the navigation dial and press the navigation dial to select. When complete select 'End' to return to the settings menu.

## Setting the Language




The following languages are available;

- English
- French (Canadian)
- Spanish
- Polish

Scroll through the menu with the navigation dial and press the navigation dial to select.

## System Information




The following system information can be displayed;

- S.W. Ver. HMI: shows the software version of the IDU interface
- ODU Software Version
- S.W. Ver. PCB: shows the software version of the control board
- Control Reboot IDU: Restart of the IDU
- Factory Settings: Restores the heatpump to factory settings

Scroll through the menu with the navigation dial and press the navigation dial to select. When complete select 'End' to return to the settings menu.

# Time Schedule Override



Time Schedule Override

Temporary Hold
Holiday Override
Manual Temp. Hold
End

Time Schedule Override modes override the set time schedule for a selectable amount of time.

Note: The symbol of the activated mode is indicated on the home screen. Refer to “Display Symbols and Indications” on page 48 for description of symbols.



Manual activation of extended operating conditions;

- Temporary Hold: setting the duration of the mode (from 1 to 24 hours or until cancelled).
- Holiday Override: setting the duration of the mode (from 1 to 60 days or until cancelled).
- Manual Temp. Hold: room temperature setting implemented by the control system: until cancelled.

Note: If any of the modes above is activated, it is possible to deactivate it after entering “Time Schedule Override”.

Scroll through the menu with the navigation dial and press the navigation dial to select.

## Service/Configuration Menu



Changes in the configuration menu are possible after entering an access code. When prompted for an access code, turn the navigation dial to the required code and confirm the code by pressing the dial. If you want to exit from the code request screen, hold the navigation dial or wait until automatic return to main function screen.

Code: 987

Scroll through the menu with the navigation dial and press the navigation dial to select. When complete select 'End' to return to the Service menu.

### Heating:

#### Control Strat.:

- Curve - Temperature is calculated on the basis of outside temperature and room temperature based on schedule.
- Constant Temperature - Fixed Setpoint Temperature, set individual for Circuit 1 and Circuit 2.

### Glycol Loop Heat Exchanger:

When this function is enabled, the Glycol Pump Output (PGC) will activate any time that the IDU internal pump is running.

- Yes - there is an additional heat exchanger in the system
- No - there is no additional heat exchanger in the system.

### Frost protection:

- Yes - if the temperature in the building drops below 45°F (7°C) in the stand-by mode and the outside temperature is lower than 36°F (2°C), heating will be turned on ,
- No - protection is disabled.

## Service/Configuration Menu

### Electric Heater Delay:

This parameter defines the time after which the heat pump activates the integrated heater of the indoor unit, when in bivalent mode. Timer begins with activation of outdoor unit compressor.

### Warm Weather Shutdown:

In cases where the outside temperature is above the switch over temperature, the back-up heat source will not be turned on. In case of need for additional heat, indoor unit internal heater will be activated.

Outside temp. offset: calibration of the displayed outside temperature value.

The user selected offset value will be added to the actual outdoor temperature.

### Circuit 1 and Circuit 2:

Parameters in this menu allow the user to adjust the operating conditions of the connected heating circuits.

Note: Heating circuit 1 is intended for heating connection to a high temperature circuit;

- Slope: Selection of a heating curve (see "Adjusting the Heating Curve" on page 63 for instructions on adjusting the slope). Note: The parameter is present when the control is set according to heating curve (Adjust regulation type to: Curve).
- Shift: Heating curve shift (see "Adjusting the Heating Curve" on page 63 for instructions on adjusting the shift) Note The parameter is present when the control is set according to heating curve (Adjust regulation type to: Curve).
- Fixed Setpoint Temperature: supply temperature when operating with constants parameters (manual setting of the heating medium) [Configuration -> Heating -> Control Strategy: Fixed setpoint temperature],
- Temp. MAX: maximum supply temperature of the heating circuit.

ATTENTION: setting room temperatures which are not suitable for the building characteristics, type of heat emitters used and degree of building insulation will increase operating costs

#### ■ Circuit

Yes - activation of the Circuit 1,  
No - turning off the circuit.

- Mixing valve runtime (only available for Circuit 2): time needed to switch the valve by 90 degrees. Adjustment range from 60 to 480 seconds, factory default 120 seconds. During configuration, please check the set value with the value of the valve drive used.

- Mixing valve sensitivity: the response speed of the valve drive to achieve the corresponding parameter in the Circuit 2.

### Cooling:

- Off: cooling function inactive, Fan coil, Radiant Cooling. For radiant and slab cooling a third party controller is required.
- Chilled water setpoint: temperature of the chilled water.

## Service/Configuration Menu

### DHW Tank:

- **Electric Heater Delay:** This parameter defines the time after which the heat pump activates the integrated heater of the indoor unit, when in bivalent mode. Timer begins with activation of outdoor unit compressor.
- **In case the outside temperature is above temperature of the bivalent point, the back-up heat source (such as a gas boiler, if integrated into the system) will not be engaged. If there is a need for additional heat, the integrated heater of the indoor unit will be activated.**

### ■ Frost protection:

Yes - activation of the DHW tank frost protection in stand-by mode,

No - function inactive.

### ■ DHW Tank:

Yes - DHW tank connected.

No - DHW tank not connected.

### Back-up Heating:

Back-up heating refers a back-up heat source (such as a gas boiler) integrated into the system. The back-up heating activation output (OUT) - dry contact - is active (closed) when the outdoor temperature is less than the set bivalent temperature for back-up heating. The output is deactivated when the outdoor temperature is 1.8°F (1°C) above the set bivalent temperature for back-up heating. If back-up heating is enabled, the integrated heater of the indoor unit is no longer available for heating.

### The heat pump:

- **Indoor unit heating element enable:** the limiting outdoor temperature up to which the heat pump operates autonomously. Below this point, an additional heat source (heater) is activated
- **Low ambient heat pump cutoff:** the limit outdoor temperature at which the heat pump will shut down. If heating is required for central heating or DHW water, the heater will be the only heat source.
- **Outdoor unit model:** Model of the connected Outdoor unit.

### Room temperature:

- **Room Temperature Sensor:** room temperature control.

Yes - heating will be switched off once the set room temperature read by the room temperature sensor has been reached

No - room temperature control switched off. The room temperature reading does not affect the central heating operation.

- **Hysteresis:** room temperature hysteresis when Room Control is activated

- **Room Temp. Offset:** calibrates the value of the indicated room temperature. The parameter is added or subtracted from the value measured depending on the sign.

### DHW Recirculation:

Yes - DHW recirculation pump active and operating based on set time schedule.

No - DHW recirculation pump turned off.

### Pumps:

- **Pumps exercise:** brief pump operation to prevent pump seizing
- **Air vent mode:** During the venting procedure (10 min) the indoor unit pump runs alternately at maximum and minimum speed, during this procedure the circuit pumps are on. This allows for the concentration of air bubbles, which makes it easier to remove air from the installation.

Off - system air purging turned off.

Circuit 1 - Heating circuit 1 purging enabled.


Circuit 2 - Heating circuit 2 purging enabled.

### Communication:

- **Device ID:** device number on the communication system.



# Service/Configuration Menu



## Heat Pump Module:

This menu provides access to view heat pump operating conditions. When prompted for an access code, turn the navigation dial to the required code and confirm the code by pressing the dial. If you want to exit from the code request screen, hold the navigation dial or wait until automatic return to main function screen.

Code: 65


Scroll through the menu with the navigation dial and press the navigation dial to select. When complete select 'End' to return to the Service menu.

## Parameters

Address	Description	Default Setting	Settings Range
S12	Duration of defrost cycle	10 minutes	1-12 Minutes
S13	Entering temperature of defrost water	13°C (55°F)	0-30°C (32-86°F)
S14	Defrost intervals	45 Minutes	30-90 Minutes
S90	Minimum compressor frequency	30 Hz	Do Not Adjust
S91	Maximum compressor frequency	90 Hz	Do Not Adjust
S94	Vitocal Model	Dependant on model	Do Not Adjust

The default settings of addresses S12, S13, and S14 ensure reliable and economical operation of the heat pump, however in areas of heavy snow fall addresses S12 and S13 can be increased and S14 decreased when standard defrost settings are determined to not be sufficient.

## Service/Configuration Menu



### Service:

This menu accesses the actuator test function for the IDU. When prompted for an access code, turn the navigation dial to the required code and confirm the code by pressing the dial. If you want to exit from the code request screen, hold the navigation dial or wait until automatic return to main function screen.

### Code: 45

Scroll through the menu with the navigation dial and press the navigation dial to select. When complete select 'End' to return to the Service menu.

# Adjusting the Heating Curve

## Setting the Heating Curve Slope


The purpose of the heat pump controller is to maintain the temperature in the central heating system depending on the outdoor temperature. When the temperature outside the building is low, the need for heat is greater, whereas if the temperature outdoors is high, there is no need to maintain a high temperature in the system. The relationship between the outdoor temperature and the temperature of the central heating system can be represented in the form of a graph, the heating curve. The figure shows a family of heating curves for a room temperature set point of 72°F (22°C). Depending on the characteristics of the building, the climate zone and the heating system type, a suitable curve needs to be selected.

## Adjusting the Slope

From the Circuit 1 and Circuit 2 configuration menus:

1. Use the navigation dial to select the desired heating circuit and press the dial to select.
2. Use the navigation dial to select 'Slope' and press the dial to select 'Yes'

Supply  
Water  
Temperature  
°F (°C)



Adjusting the Heating Curve


Setting the Heating Curve Shift

If the curve needs to be shifted, change the [shift] parameter. The figure shows as an example curve no. 8 with a shift of -14°F and 50°F (-10°C and 10°C).

Adjusting the Shift

From the Circuit 1 and Circuit 2 configuration menus:

- 1. Use the navigation dial to select the desired heating circuit and press the dial to select.
- 2. Use the navigation dial to select 'Shift' and press the dial to select 'Yes'



Tips on setting the heating curve

Course of heating	Actions concerning the "heating curve"
During cold seasons, it is too cold indoors.	Set the shift to the next higher value.
During cold seasons, the rooms are too warm.	Set the shift to the next lower value.
During transitional and cold seasons, it is too cold indoors.	Set the slope to a higher value.
During transitional and cold seasons, the rooms are too warm.	Set the slope to a lower value.
It is too cool indoors in transitional seasons, yet it is warm enough in cold seasons.	Set the shift to the next lower value and the slope to a higher value.
It is too warm indoors in transitional seasons, yet warm enough in cold seasons.	Set the shift to the next higher value and the slope to a lower value.

## Troubleshooting

### Rooms are too cold

Cause	Corrective Action
The heat pump is switched off.	<ul style="list-style-type: none"> <li>■ Switch on the power switch</li> <li>■ Switch on the main switch (if installed, outside the mechanical room).</li> <li>■ Switch on the fuse in the electrical switchboard (the house fuse).</li> </ul>
The settings on the heat pump controller have been altered or are incorrect.	<ul style="list-style-type: none"> <li>■ Space heating/cooling must be activated. Check and correct the following settings if necessary: <ul style="list-style-type: none"> <li>■ Work program</li> <li>■ Heating curve</li> <li>■ Room temperature</li> <li>■ Time</li> <li>■ Time program for space heating/cooling</li> <li>■ Run additional electric heating for space heating, if necessary</li> </ul> </li> </ul>
Heating of DHW in progress	<ul style="list-style-type: none"> <li>■ Wait until the DHW heated up.</li> <li>■ If necessary, reduce the hot water intake or, temporarily, the normal hot water temperature.</li> </ul>
The display shows "Warning" or "Fault".	<ul style="list-style-type: none"> <li>■ Read out the type of notification. Confirm the notification.</li> <li>■ If necessary, contact an Authorised Service Centre</li> </ul>

### Rooms are too hot

Cause	Corrective Action
The settings on the heat pump controller have been altered or are incorrect.	<ul style="list-style-type: none"> <li>■ Space heating/cooling must be activated. Check and correct the following settings if necessary: <ul style="list-style-type: none"> <li>■ Work program</li> <li>■ Room temperature</li> <li>■ Heating curve/cooling temperature</li> <li>■ Time</li> <li>■ Time program for space heating/cooling</li> <li>■ Activate the "active cooling mode" if necessary</li> </ul> </li> </ul>
The display shows "Warning" or "Fault".	<ul style="list-style-type: none"> <li>■ Read out the type of notification. Confirm the notification.</li> <li>■ If necessary, contact an Authorised Service Centre</li> </ul>

### No Domestic Hot Water

Cause	Corrective Action
The heat pump is switched off.	<ul style="list-style-type: none"> <li>■ Switch on the power.</li> <li>■ Switch on the main switch (if installed, outside the mechanical room).</li> <li>■ Switch on the fuse in the electrical switchboard (the house fuse).</li> </ul>
The settings on the heat pump controller have been altered or are incorrect.	<ul style="list-style-type: none"> <li>■ DHW heating must be started. Check and correct the following settings if necessary: <ul style="list-style-type: none"> <li>■ Space heating or cooling time program</li> <li>■ DHW Temperature setpoint.</li> <li>■ DHW Time Program</li> <li>■ Time setting</li> <li>■ Run additional electric heating, if necessary, to heat DHW</li> </ul> </li> </ul>
The display shows "Warning" or "Fault".	<ul style="list-style-type: none"> <li>■ Read out the type of notification.</li> <li>■ If necessary, contact an contact heating contractor.</li> </ul>

## Troubleshooting

### Domestic Hot Water is too hot

Cause	Corrective Action
The settings on the heat pump controller have been altered or are incorrect.	Check and, if necessary, correct the DHW setpoint temperature.

### Warning

Cause	Corrective Action
Warning concerning special occurrence, operating condition of heat pump, heating system	If necessary, contact heating contractor.

### Fault

Cause	Corrective Action
Fault in heat pump or in heating system	If necessary, contact heating contractor.

## Fault Codes Indoor Unit

Fault Code	Cause
Temp. HC2	Circuit 2 temperature sensor error
Cooling temp.	Cold buffer temperature sensor error
DHW Tank Temp.	DHW tank temperature sensor error
Room Temp.	Room temperature sensor error
Outlet Temp.	Outlet temperature sensor error
Inlet Temp.	Return temperature sensor error
Press. Sensor	System pressure sensor error indoor unit
Temp. HC1	Circuit 1 temperature sensor error
Outside Temp.	Outside temperature sensor error
Low Battery	Battery to be replaced
PIU Pump	Indoor unit internal circulation pump error in indoor unit
Heat Pump Module	Heat pump error - outdoor unit
Low Pressure	Low pressure of the heating medium
Communication	Communication error indoor unit to outdoor unit
Thermal Cut-off	Fixed high limit switch triggered indoor unit
HP Inlet Temp.	Inlet temperature sensor error - outdoor unit
HP Outlet Temp.	Outlet temperature sensor error - outdoor unit
Curves Config. Error	Heating curves configuration error
Circuit Config. Error	Error in the configuration of the heating circuits
HP Low Pressure	Outdoor unit low refrigerant pressure

## Fault Codes Outdoor Unit

Fault Code	Cause
E10 - E11	Reserved
E12	Heating return temp sensor failure
E13	Heating outlet water temp sensor failure
E14	High pressure protection - requires manual reset
E15	Reserved
E16	Low pressure protection - requires manual reset
E17	Reserved
E18	Water flow protection - requires manual reset
E19	Electric heating overload protection
E110	Winter first class anti-freeze protection
E111	Winter second class anti-freeze protection
E112	Anti-freeze protection - requires manual reset
E113	Reserved
E114	Room temp failure
E115	Reserved
E20	Exhaust temperature overprotection - requires manual reset
E21 E22	Reserved
E23	Fan 1 overload speed limit

## Fault Codes Outdoor Unit

Fault Code	Cause
E24	Fan 2 overload speed limit
E25	The temp difference of inlet water and outlet water exceeded
E26	Outlet water over heat
E27	Mixing outlet water temp sensor failure
E28	Hot water return temp sensor failure
E29	Hot water outlet water temp sensor failure
E210 - E215	Reserved
E30 - E33	Reserved
E34	High pressure protection 3 times
E35	Reserved
E36	Low pressure protection 3 times
E37	Reserved
E38	Water flow protection 3 times - requires manual reset
E39	Electric heating protection 3 times
E310 - E311	Reserved
E312	Anti-freeze protection 3 times - requires manual reset
E313 - E315	Reserved
E40	Discharge over heat protection 3 times
E41	Reserved
E42	The temp difference of inlet water and outlet water temp exceeded 3 times
E43	The outlet water temp too low 3 times
E44	Outlet water over temperature protection 3 times
E45 - E49	Reserved
E410 - E415	Reserved
E50	Inlet water temp failure
E51	Outlet water temp failure
E52	Coil temp failure
E53	Ambient temp failure
E54	Suction temp failure
E55	Anti- freeze temp failure
E56	The coil outlet water temp sensor failure
E57 - E58	Reserved
E59	EVI inlet temp failure
E510	EVI outlet temp failure
E511	Discharge temp failure
E512	Reserved
E513	System 1 pressure sensor failure
E514	Low ambient temp failure
E515	Outlet temp too low protection
E60 - E67	Reserved
E68	Hot water temp failure
E69	Reserved




## Fault Codes Outdoor Unit

Fault Code	Cause
E610	Reserved
E611	Fan 1 failure
E612	Fan 2 failure
E613	Communication failure(main board with fan motor module board)
E614	Reserved
E615	Communication failure(main board with fan motor 2 module board)
E70	IPM overheat
E71	Compressor start failure
E72	Compressor over currents - requires manual reset
E73	Input voltage phase loss
E74	IPM current sampling fault
E75	Overheat protection of drive board devices
E76	Pre-charge failure
E77	DC bus bar over voltage
E78	DC bus under voltage
E79	AC input voltage under voltage
E710	AC input over current shutdown
E711	Input voltage sampling fault
E712	DSP and PFC communication failure
E713	Drive plate temperature fault
E714	DSP and communication board communication failure
E715	Mainboard communication failure
E80	IPM overheat stop
E81 - E82	Reserved
E83	15VDC undervoltage
E84 - E89	Reserved
E810 - E815	Reserved
E90	Voltage electromechanical current down frequency alarm
E91	Compressor weak magnetic protection alarm
E92	Power unit overheating alarm
E93	Reserved
E94	AC input current down alarm
E95	EEPROM failure warning
E96 - E99	Reserved
E910 - E912	Reserved

For faults requiring a manual reset, shut off the breaker for the outdoor unit and turn back on.

## Preparing for Service




### Preparing for Service

The mid panel of the jacketing can be removed to provide additional access of the internal components for service and maintenance. To remove the mid panel;

1. Remove the two door retaining screws.
2. Swing the door open to the left.
3. Remove the four mid panel retaining screws
4. Slide the mid panel forward to remove

When service has been completed reassemble in reverse order.


## Check Sensors



### Sensors


All sensor connections are made to the indoor unit; all sensors are NTC 10 kΩ. The temperature sensors are connected to a low-voltage printed circuit board.

- DHW Tank Temperature sensor
- System supply water temperature sensor
- Room temperature sensors



- Outdoor temperature sensor

## Checking Fuses



Fuse F3 of the indoor unit is located on the main board of the indoor unit.

Fuse type:

- T 5.0 A H, 250 V ~

1. Switch off the power supply
2. Check the fuse, replace if necessary.



### IMPORTANT

Incorrect or improperly installed fuses may lead to an increased risk of fire.



### IMPORTANT

Removing the fuses does not result in the load circuit being disconnected from voltage. Contact with any live parts may lead to electrocution. When working on the unit, it is essential that the load circuit is also disconnected.

Maintenance

Cleaning

- Note:  
Commercially available cleaners and special cleaners for heat exchangers (evaporators) may cause damage to the heat pump.
- Clean the surfaces of the unit with a damp cloth only.
  - If necessary, clean the shutters of the heat exchanger (evaporator) with a long bristle brush.

The surface of the indoor unit can be cleaned with the microfibre cloth.

Regular maintenance ensures trouble-free, energy-efficient and environmentally-friendly operation in the heating/cooling mode. For this purpose, it is best to contract a specialist company for inspection and maintenance.

Damaged connection wires  
If the connection wires of the unit or of outdoor accessories are damaged, they must be replaced with specific connection cables. Only use the cables recommended by the manufacturer for replacement. Notify a specialist company for this purpose.

Refrigerant  
The unit contains fluorinated greenhouse gases (a refrigerant) listed in the Kyoto Protocol. The refrigerant type which the device operates with is indicated on the rating plate.  
The Global Warming Potential (GWP) of the refrigerant is given as a multiple of the GWP of carbon dioxide (CO<sub>2</sub>). The GWP of carbon dioxide CO<sub>2</sub> is 1.

Refrigerant	Global Warming Potential GWP
R32	675 <sup>*1</sup> /677 <sup>*2</sup>

<sup>\*1</sup> According to the Fourth Assessment Report adopted by the Intergovernmental Panel on Climate Change (IPCC)

<sup>\*2</sup> According to the Fifth Assessment Report adopted by the Intergovernmental Panel on Climate Change (IPCC)

## Maintenance

For systems with flammable refrigerants

- Anyone working on a refrigeration system is required to submit a proof of qualification issued by an accredited body authorised to issue industry certifications. The proof of qualification is a certificate of competence in the safe handling of refrigerants as prescribed in industry standards.
- Maintenance work must always be carried out in accordance with the manufacturer's requirements. If assistance by other persons is required during maintenance and repair work, then a person trained in the safe handling of flammable refrigerants is required to supervise the work being carried out at all times.
- In order to minimise the risk of fire, it is necessary to carry out safety checks before working on equipment where flammable refrigerants are used. Before working on a refrigeration circuit, the following measures must be taken:

General: place of work	
	<ul style="list-style-type: none"> <li>■ Inform the persons listed below of the work to be carried out:               <ul style="list-style-type: none"> <li>- All maintenance staff</li> <li>- All persons who are in the vicinity of the installation.</li> </ul> </li> <li>■ Close off the area near the heat pump.</li> <li>■ Check the surroundings of the heat pump for combustible materials and sources of ignition. Remove all combustible materials and sources of ignition.</li> </ul>
Monitoring the presence of refrigerant	
	<ul style="list-style-type: none"> <li>■ To identify flammable atmosphere in good time: Before, during and after the work, check the surroundings for refrigerant leaks using an ignition-protected refrigerant detector designed for R32. The refrigerant detector must not cause any sparks and must be properly sealed.</li> </ul>
Fire extinguisher	
	<p>A CO<sub>2</sub> or powder extinguisher must be available in the cases described below:</p> <ul style="list-style-type: none"> <li>■ Filling the system with refrigerant.</li> <li>■ Performing welding or soldering work.</li> </ul>
Sources of ignition	
	<ul style="list-style-type: none"> <li>■ During any work carried out on a refrigeration circuit that contains or contained a refrigerant, ignition sources that could ignite the refrigerant must not be used. Any possible sources of ignition, including cigarettes, must be removed from the area where installation, repair, dismantling or disposal work is to be carried out that involves a hazard of the refrigerant leak.</li> <li>■ Before starting work, check that there are no combustible materials or sources of ignition around the heat pump. Remove all combustible materials and sources of ignition.</li> <li>■ Place no-smoking signs</li> </ul>
Work area ventilation	
	<ul style="list-style-type: none"> <li>■ Carry out repairs in the open air or ventilate the work area well before working on the cooling system or carrying out welding or soldering work.</li> <li>■ Ventilation must be in operation at all times. The purpose of the ventilation is to dilute the refrigerant in the event of a leak and to discharge it outdoors if possible.</li> </ul>


## Maintenance

Inspection of the refrigeration installation	
	<ul style="list-style-type: none"> <li>■ Replaced electrical components must be suitable for the application and comply with the specifications provided by the manufacturer. Replace any defective components with original spare parts only.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Replace components according to the recommendations issued by the company of Viessmann. Contact Viessmann technical service if necessary.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Check the surroundings of the heat pump for combustible materials and sources of ignition. Remove all combustible materials and sources of ignition.</li> </ul>
Carry out the following checks	
	<ul style="list-style-type: none"> <li>■ Check the operation of the ventilation. Ventilation openings must not be blocked or obstructed.</li> </ul>
	<ul style="list-style-type: none"> <li>■ If a system with hydronic decoupling is used, check the secondary circuit for the refrigerant.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Inscriptions and symbols must be clearly visible and legible. Replace any illegible inscriptions or symbols.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Refrigerant lines or components must be fitted in such a way that they do not come into contact with corrosive substances.</li> </ul>
	Exception: refrigerant lines are made of a corrosion-resistant material or are reliably protected against corrosion.
Inspection of electric components	
	<ul style="list-style-type: none"> <li>■ When carrying out maintenance and repair work on electric parts, safety checks must be carried out: see below.</li> </ul>
	<ul style="list-style-type: none"> <li>■ If a safety-critical fault occurs, do not connect the installation until the fault has been rectified. If it is not possible to rectify the fault immediately, a suitable interim solution for the operation of the installation must be found if possible. Notify the user of the installation</li> </ul>
Carry out the following safety checks:	
	<ul style="list-style-type: none"> <li>■ Discharging of capacitors: ensure that no sparks are generated during the discharge process.</li> </ul>
	<ul style="list-style-type: none"> <li>■ When filling or draining the refrigerant, as well as when flushing the refrigeration circuit, do not place any electrical parts or live wires near the device.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Check the earthing connection.</li> </ul>
Repairs to sealed casings	
	<ul style="list-style-type: none"> <li>■ During work on sealed components, the device must be powered off before the sealed cover is removed.</li> </ul>
	<ul style="list-style-type: none"> <li>■ To warn of a potentially hazardous situation, a permanently operating refrigerant detector should be placed at critical locations.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Particular care must be taken when working on electrical parts so as not to modify the casing in a way that weakens its protective effect. This applies to a damage to cables, the creation of too many connectors on one connection terminal, the creation of connectors that do not meet the manufacturer's requirements, damage to seals and incorrect installation of cable restraints.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Ensure that the unit is installed correctly.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Check that the seals are properly installed. Thereby, check that the seals reliably protect the device against the penetration of a flammable atmosphere. Replace any damaged hoses. <b>Attention!</b> Silicone as a sealing agent may affect the performance of a leak detection devices. Do not use silicone as a sealing agent.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Spare parts must comply with the manufacturer's guidelines.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Work on components that are suitable for flammable atmospheres: these components do not need to be powered off.</li> </ul>

## Maintenance

Repairs to parts that operate in a combustible atmosphere	
	<ul style="list-style-type: none"> <li>■ Unless it can be established that the permissible voltage and current values will not be exceeded, no capacitive or inductive loads must be connected to the device.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Only those components that meet the requirements for operation in a flammable atmosphere may be connected to voltage in a flammable atmosphere.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Use only original spare parts or parts approved by Viessmann. In the event of a leak, all other parts may ignite the refrigerant.</li> </ul>
Wiring	
	<ul style="list-style-type: none"> <li>■ Check that the wiring is not exposed to wear, corrosion, stretching, vibration or any adverse environmental conditions and that it is not located near sharp edges.</li> </ul>
	<ul style="list-style-type: none"> <li>■ When inspecting, also consider the effects of ageing and the effects of continuous vibration on the compressors and fans.</li> </ul>
Refrigerant detectors	
	<ul style="list-style-type: none"> <li>■ Under no circumstances use ignition sources to detect the refrigerant and refrigerant leaks.</li> </ul>
	<ul style="list-style-type: none"> <li>■ No flame detectors may be used to detect leaks.</li> </ul>
Leak detection	
The methods described below are suitable for detecting leaks in systems filled with a flammable refrigerant: Leak detection with electronic refrigerant detectors:	
	<ul style="list-style-type: none"> <li>■ Electronic leak detectors may not be adequately sensitive or need to be calibrated for a specific detection range. Calibrate the detector in a refrigerant-free environment.</li> </ul>
	<ul style="list-style-type: none"> <li>■ The refrigerant detector must be suitable for detecting R32.</li> </ul>
	<ul style="list-style-type: none"> <li>■ The refrigerant detector must contain no potential ignition sources.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Calibrate the refrigerant detector for the refrigerant used. Set the trip threshold <math>&lt; 3 \text{ g/a}</math>, which is suitable for R32. Leak detection using leak detection fluids, Leak detection fluids are suitable for most of refrigerants.</li> </ul>
Note:	
Chlorine-containing leak detection fluids may react with the refrigerant.	
As a result, rust may form.	
Do not use any leak detection fluids that contain chlorine.	
Procedure when leaks are found in the refrigeration circuit:	
	<ul style="list-style-type: none"> <li>■ Immediately extinguish any fire in the vicinity of the heat pump.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Do not solder leaks on the refrigeration circuit.</li> </ul>
Refrigerant suction and evacuation	
	Purge reffridgerant using methods approved for A2L reffridgerants
Refrigerant filling	
	Fill reffridgerant using methods approved for A2L reffridgerants
Marking (inscriptions on the heat pump)	
A plate with the date and signature and the following information must be placed in a clearly visible position on the heat pump which has been decommissioned:	
	<ul style="list-style-type: none"> <li>■ Flammable refrigerant</li> </ul>
	<ul style="list-style-type: none"> <li>■ Installation is not working.</li> </ul>
	<ul style="list-style-type: none"> <li>■ Refrigerant has been removed.</li> </ul>


**AM2V 020028/034043 Indoor Unit**



CB1 - Circuit Breaker

P - Pressure Sensor






CB1 - Circuit Breaker

P - Pressure Sensor

## AM2V 020028 Outdoor Unit




Designation	Description
AFT	Anti-freeze Temperature
AT	Ambient Temperature
COMP	Compressor
CT	Coil Temperature
CH	Cabinet Heater
EIT	EVI Inlet Gas Temperature
EOT	EVI Outlet Gas Temperature
EEV	Electronic Expansion Valve
EVIV	Electronic Expansion Valve for EVI
ET	Exhaust Temperature
FM	Fan Motor
FS	Flow Switch
HP	High Pressure Protection
IT	Inlet Water Temperature

Designation	Description
K4	Relay of Circulation Pump
K5	Relay of Hot Water Pump
K9	Relay of 3-Way Valve
K11	Relay of Pan Heater
LP	Low Pressure Protection
LPS	Low Pressure Sensor
OT	Outlet Water Temperature
OHP	Overheat Protection
PH	Pan Heater
RT	Room Temperature
SUT	Suction Temperature
SPS	Switching Power Supply
4V	4-Way Valve
TT	Tank Temperature

# Outdoor Unit Wiring Diagram


## AM2V 034043 Outdoor Unit



Designation	Description
AFT	Anti-freeze Temperature
AT	Ambient Temperature
COMP	Compressor
CT	Coil Temperature
CH	Cabinet Heater
EIT	EVI Inlet Gas Temperature
EOT	EVI Outlet Gas Temperature
EEV	Electronic Expansion Valve
EVIV	Electronic Expansion Valve for EVI
ET	Exhaust Temperature
FM	Fan Motor
FS	Flow Switch
HP	High Pressure Protection
IT	Inlet Water Temperature

Designation	Description
K4	Relay of Circulation Pump
K5	Relay of Hot Water Pump
K9	Relay of 3-Way Valve
K11	Relay of Pan Heater
LP	Low Pressure Protection
LPS	Low Pressure Sensor
OT	Outlet Water Temperature
OHP	Overheat Protection
PH	Pan Heater
RT	Room Temperature
SUT	Suction Temperature
SPS	Switching Power Supply
4V	4-Way Valve
TT	Tank Temperature

## AM2V 051078 Outdoor Unit



Designation	Description
AFT	Anti-freeze Temperature
AT	Ambient Temperature
COMP	Compressor
CT	Coil Temperature
CH	Cabinet Heater
EIT	EVI Inlet Gas Temperature
EOT	EVI Outlet Gas Temperature
EEV	Electronic Expansion Valve
EVIV	Electronic Expansion Valve for EVI
ET	Exhaust Temperature
FM	Fan Motor
FS	Flow Switch
HP	High Pressure Protection
IT	Inlet Water Temperature

Designation	Description
K4	Relay of Circulation Pump
K5	Relay of Hot Water Pump
K9	Relay of 3-Way Valve
K11	Relay of Pan Heater
LP	Low Pressure Protection
LPS	Low Pressure Sensor
OT	Outlet Water Temperature
OHP	Overheat Protection
PH	Pan Heater
RT	Room Temperature
SUT	Suction Temperature
SPS	Switching Power Supply
4V	4-Way Valve
TT	Tank Temperature

## Parts List

### Indoor Unit Model No. Serial No.

AM2V 020028 7228973 AM2V 034043 7228974 AM2V 051078 7228975 

### Ordering Replacement Parts:

Please provide Model and Serial Number from rating plate when ordering replacement parts.

Order replacement components from your Viessmann distributor.


0001 - Wall Mounting Bracket

0002 - Electrical Knockout Panel

0003 - Indoor Unit User Interface

0004 - Mid-panel

0005 - Door



## Parts List

### Indoor Unit Model No. Serial No.

AM2V 020028	7228973	□□□□□□□□
AM2V 034043	7228974	□□□□□□□□
AM2V 051078	7228975	□□□□□□□□


### Ordering Replacement Parts:

Please provide Model and Serial Number from rating plate when ordering replacement parts.  
Order replacement components from your Viessmann distributor.

- 0001 - DIN Rail
- 0002 - Fixed High Limit
- 0003 - Contactor
- 0004 - Control Board
- 0005 - Temperature Sensor

### Other Items not Illustrated

- 0006 - Immersion Temperature Sensor (System)
- 0007 - Strap-on Temperature Sensor System
- 0008 - Room Temperature Sensor
- 0009 - Outdoor Temperature Sensor
- 0010 - Fuse 5A 250VAC Time Delay



## Parts List


### Indoor Unit Model No. Serial No.

AM2V 020028	7228973	□□□□□□□□
AM2V 034043	7228974	□□□□□□□□
AM2V 051078	7228975	□□□□□□□□

### Ordering Replacement Parts:

Please provide Model and Serial Number from rating plate when ordering replacement parts.  
Order replacement components from your Viessmann distributor.

- 0001 - Expansion vessel
- 0002 - Automatic Air Vent
- 0003 - Electric Heating Element
- 0004 - Gasket
- 0005 - DHW Heating Supply Pipe
- 0006 - Diverting Valve Body
- 0007 - System Supply Pipe
- 0008 - Diverting Valve Actuator
- 0009 - System Return Pipe
- 0010 - Pressure Sensor
- 0011 - Outdoor Unit Return Pipe
- 0012 - Manual Bleeder Screw
- 0013 - Circulation Pump
- 0014 - Outdoor Unit Supply Pipe
- 0015 - Auto Reset Temperature Limit



## Parts List

Outdoor Unit Model No.

AM2V 020028

Serial No.


7986309□□□□□□□□

### Ordering Replacement Parts:

Please provide Model and Serial Number from rating plate when ordering replacement parts.

Order replacement components from your Viessmann distributor.

- 0001 Fan Grill
- 0002 Front Panel
- 0003 Wind Deflector
- 0004 Fan Blade
- 0005 Fan Motor
- 0006 Left Panel
- 0007 Corner Panel
- 0008 Air to Refrigerant Coil
- 0009 Fan Motor Bracket
- 0010 Electrical Box
- 0011 Top Panel
- 0012 Top Rail
- 0013 Electrical Box Cover
- 0014 Rear Grill Panel
- 0015 Interior Separation Panel
- 0016 System Water Supply Pipe
- 0017 Refrigerant to System Water Plate Heat Exchanger
- 0018 System Water Return Pipe
- 0019 Reversing Valve
- 0020 System Water Flow Switch
- 0021 Electrical Grommet
- 0022 Rear Connection Panel
- 0023 Side Access Panel
- 0024 Support Bracket
- 0025 Low Pressure Switch
- 0026 High Pressure Switch
- 0027 Isolation Fill Valve
- 0028 One Way Safety Valve
- 0029 Electronic Expansion Valve
- 0030 Filter
- 0031 Electronic Expansion Valve
- 0032 Schrader Valve
- 0033 EVI Plate Heat Exchanger
- 0034 EVI Plate Heat Exchanger Bracket
- 0035 Refrigerant to System Water Plate Heat Exchanger Bracket
- 0036 Base Plate
- 0037 Compressor
- 0038 Transformer
- 0039 Compressor Cover 1
- 0040 Compressor Cover 2
- 0041 Transformer Housing
- 0042 Compressor Cover 3
- 0043 Compressor Cover 4
- 0044 Suspension Chassis
- 0045 Pressure Switch
- 0046 Tee Fitting (9.7X9.7)
- 0047 Tee Fitting (6.5X6.5)
- 0048 Tee Fitting (9.52X6.35)







## Parts List

**Outdoor Unit Model No.**      **Serial No.**  
 AM2V 020028                      7986309□□□□□□□□

### Ordering Replacement Parts:

Please provide Model and Serial Number from rating plate when ordering replacement parts.  
 Order replacement components from your Viessmann distributor.

0001 Fuse  
 0002 2 Pole Terminal  
 0003 Driver Board  
 0004 Switching Power Supply  
 0005 PC4003-G Board  
 0006 Electrical Enclosure  
 0007 Relay  
 0008 BHB21 Board  
 0009 DIN Rail 2 Pole  
 0010 Power Supply Terminal



## Parts List

**Outdoor Unit Model No.**

AM2V 034043

**Serial No.**


7986310□□□□□□□□

**Ordering Replacement Parts:**

Please provide Model and Serial Number from rating plate when ordering replacement parts.

Order replacement components from your Viessmann distributor.

- 0001 Fan Grill
- 0002 Front Panel
- 0003 Wind Deflector
- 0004 Fan Blade
- 0005 Fan Motor
- 0006 Left Panel
- 0007 Corner Panel
- 0008 Air to Refrigerant Coil
- 0009 Fan Motor Bracket
- 0010 Electrical Box
- 0011 Top Panel
- 0012 Top Rail
- 0013 Electrical Box Cover
- 0014 Rear Grill Panel
- 0015 Interior Separation Panel
- 0016 System Water Supply Pipe
- 0017 System Water Return Pipe
- 0018 Reversing Valve
- 0019 Refrigerant to System Water Plate Heat Exchanger Bracket
- 0020 Refrigerant to System Water Plate Heat Exchanger
- 0021 System Water Flow Switch
- 0022 Electrical Grommet
- 0023 Side Access Panel
- 0024 Rear Connections Panel
- 0025 Support Bracket
- 0026 Low Pressure Switch
- 0027 High Pressure Switch
- 0028 Schrader Valve 1
- 0029 Isolation Fill Valve
- 0030 One Way Safety Valve
- 0031 Electronic Expansion Valve
- 0032 Filter
- 0033 Electronic Expansion Valve 2
- 0034 Schrader Valve 2
- 0035 EVI Plate Heat Exchanger
- 0036 Fluid Reservoir
- 0037 Base Plate
- 0038 Compressor
- 0039 Compressor Cover 1
- 0040 Compressor Cover 2
- 0041 Transformer
- 0042 Compressor Cover 3
- 0043 Compressor Cover 4
- 0044 Suspension Chassis
- 0045 Pressure Switch
- 0046 Tee Fitting (9.7X9.7)
- 0047 Tee Fitting (6.5X6.5)
- 0048 Tee Fitting (9.52X6.35)





## Parts List

**Outdoor Unit Model No.**      **Serial No.**  
 AM2V 034043                      7986310□□□□□□□□

### Ordering Replacement Parts:

Please provide Model and Serial Number from rating plate when ordering replacement parts.  
 Order replacement components from your Viessmann distributor.

0001 Switching Power Supply  
 0002 Fan Speed Control Module  
 0003 Driver Board  
 0004 2 Pole Terminal  
 0005 PC4003-G Board  
 0006 Relay  
 0007 Fuse  
 0008 8 Pole Terminal  
 0009 BHB21 Board  
 0010 EMC Filter  
 0011 DIN Rail 2 Pole  
 0012 Power Supply Terminal



## Parts List

Outdoor Unit Model No.

AM2V 051078

Serial No.


7986311□□□□□□□□

### Ordering Replacement Parts:

Please provide Model and Serial Number from rating plate when ordering replacement parts.

Order replacement components from your Viessmann distributor.

- 0001 Fan Grill
- 0002 Front Panel
- 0003 Wind Deflector
- 0004 Fan Blade
- 0005 Fan Motor
- 0006 Left Panel
- 0007 Corner Panel
- 0008 Air to Refrigerant Coil
- 0009 Fan Motor Bracket
- 0010 Electrical Box
- 0011 Top Panel
- 0012 Top Rail
- 0013 Electrical Box Cover
- 0014 Rear Grill Panel
- 0015 Interior Separation Panel
- 0016 Refrigerant to System Water Plate Heat Exchanger
- 0017 System Water Supply Pipe
- 0018 System Water Return Pipe
- 0019 Refrigerant to System Water Plate Heat Exchanger Bracket
- 0020 Reversing Valve
- 0021 Transformer
- 0022 System Water Flow Switch
- 0023 Electrical Grommet
- 0024 Side Access Panel
- 0025 Rear Connections Panel
- 0026 Support Bracket
- 0027 Isolation Fill Valve
- 0028 High Pressure Switch
- 0029 Low Pressure Switch
- 0030 One Way Safety Valve
- 0031 Electronic Expansion Valve
- 0032 Filter
- 0033 Electronic Expansion Valve
- 0034 Schrader Valve 1
- 0035 Schrader Valve 2
- 0036 EVI Plate Heat Exchanger
- 0037 EVI Plate Heat Exchanger Bracket
- 0038 Bracket
- 0039 Compressor
- 0040 Compressor Cover 1
- 0041 Base Plate
- 0042 Compressor Cover 2
- 0043 Compressor Cover 3
- 0044 Compressor Cover 4
- 0045 Transformer
- 0046 Transformer Cover
- 0047 Transformer Base
- 0048 Mounting Bracket
- 0049 Suspension Chassis
- 0050 Pressure Switch
- 0051 Tee Fitting (9.7X9.7)
- 0052 Tee Fitting (12.7X12.7)
- 0053 Filter





## Parts List

**Outdoor Unit Model No.**      **Serial No.**  
 AM2V 051078                      7986311□□□□□□□□

### Ordering Replacement Parts:

Please provide Model and Serial Number from rating plate when ordering replacement parts.  
 Order replacement components from your Viessmann distributor.

0001 PC4003-G Board  
 0002 Switching Power Supply  
 0003 Fan Speed Control Module  
 0004 8 Pole Terminal  
 0005 Fuse  
 0006 Driver Board  
 0007 2 Pole Terminal  
 0008 Temperature Sensor  
 0009 Electrical Enclosure  
 0010 BHB21 Board  
 0011 EMC Filter  
 0012 Relay  
 0013 Power Supply Terminal  
 0014 DIN Rail 2 Pole  
 0015 Electrical Enclosure



## Parts List

### Indoor Unit Model No. Serial No.

AM2V 020028 7228973

AM2V 034043 7228974

AM2V 051078 7228975

### Ordering Replacement Parts:

Please provide Model and Serial Number from rating plate when ordering replacement parts.

Order replacement components from your Viessmann distributor.

0001 - Reducer 1-1/4 to 1 in. Brass

0002 - 1 in. Close Nipple Brass

0003 - Isolation Valve


0004 - 1-1/4 X 1 X 1 in. Reducing Tee Brass

0005 - Pressure Relief Valve 30 PSI

0006 - 3/4 in. Close Nipple Brass

0007 - 1 in. X 6 in. Long Nipple Brass

0008 - 1 to 3/4 in. Reducing Elbow Brass





# Parts List

Outdoor Unit Model No.	Serial No.
AM2V 020028	7986309□□□□□□□□
AM2V 034043	7986310□□□□□□□□
AM2V 051078	7986311□□□□□□□□

## Ordering Replacement Parts:

Please provide Model and Serial Number from rating plate when ordering replacement parts.  
Order replacement components from your Viessmann distributor.

- 0001 - Pressure Relief Valve 30 PSI
- 0002 - 3/4 in. Close Nipple Brass
- 0003 - 3/4 in. Street Elbow Brass
- 0004 - 1 X 1 X 3/4 in. Reducing Tee Brass
- 0005 - Microbubble Air Separator
- 0006 - 1 in. Elbow Brass
- 0007 - 1 in. X 8 in. Long Nipple Brass



## Indoor Unit Technical Data

Indoor Unit	Model	AM2V 020028	AM2V 034043	AM2V 051078
<b>Electrical Data</b>				
Power Supply	Voltage	230 VAC	230 VAC	230 VAC
	Phase	1	1	1
	Hertz	60	60	60
	Amperage (FLA)	31	31	43
	Maximum Fuse (Amps)	40	40	50
Electric Heater Output	kW (BTU)	6 (20500)	6 (20500)	9 (30700)
Heating Elements		2	2	3
<b>Hydronic Data</b>				
Hydronic connection		1¼ NPT (Male Threads)	1¼ NPT (Male Threads)	1¼ NPT (Male Threads)
Min. Operating Pressure	PSI (bar)	8 (0.5)	8 (0.5)	8 (0.5)
Max. Operating Pressure	PSI (bar)	30 (2)	30 (2)	30 (2)
Max. System Temperature	°F (°C)	140 (60)	140 (60)	140 (60)
Max. DHW Temperature	°F (°C)	167 (75)	167 (75)	167 (75)
Max. Operating Temperature	°F (°C)	165 (74)	165 (74)	165 (74)
Fixed High Limit	°F (°C)	186 (86)	186 (86)	186 (86)
Expansion vessel volume	USG (l)	3.2 (12)	3.2 (12)	3.2 (12)
Expansion vessel precharge	PSI (bar)	14 (1)	14 (1)	14 (1)
Minimum flow	GPM (m³/h)	2.6 (0.6)	3.1 (0.7)	3.7 (0.85)
Maximum flow	GPM (m³/h)	4.4 (1.0)	7.5 (1.7)	12.8 (2.9)
Pressure drop	ft. of hd (kPa)	0.6 (2)	1.6 (5)	5.0 (15)
Residual Head <sup>*1</sup>	ft. of hd (kPa)	17 (50)	17 (50)	17 (50)
Minimum Relief Valve Capacity	MBH	510	510	510
<b>Dimensional Data</b>				
Dimensions	Height	in. (mm)	28-½ (723)	28-½ (723)
	Width	in. (mm)	16-¼ (416)	16-¼ (416)
	Depth	in. (mm)	12-¾ (323)	12-¾ (323)
Weight	lbs (kg)		64 (29)	64 (29)

<sup>\*1</sup> Residual head for the Indoor Unit internal pump, the residual head value takes into consideration pressure drop of the Indoor Unit, Outdoor Unit and supplied installation fittings at rated maximum flow rate of the Indoor Unit. The pressure drop through the piping between the IDU, ODU, buffer tank, and the coil of the indirect DHW tank, must not exceed the stated residual head in order to maintain optimal system performance.



## Outdoor Unit Technical Data

Outdoor Unit		Model	AM2V 020028	AM2V 034043	AM2V 051078
<b>Heating/Cooling Data</b>					
Heating Capacity* <sup>1</sup>		MBH (kW)	20.5 (6.0)	34.0 (10)	58.0 (17)
COP (A5W110)* <sup>2</sup>			1.3	2.2	1.9
Cooling Capacity Range	Low	Tons (kW)	1.4 (4.9)	2.8 (9.8)	4.2 (14.7)
	High	Tons (kW)	1.5 (5.2)	2.9 (10.2)	4.3 (15.1)
Energy Efficiency Ratio (EER)			16.81	16.75	14.46
COP			4.927	4.909	4.238
<b>Electrical Data</b>					
Power Supply		Voltage	208/230 VAC	208/230 VAC	208/230 VAC
		Phase	1	1	1
		Hertz	60	60	60
Total Electrical Load		Amps	13.0	21.8	35.1
Compressor Load Rating		Amps	12.2	21.0	33.5
Fan Motor Load Rating		Amps	0.8	0.8	2 x 0.8
Minimum Circuit Ampacity		Amps	17	28	44
Maximum Fuse		Amps	25	45	70
<b>Refrigerant</b>					
Refrigerant			R32	R32	R32
Factory Charge		lbs (kg)	2.43 (1.1)	3.97 (1.8)	4.41 (2.0)
Max. Allowable Pressure - Heating		PSIG (MPa)	725 (5.0)	740 (5.1)	972 (6.7)
Max. Allowable Pressure - Cooling		PSIG (MPa)	624 (4.3)	609 (4.2)	624 (4.3)
Max. Operating Pressure - Low Side		PSIG (MPa)	305 (2.1)	305 (2.1)	305 (2.1)
Max. Operating Pressure - High Side		PSIG (MPa)	638 (4.4)	638 (4.4)	638 (4.4)
<b>Hydronic Data</b>					
Hydronic connection			1 NPT (Male Threads)	1 NPT (Male Threads)	1 NPT (Male Threads)
Water Flow Rate		GPM (m <sup>3</sup> /h)	3.7-8.8 (0.85-2.0)	6.2-15.0 (1.4-3.4)	11.4-25.5 (2.6-5.8)
Pressure drop		ft. of hd (kPa)	3.3 (10)	6.7 (20)	15.0 (45)
Maximum temperature of heating medium		°F(°C)	149 (65)	149 (65)	149 (65)
<b>Air and Noise</b>					
Maximum DC power of fan		W	85	170	2 x 75
Maximum air flow		CFM (m <sup>3</sup> /h)	1765 (3000)	2650 (4500)	2 x 1470 (2 x 2500)
Minimum/maximum air temperature		°F(°C)	-13/109 (-25/43)	-13/109 (-25/43)	-13/109 (-25/43)
Maximum sound pressure level at 3.3 ft. (1m) distance		dB(A)	52	55	56
Maximum sound power level		dB(A)	60	63	64
<b>Dimensional Data</b>					
Dimensions (HXWXD)	Height	in. (mm)	31-1/4 (795)	36-1/2 (928)	52-3/8 (1329)
	Width	in. (mm)	46 (1165)	50-3/4 (1285)	49-1/4 (1250)
	Depth	in. (mm)	15-3/4 (400)	18-1/8 (460)	19-1/2 (495)
Weight		lbs (kg)	206 (93.5)	275 (124.5)	411 (186.5)

\*<sup>1</sup> Heating capacity based on a ambient air temper of 45°F (7°C) supply water temperature 95°F (35°C) and a 8°F (5°C) Δt

\*<sup>2</sup> COP (A5W110) Coefficient of Performance at ambient air temperature of 5°F (-15°C) supply water temperature 110°F (43.3°C)

## Filling the System

### Water quality


Treatment for Vitocal 100 AW feed water should be considered in areas of known problems, such as where a high mineral content and hardness exist.

In areas where freezing might occur, an antifreeze may be added to the system water to protect the system. Please adhere to the specifications given by the antifreeze manufacturer.

Do not use automotive silicate based antifreeze. Please observe that an antifreeze/water mixture may require a backflow preventer within the automatic water feed and influence components such as diaphragm expansion tanks, radiation, etc. Maximum antifreeze content is 50% for the Vitocal 100 AW. Refer to the manufacturers specifications when determining derate based on glycol concentration.

Do not use feed water which contains sulphur. Check pH-level after some operating time. It should be in the range from 8.2 to 9.5. If it is not, please take appropriate measures. Total permissible hardness of the fill and top-up water - 70 ppm.


Do not use antifreeze other than specifically made for hot water heating systems. System also may contain components which might be negatively affected by antifreeze. Check total system frequently when filled with antifreeze. Advise system operator/ultimate owner that system is filled with a glycol mix. The heating contractor must provide a SDS (Safety Data Sheet) for the antifreeze used to the system operator/ultimate owner.





Viessmann Manufacturing Company (U.S.) Inc.  
45 Access Road  
Warwick, Rhode Island · 02886 · USA  
TechInfo Line 1-888-484-8643  
1-800-288-0667 · Fax (401) 732-0590  
[www.viessmann-us.com](http://www.viessmann-us.com) · [info@viessmann-us.com](mailto:info@viessmann-us.com)

Viessmann Manufacturing Company ULC  
750 McMurray Road  
Waterloo, Ontario · N2V 2G5 · Canada  
TechInfo Line 1-888-484-8643  
1-800-387-7373 · Fax (519) 885-0887  
[www.viessmann.ca](http://www.viessmann.ca) · [info@viessmann.ca](mailto:info@viessmann.ca)



Technical information subject to change without notice.

Printed on environmentally friendly  
(recycled and recyclable) paper.