

D5CUHAH

Installation Instructions

Residential Single Zone Heat Pump Ductless System
Sizes 18K - 60K

TABLE OF CONTENTS

PAGE

| | |
|--|----|
| SAFETY CONSIDERATIONS | 2 |
| ACCESSORIES | 9 |
| DIMENSIONS | 10 |
| REFRIGERANT PIPING CONNECTION | 15 |
| REFRIGERANT PIPING CONNECTION INSTRUCTIONS . . . | 16 |
| OUTDOOR UNIT INSTALLATION | 18 |
| WIRING PRECAUTIONS..... | 21 |
| OUTDOOR UNIT WIRING | 22 |
| SPECIFIC WIRING METHODS..... | 23 |
| CROSSOVER WIRING DIAGRAMS..... | 25 |
| WIRING DIAGRAMS..... | 31 |
| OUTDOOR UNIT DIP SWITCH SETTING..... | 35 |
| THERMOSTAT WIRING METHODS | 36 |
| SPECIFICATIONS..... | 40 |
| EVACUATE COIL AND TUBING SYSTEM | 40 |
| ADDING REFRIGERANT | 41 |
| TEST RUN | 41 |
| TROUBLESHOOTING | 42 |
| CROSSOVER START-UP CHECKLIST | 43 |



Fig. 1 —Sizes 18K - 48K



Fig. 2 —Size 60K

NOTES: Read the entire instruction manual before starting the installation.

Images are for illustration purposes only. Actual models may differ slightly.

SAFETY CONSIDERATIONS

Installing, starting up, and servicing air-conditioning equipment can be hazardous due to system pressures, electrical components, and equipment location (roofs, elevated structures, etc.).

Only trained, qualified installers and service mechanics should install, start-up, and service this equipment.

Untrained personnel can perform basic maintenance functions such as coil cleaning. All other operations should be performed by trained service personnel.

When working on the equipment, observe precautions in the literature and on tags, stickers, and labels attached to the equipment.

Follow all safety codes. Wear safety glasses and work gloves. Keep a quenching cloth and fire extinguisher nearby when brazing. Use care in handling, rigging, and setting bulky equipment.

Read these instructions thoroughly and follow all warnings or cautions included in literature and attached to the unit. Consult local building codes and National Electrical Code (NEC) for special requirements. Recognize safety information.

This is the safety-alert symbol

When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury. Understand these signal words: **DANGER**, **WARNING**, and **CAUTION**. These words are used with the safety-alert symbol.

DANGER identifies the most serious hazards which will result in severe personal injury or death.

WARNING signifies hazards which could result in personal injury or death.

CAUTION is used to identify unsafe practices which may result in minor personal injury or product and property damage.

NOTE is used to highlight suggestions which will result in enhanced installation, reliability, or operation.



WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Before installing, modifying, or servicing system, the main electrical disconnect switch must be in the OFF position. There may be more than 1 disconnect switch. Lock out and tag switch with a suitable warning label.



WARNING



EXPLOSION HAZARD

Failure to follow this warning could result in personal injury or death.

Before installing, modifying, or servicing system, the main electrical disconnect switch must be in the OFF position. There may be more than 1 disconnect switch. Lock out and tag switch with a suitable warning label.



CAUTION

EQUIPMENT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage or improper operation.

Do not bury more than 36 in. (914 mm) of refrigerant pipe in the ground. If any section of pipe is buried, there must be a 6 in. (152 mm) vertical rise to the valve connections on the outdoor units. If more than the recommended length is buried, refrigerant may migrate to the cooler buried section during extended periods of system shutdown. This causes refrigerant slugging and could possibly damage the compressor at start-up.



WARNING

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.



WARNING

Only use the specified wire. If the wire is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. The product must be properly grounded at the time of installation, or electric shock may occur.

For all electrical work, follow all local and national wiring standards, regulations, and the Installation Manual. Connect the cables tightly, and clamp them securely to prevent external forces from damaging the terminal. Improper electrical connections can overheat and cause fire, and may also cause shock. All electrical connections must be made according to the Electrical Connection Diagram located on the panels of the indoor and outdoor units.

All wiring must be properly arranged to ensure that the control board cover can close properly. If the control board cover is not closed properly, it can lead to corrosion and cause the connection points on the terminal to heat up, catch fire, or cause electrical shock.

Disconnection must be incorporated in the fixed wiring in accordance with NEC, CSA, and Local Codes. Do not share the electrical outlet with other appliances. Improper or insufficient power supply can cause fire or electric shock.

If connecting power to fixed wiring, an all-pole disconnection device which has at least 3mm clearances in all poles, and have a leakage current that may exceed 10mA, the residual current device (RCD) having a rated residual operating current not exceeding

**WARNING**

Turn off the unit and disconnect the power before performing any installation or repairing. Failure to do so can cause electric shock.

Installation must be performed by an authorized dealer or specialist. Defective installation can cause water leakage, electrical shock, or fire.

Installation must be performed according to the installation instructions. Improper installation can cause water leakage, electrical shock, or fire.

Contact an authorized service technician for repair or maintenance of this unit. This appliance shall be installed in accordance with national wiring regulations. Only use the included accessories, parts, and specified parts for installation. Using non-standard parts can cause water leakage, electrical shock, fire, and can cause the unit to fail.

Install the unit in a firm location that can support the unit's weight. If the chosen location cannot support the unit's weight, or the installation is not done properly, the unit may drop and cause serious injury and damage.

Install drainage piping according to the instructions in this manual. Improper drainage may cause water damage to your home and property.

For units that have an auxiliary electric heater, do not install the unit within 3 feet (1 meter) of any combustible materials.

If combustible gas accumulates around the unit, it may cause fire.

Do not turn on the power until all work has been completed.

When moving or relocating the unit, consult experienced service technicians for disconnection and re-installation of the unit.

How to install the appliance to its support, please read the information for details in "indoor unit installation" and "outdoor unit installation" sections.

NOTE: The air conditioner's circuit board (PCB) is designed with a fuse to provide overcurrent protection. The specifications of the fuse are printed on the circuit board, for example: T3.15AL/250VAC, T5AL/250VAC, T3.15A/250VAC, T5A/250VAC, T20A/250VAC, T30A/250VAC, etc.

NOTE: Only the blast-proof ceramic fuse can be used.

Table 1 lists the units covered in this document.

Table 1 — Unit Sizes

| SYSTEM TONS | BTUH | VOLTAGE-PHASE | OUTDOOR MODEL |
|-------------|--------|---------------|---------------|
| 1.50 | 18,000 | 208/230V-1 | D5CUHAH18AAK |
| 2.00 | 24,000 | | D5CUHAH24AAK |
| 2.50 | 30,000 | | D5CUHAH30AAK |
| 3.00 | 36,000 | | D5CUHAH36AAK |
| 4.00 | 48,000 | | D5CUHAH48AAK |
| 5.00 | 60,000 | | D5CUHAH60AAK |

**WARNING****FOR FLAMMABLE REFRIGERANTS**

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).

Do not pierce or burn. Be aware that refrigerants may not contain an odor.

**WARNING****PERSONAL INJURY AND PROPERTY DAMAGE HAZARD**

For continued performance, reliability, and safety, the only approved accessories and replacement parts are those specified by the equipment manufacturer. The use of non-manufacturer approved parts and accessories could invalidate the equipment limited warranty and result in fire risk, equipment malfunction, and failure. Review the manufacturer's instructions and replacement parts catalogs available from your equipment supplier.

WARNING - RISK OF FIRE DUE TO FLAMMABLE REFRIGERANT USED. FOLLOW HANDLING INSTRUCTIONS CAREFULLY IN COMPLIANCE WITH NATIONAL REGULATIONS.

R-454B



Refrigerant
Safety Group
A2L

R-454B

NOTE: Risk of Fire. Flammable refrigerant used. To be repaired only by trained service personnel. Do not puncture refrigerant tubing.

Table 2 — A (min)

Ho, release height ft (m)

| MC or Mrel lbs (kgs) | ≤ 7.2 (2.2) | 7.5 (2.3) | 7.9 (2.4) | 8.5 (2.6) | 9.2 (2.8) | 9.8 (3.0) |
|--------------------------|----------------|-------------|-------------|-------------|-------------|-------------|
| | ≤ 3.91 (1.776) | 12 (1.10) | | | | |
| 4.0 (1.8) | 60 (5.53) | 57 (5.29) | 55 (5.07) | 50 (4.68) | 47 (4.34) | 44 (4.05) |
| 4.4 (2.0) | 66 (6.14) | 63 (5.88) | 61 (5.63) | 56 (5.2) | 52 (4.83) | 48 (4.5) |
| 4.9 (2.2) | 73 (6.76) | 70 (6.46) | 67 (6.19) | 62 (5.72) | 57 (5.31) | 53 (4.95) |
| 5.3 (2.4) | 79 (7.37) | 76 (7.05) | 73 (6.76) | 67 (6.24) | 62 (5.79) | 58 (5.41) |
| 5.7 (2.6) | 86 (7.99) | 82 (7.64) | 79 (7.32) | 73 (6.76) | 68 (6.27) | 63 (5.86) |
| 6.2 (2.8) | 93 (8.6) | 89 (8.23) | 85 (7.88) | 78 (7.28) | 73 (6.76) | 68 (6.31) |
| 6.6 (3.0) | 99 (9.21) | 95 (8.81) | 91 (8.45) | 84 (7.8) | 78 (7.24) | 73 (6.76) |
| 7.1 (3.2) | 106 (9.83) | 101 (9.4) | 97 (9.01) | 90 (8.32) | 83 (7.72) | 78 (7.21) |
| 7.5 (3.4) | 112 (10.44) | 108 (9.99) | 103 (9.57) | 95 (8.84) | 88 (8.2) | 82 (7.66) |
| 7.9 (3.6) | 119 (11.06) | 114 (10.58) | 109 (10.14) | 101 (9.36) | 94 (8.69) | 87 (8.11) |
| 8.4 (3.8) | 126 (11.67) | 120 (11.16) | 115 (10.7) | 106 (9.88) | 99 (9.17) | 92 (8.56) |
| 8.8 (4.0) | 132 (12.29) | 126 (11.75) | 121 (11.26) | 112 (10.4) | 104 (9.65) | 97 (9.01) |
| 9.3 (4.2) | 139 (12.9) | 133 (12.34) | 127 (11.82) | 117 (10.91) | 109 (10.14) | 102 (9.46) |
| 9.7 (4.4) | 145 (13.51) | 139 (12.93) | 133 (12.39) | 123 (11.43) | 114 (10.62) | 107 (9.91) |
| 10.1 (4.6) | 152 (14.13) | 145 (13.51) | 139 (12.95) | 129 (11.95) | 119 (11.1) | 112 (10.36) |
| 10.6 (4.8) | 159 (14.74) | 152 (14.1) | 145 (13.51) | 134 (12.47) | 125 (11.58) | 116 (10.81) |
| 11 (5.0) | 165 (15.36) | 158 (14.69) | 152 (14.08) | 140 (12.99) | 130 (12.07) | 121 (11.26) |
| 11.5 (5.2) | 172 (15.97) | 164 (15.28) | 158 (14.64) | 145 (13.51) | 135 (12.55) | 126 (11.71) |
| 11.9 (5.4) | 179 (16.58) | 171 (15.86) | 164 (15.2) | 151 (14.03) | 140 (13.03) | 131 (12.16) |
| 12.3 (5.6) | 185 (17.2) | 177 (16.45) | 170 (15.77) | 157 (14.55) | 145 (13.51) | 136 (12.61) |
| 12.8 (5.8) | 192 (17.81) | 183 (17.04) | 176 (16.33) | 162 (15.07) | 151 (14) | 141 (13.06) |
| 13.2 (6.0) | 198 (18.43) | 190 (17.63) | 182 (16.89) | 168 (15.59) | 156 (14.48) | 145 (13.51) |
| 13.7 (6.2) | 205 (19.04) | 196 (18.21) | 188 (17.45) | 173 (16.11) | 161 (14.96) | 150 (13.96) |
| 14.1 (6.4) | 212 (19.66) | 202 (18.8) | 194 (18.02) | 179 (16.63) | 166 (15.44) | 155 (14.41) |
| 14.6 (6.6) | 218 (20.27) | 209 (19.39) | 200 (18.58) | 185 (17.15) | 171 (15.93) | 160 (14.86) |
| 15 (6.8) | 225 (20.88) | 215 (19.98) | 206 (19.14) | 190 (17.67) | 177 (16.41) | 165 (15.32) |
| 15.4 (7.0) | 231 (21.5) | 221 (20.56) | 212 (19.71) | 196 (18.19) | 182 (16.89) | 170 (15.77) |
| 15.9 (7.2) | 238 (22.11) | 228 (21.15) | 218 (20.27) | 201 (18.71) | 187 (17.37) | 175 (16.22) |

Amin is the required minimum room area in ft²/m².**mc** is the actual refrigerant charge in the system in lbs (kg).**mREL** is the refrigerant releasable charge in lbs (kg).**hinst** is the height of the bottom of the unit relative to the floor of the room after installation.**Ho** is the vertical distance in feet (meters) from the floor to the point of release when the appliance is installed.**Ho** release height = **hinst**, install height**WARNING**

The minimum room area or minimum room area of conditioned space is based on releasable charge or total system refrigerant charge.

For R-454B Refrigerant Charge Amount and Minimum Room Area:

The indoor and outdoor units are designed to be used together. Please check the unit you purchased: The height of the room cannot be less than 7.3 feet / 2.2 meters; and the minimum room area of operating or storage should be specified in Table 2.

**WARNING****PRIOR TO INSTALLATION**

Before installing the indoor unit, ensure the compatibility with the outdoor unit using the product data as a reference. It is also necessary to confirm the proper application of the equipment and to perform a heat load calculation for proper sizing.

1. Installation (where refrigerant pipes are allowed)

- Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
- Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- That the installation of pipe-work shall be kept to a minimum.
- That pipe-work shall be protected from physical damage.
- Where refrigerant pipes shall be compliance with national gas regulations.
- That mechanical connections shall be accessible for maintenance purposes.
- Be more careful that foreign matter (oil, water, etc) does not enter the piping. Also, when storing the piping, securely seal the opening by pinching, taping, etc.
- All working procedure that effects safety means shall only be carried by competent persons.
- Appliance shall be stored in a well ventilated area where the room size corresponds to the room area as specific for operation.
- Joints shall be tested with detection equipment with a capability of 1/8 oz (5grams)/year of refrigerant or better, with the equipment in standstill and under operation or under a pressure of at least these standstill or operation conditions after installation.
- In cases that require mechanical ventilation, ventilation openings shall be kept clear of obstruction.
- LEAK DETECTION SYSTEM** installed. Unit must be powered except for service. For the unit with refrigerant sensor, when the refrigerant sensor detects refrigerant leakage, the indoor unit will display a error code and emit a buzzing sound, the compressor of outdoor unit will immediately stop, and the indoor fan will start running. The service life of the refrigerant sensor is 15 years. When the refrigerant sensor malfunctions, the indoor unit will display the error code FHCC. The refrigerant sensor can not be repaired and can only be replaced by the manufacture. It shall only be replaced with the sensor specified by the manufacture.

2. When a FLAMMABLE REFRIGERANT is used

The requirements for installation space of appliance and/or ventilation requirements are determined according to:

- the mass charge amount (M) used in the appliance,
- the installation location,
- the type of ventilation of the location or of the appliance.
- piping material, pipe routing, and installation shall include protection from physical damage in operation and service, and be in compliance with national and local codes and standards, such as ASHRAE 15 or CSA B52. All field joints shall be accessible for inspection prior to being covered or enclosed.
- that protection devices, piping, and fittings shall be protected as far as possible against adverse environmental effects, for example, the danger of water collecting and freezing in relief pipes or the accumulation of dirt and debris;
- that piping in refrigeration systems shall be so designed and installed to minimize the likelihood of hydraulic shock damaging the system;
- that steel pipes and components shall be protected against corrosion with a rustproof coating before applying any insulation;
- that precautions shall be taken to avoid excessive vibration or pulsation;
- the minimum floor area of the room shall be mentioned in the form of a table or a single figure without reference to a formula;

- after completion of field piping for split systems, the field pipework shall be pressure tested with an inert gas and then vacuum tested prior to refrigerant charging, according to the following requirements:
 - The minimum test pressure for the low side of the system shall be the low side design pressure and the minimum test pressure for the high side of the system shall be the high side design pressure, unless the high side of the system cannot be isolated from the low side of the system in which case the entire system shall be pressure tested to the low side design pressure.
 - The test pressure after removal of pressure source shall be maintained for at least 1 hour with no decrease of pressure indicated by the test gauge with test gauge resolution not exceeding 5% of the test pressure.
 - During the evacuation test, after achieving a vacuum level specified in the manual or less, the refrigeration system shall be isolated from the vacuum pump and the pressure shall not rise above 1/2 inch within 10 min. The vacuum pressure level shall be specified in the manual, and shall be the lessor of 1/4 inch or the value required for compliance with national and local codes and standards, which may vary between residential, commercial, and industrial buildings.
- Field-made refrigerant joints indoors shall be tightness tested according to the following requirements: The test method shall have a sensitivity of 1/8 oz (5grams) per year of refrigerant or better under a pressure of at least 125% of the maximum allowable pressure. No leak shall be detected.

3. Qualification of Workers

Any maintenance, service and repair operations must be performed by skilled and authorized personnel. Every working procedure that effects safety means shall only be carried out by competent persons that joined the training and achieved competence should be documented by a certificate. The training of these procedures is carried out by national training organizations or manufacturers that are accredited to teach the relevant national competency standards that may be set in legislation. Examples for such working procedures are:

- breaking into the refrigerating circuit;
- opening of sealed components;
- opening of ventilated enclosures.

4. Checks to the area

Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the refrigerating system, the following precautions shall be complied with prior to conducting work on the system.

5. Work procedure

Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapor being present while the work is being performed.

6. General work area

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. work in confined spaces shall be avoided.

7. Checking for presence of refrigerant

The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants, i.e. no sparking, adequately sealed or intrinsically safe.

8. Presence of fire extinguisher

If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry power or CO2 fire extinguisher adjacent to the charging area.

9. No ignition sources

No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.

10. Ventilated area

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

11. Checks to the refrigeration equipment

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using FLAMMABLE REFRIGERANTS:

- the actual refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed;
- the ventilation machinery and outlets are operating adequately and are not obstructed;
- if an indirect refrigerating circuit is being used, the secondary circuits shall be checked for the presence of refrigerant;
- marking to the equipment continues to be visible and legible, marking and signs that are illegible shall be corrected;
- refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

12. Checks to electrical devices

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, and adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised. **Initial safety checks shall include:**

- that capacitors are discharged: this shall be done in a safe manner to avoid the possibility of sparking
- that there are no live electrical components and exposed wiring while charging, recovering, or purging the system;
- that there is continuity of earth bonding.

13. Cabling

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

14. Detection of flammable refrigerants

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

The following leak detection methods are deemed acceptable for refrigerant systems. Electronic leak detectors may be used to detect refrigerant leaks but, in the case of FLAMMABLE REFRIGERANTS, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed. Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

NOTE: Examples of leak detection fluids are:

- bubble method,
- fluorescent method agents.

If a leak is suspected, all naked flames shall be removed/extinguished.

If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. See the following instructions of removal of refrigerant.

15. Removal and evacuation

When breaking into the refrigerant circuit to make repairs - or for any other purpose conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed, since flammability is a consideration.

The following procedure shall be adhered to:

- safely remove refrigerant following local and national regulations
- evacuate
- purge the circuit with inert gas (optional for A2L)
- evacuate (optional for A2L)
- continuously flush or purge with inert gas when using flame to open circuit
- open the circuit

The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems.

For appliances containing flammable refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum (optional for A2L). This process shall be repeated until no refrigerant is within the system (optional for A2L). When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.

The outlet for the vacuum pump shall not be close to any potential ignition sources, and ventilation shall be available.

16. Charging procedures

In addition to conventional charging procedures, the following requirements shall be followed:

Work shall be undertaken with appropriate tools only (In case of uncertainty, consult the manufacturer of the tools for use with flammable refrigerants).

Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.

Cylinders shall be kept in an appropriate position.

Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.

Label the system when charging is complete (if not already).

Extreme care shall be taken not to overfill the refrigeration system.

Prior to recharging the system it shall be pressure tested with oxygen free nitrogen (OFN). The system shall be leak tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

17. Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.

- a. Become familiar with the equipment and its operation.
- b. Isolate system electrically
- c. Before attempting the procedure ensure that:
 - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - all personal protective equipment is available and being used correctly;
 - the recovery process is supervised at all times by a competent person; recovery equipment and cylinders conform to the appropriate standards.
- d. Pump down refrigerant system, if possible.
- e. If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f. Make sure that cylinder is situated on the scales before recovery takes place.
- g. Start the recovery machine and operate in accordance with instructions.
- h. Do not overfill cylinders (no more than 80 % volume liquid charge)
- i. Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j. When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k. Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

18. Labeling

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing FLAMMABLE REFRIGERANTS, ensure that there are labels on the equipment stating the equipment contains FLAMMABLE REFRIGERANT.

19. Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labeled for that refrigerant (i. e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and

associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of the flammable refrigerant. If in doubt? the manufacturer should be consulted. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition.

The recovered refrigerant shall be processed according to local legislation in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The compressor body shall not be heated by an open flame or other ignition sources to accelerate this process. When oil is drained from a system, it shall be carried out safely.

20. Unventilated areas

For appliances containing more than for any refrigerating circuit, the manual shall include a statement advising that an unventilated area where the appliance using FLAMMABLE REFRIGERANTS is installed shall be so constructed that should any refrigerant leak, it will not stagnate so as to create a fire or explosion hazard. This shall include:

- a warning that if appliances with A2L REFRIGERANTS connected via an air duct system to one or more rooms are installed in a room with an area less than $>A_{min}$ as determined in Clause GG.2, that room shall be without continuously operating open flames (for example an operating gas appliance) or other POTENTIAL IGNITION SOURCES (for example an operating electric heater, hot surfaces). A flame-producing device may be installed in the same space if the device is provided with an effective flame arrest;
- for appliances using A2L REFRIGERANTS connected via an air duct system to one or more rooms, a warning with the substance of the following: "Auxiliary devices which may be a POTENTIAL IGNITION SOURCE shall not be installed in the duct work. Examples of such POTENTIAL IGNITION SOURCES are hot surfaces with a temperature exceeding X °C and electric switching devices". NOTE X is the maximum allowable surface temperature as defined in 22.117. The manufacturer should specify other potential continuously operating sources known to cause ignition of the refrigerant used. The appliance shall be stored so as to prevent mechanical damage from occurring.
- for appliances using A2L refrigerants connected via an air duct system to one or more rooms, a warning that only auxiliary devices approved by the appliance manufacturer or declared suitable with the refrigerant shall be installed in connecting ductwork. The manufacturer shall list in the instructions all approved auxiliary devices by manufacturer and model number for use with the specific appliance, if those devices have a potential to become an ignition source.
- a warning that if appliances connected via an air duct system to one or more rooms with A2L REFRIGERANTS are installed in a room with an area less than $4m^3$ as determined in Clause GG.2. or installed in a room with an EFFECTIVE DISPERSAL VOLUME VED less than the minimum as determined by Clause 101.DVN.8, that room shall be without continuously operating open flames (e.g. an operating gas appliance) or other POTENTIAL IGNITION SOURCES (for e.g. an operating electric heater, hot surfaces). A flame-producing device may be installed in the same space if the device is provided with an effective flame arrest.
- for REFRIGERANT DETECTION SYSTEMS, the function and operation and required servicing measures;

- for LIMITED LIFE REFRIGERANT SENSORS Used in REFRIGERANT DETECTION SYSTEMS, the specified end-of-life and replacement instructions;
- REFRIGERANT SENSORS for REFRIGERANT DETECTION SYSTEMS Shall Only be replaced with sensors specified by the appliance manufacture; and instructions to verify actuation of mitigation actions per Annex GG or Annex 101.DVN as applicable.

For appliances using FLAMMABLE REFRIGERANTS with safety features that depend upon the proper function of a leak detection system used for leak mitigation, the instructions and unit markings shall contain the substance of the following:

"LEAK DETECTION SYSTEM installed. Unit must be powered except for service."

If any remote located REFRIGERANT SENSOR is employed to detect leaked refrigerant, such a remote located REFRIGERANT SENSOR shall also apply to this marking or be accompanied by such instructions.

21. Transportation, marking and storage for units that employ flammable refrigerants

a. General

The following information is provided for units that employ FLAMMABLE REFRIGERANTS.

b. Transport of equipment containing flammable refrigerants

Attention is drawn to the fact that additional transportation regulations may exist with respect to equipment containing flammable gas. The maximum number of pieces of equipment or the configuration of the equipment permitted to be transported together will be determined by the applicable transport regulations.

c. Marking of equipment using signs

Signs for similar appliances used in a work area are generally addressed by local regulations and give the minimum requirements for the provision of safety and/or health signs for a work location.

All required signs are to be maintained and employers should ensure that employees receive suitable and sufficient instruction and training on the meaning of appropriate safety signs and the actions that need to be taken in connection with these signs.

The effectiveness of signs should not be diminished by too many signs being placed together.

Any pictograms used should be as simple as possible and contain only essential details.

d. Disposal of equipment using flammable refrigerants

See national regulations.

e. Storage of equipment/appliances





The storage of the appliance should be in accordance with the applicable regulations or instructions, whichever is more stringent.

f. Storage of packed (unsold) equipment

Storage package protection should be constructed in such a way that mechanical damage to the equipment inside the package will not cause a leak of the REFRIGERANT CHARGE.

The maximum number of pieces of equipment permitted to be stored together will be determined by local regulations.





Table 3 — Symbols displayed on the indoor unit or outdoor unit

| | | |
|---|----------------|---|
|  | WARNING | This symbol shows that this appliance used a flammable refrigerant. If the refrigerant is leaked and exposed to an external ignition source, there is a risk of fire. |
|  | CAUTION | This symbol shows that the operation manual should be read carefully. |
|  | CAUTION | This symbol shows that a service personnel should be handling this equipment with reference to the installation manual. |
|  | CAUTION | This symbol shows that information is available such as the operating manual or installation manual. |

ACCESSORIES

The system is shipped with the following accessories. Use all of the installation parts and accessories to install the system. Improper installation may result in water leakage, electrical shock and fire, or cause the equipment to fail. Keep the installation manual in a safe place and do not discard any other accessories until the installation work has been completed.

Table 4 — Accessories

| NAME | IMAGE | QUANTITY |
|--|---|----------|
| Drain Fitting |  | 1 |
| Gasket NOTE: Sizes 48K and 60K will not require the gasket. |  | 1 |
| Flare-to braze adapter |  | 2 |
| 5/8 flare→3/4 flare adapter (For 18K Regular Heat Series) |  | 1 |
| 6 Foot Drain Tubing | | 1 |




Fig. 3 — Outdoor Unit

NOTE:

- If the outdoor unit is higher than the indoor unit, prevent rain from flowing into the indoor unit along the connection pipe by making a downward arc in the connection pipe before it enters the wall to the indoor unit. This ensures that rain drips from the connection pipe before it enters the wall.
- Piping and the interconnecting wiring are field supplied.
- Figure 3 is only a sketch. The actual model may differ slightly.

DIMENSIONS

Table 5 — Dimensions and Weights

| System Size | | 18K | 24K | 30K | 36K | 48K | 60K |
|-------------|-----------|-------------|--------------|--------------|--------------|--------------|---------------|
| | | (208/230 V) | (208/230 V) | (208/230 V) | (208/230 V) | (208/230 V) | (208/230 V) |
| Height (H) | in (mm) | 26.50(673) | 26.50(673) | 31.89(810) | 38.39(975) | 38.39(975) | 52.48(1333) |
| Width (W) | in (mm) | 35.04(890) | 35.04(890) | 37.24(946) | 38.58(980) | 38.58(980) | 37.48(952) |
| Depth (D) | in (mm) | 13.46(342) | 13.46(342) | 16.14(410) | 16.34(415) | 16.34(415) | 16.34(415) |
| Weight -Net | lbs. (kg) | 101.41(46) | 102.29(46.4) | 164.02(74.4) | 204.15(92.6) | 201.06(91.2) | 242.95(110.2) |

Dimensions: inches (mm)




Fig. 4 —Sizes 18K / 24K

DIMENSIONS (CONT.)




Fig. 5 —Size 30K

DIMENSIONS (CONT.)





Fig. 6 —Size 36K / 48K

DIMENSIONS (CONT.)



Dimensions: inches (mm)
Fig. 7 —Sizes 60K

DIMENSIONS (CONT.)

The outdoor unit can be anchored to the ground or to a wall-mounted bracket with bolt (M10). Prepare the installation base of the unit according to the dimensions below. For installation of multiple units, see Fig 17.




Fig. 8 —Outdoor Unit Types and Specifications

Table 6 — Dimensions

| Capacity Sizes | Outdoor Unit Dimensions | | | | | | Mounting Dimensions | | | |
|-------------------|-------------------------|-----|----------|------|----------|-----|---------------------|-----|----------|-----|
| | W | | H | | D | | A | | B | |
| | Inch | mm | Inch | mm | Inch | mm | Inch | mm | Inch | mm |
| 18/24 | 35 | 890 | 26-1/2 | 673 | 13-15/32 | 342 | 26-1/8 | 663 | 13-15/16 | 354 |
| 30 | 37-1/4 | 946 | 31-29/32 | 810 | 16-5/32 | 410 | 26-1/2 | 673 | 15-7/8 | 403 |
| 36/48 | 38-19/32 | 980 | 38-3/8 | 975 | 16-11/32 | 415 | 24-1/4 | 616 | 15-5/8 | 397 |
| 60 | 37-1/2 | 952 | 52-1/2 | 1333 | 16-11/32 | 415 | 24-35/36 | 634 | 15-29/32 | 404 |

REFRIGERANT PIPING CONNECTION

SAFETY PRECAUTIONS



WARNING

All field piping must be completed by a licensed technician and must comply with the local and national regulations.

When the air conditioner is installed in a small room, measures must be taken to prevent the refrigerant concentration in the room from exceeding the safety limit in the event of refrigerant leakage. If the refrigerant leaks and its concentration exceeds its proper limit, hazards due to lack of oxygen may result.

When installing the refrigeration system, ensure that air, dust, moisture or foreign substances do not enter the refrigerant circuit. Contamination in the system may cause poor operating capacity, high pressure in the refrigeration cycle, explosion or injury.

Ventilate the area immediately if there is refrigerant leakage during the installation. Leaked refrigerant gas is both toxic and flammable. Ensure there is no refrigerant leakage after completing the installation work.

NOTES ON PIPE LENGTH AND ELEVATION: Ensure that the length of the refrigerant pipe, the number of bends, and the drop height between the indoor and outdoor units meets the requirements shown in the following table:

Table 7 — Max Length and Drop Height Based on Model

| System Size | | 18K | 24K | 30K | 36K | 48K | 60K |
|--|-------------|--------------|-------------|-------------|------------|------------|-------------|
| 208/230V | | | | | | | |
| Min. Piping Length | ft. (m) | 10 (3) | | | | | |
| Standard Piping Length | ft. (m) | 24.6 (7.5) | | | | | |
| Max. outdoor-indoor height difference (OU higher than IU) | ft. (m) | 65.6 (20) | 82 (25) | 82 (25) | 98.4 (30) | 98.4 (30) | 98.4 (30) |
| Max. outdoor-indoor height difference (IU higher than OU) | ft. (m) | 65.6 (20) | 82 (25) | 82 (25) | 98.4 (30) | 98.4 (30) | 98.4 (30) |
| Suction Pipe (size - connection type) | in (mm) | ø3/4" (19) | ø3/4" (19) | ø3/4" (19) | ø3/4" (19) | ø3/4" (19) | ø3/4" (19) |
| Liquid Pipe (size-connection) | in (mm) | ø3/8" (9.52) | | | | | |
| Refrigerant Type | Type | R454B | | | | | |
| Charge Amount | lb. (kg) | 4.63 (2.1) | 4.63 (2.1) | 6.61 (3.0) | 7.94 (3.6) | 8.38 (3.8) | 11.46 (5.2) |
| Additional Refrigerant Charge (when Pipe length > 24.6 ft) | Oz/ft (g/m) | 0.7(65) | 0.7(65) | 0.7(65) | 0.7(65) | 0.7(65) | 0.7(65) |
| Total Maximum Piping Length per system | ft. (m) | 98.42 (30) | 164.04 (50) | 164.04 (50) | 246 (75) | 246 (75) | 246 (75) |

NOTE: To match D5CUHAH30AAK Outdoor with D5FUHAH36XAK, an additional 0.60kg/21.16 oz of refrigerant is required.

NOTE: To match D5CUHAH48AAK Outdoor with D5FUHAH60XAK, an additional 0.65kg/22.93 oz of refrigerant is required.

Table 8 — Pipe Specifications

| Name | Model | Liquid Side | Gas Side | Remarks |
|--------------------------|-------|-----------------|---------------|---|
| Connecting Pipe Assembly | 18K | Ø3/8in(Ø9.52mm) | Ø3/4in(Ø19mm) | Pipes are not included in the accessories and will need to be purchased separately from the local supplier. |
| | 24K | Ø3/8in(Ø9.52mm) | Ø3/4in(Ø19mm) | |
| | 30K | Ø3/8in(Ø9.52mm) | Ø3/4in(Ø19mm) | |
| | 36K | Ø3/8in(Ø9.52mm) | Ø3/4in(Ø19mm) | |
| | 48K | Ø3/8in(Ø9.52mm) | Ø3/4in(Ø19mm) | |
| | 60K | Ø3/8in(Ø9.52mm) | Ø3/4in(Ø19mm) | |

Table 9 — Air Handler Braze Adapter Connection

| Air Handler Unit Model | Air Handler Unit Connection(in.flare) | | Adapter Required at Air Handler Unit(in.flare to braze) | Outdoor Model | Outdoor Unit Connection (in.flare) | | Adapter Required at Outdoor Unit(in.flare to flare or braze) |
|------------------------|---------------------------------------|-----|---|-------------------------|------------------------------------|-----|--|
| 18K-60K | Liquid | 3/8 | 3/8flare→3/8braze | 18K/24K/30K/36K/48K/60K | Liquid | 3/8 | 3/8flare→3/8braze |
| | Gas | 3/4 | 3/4flare→3/4braze | | Gas | 3/4 | 3/8flare→3/8braze |

REFRIGERANT PIPING CONNECTION INSTRUCTIONS



CAUTION

The branching pipe must be installed horizontally. An angle of more than 10° may cause malfunction.

DO NOT install the connecting pipe until both indoor and outdoor units have been installed.

Insulate the gas piping to prevent condensation.

Step 1: Cut Pipes

When preparing refrigerant pipes, take extra care to cut and flare them properly. This ensures efficient operation and minimizes the need for future maintenance.

- Measure the distance between the indoor and outdoor units.
- Using a pipe cutter, cut the pipe a little longer than the measured distance.
- Make sure the pipe is cut at a perfect 90° angle.




Fig. 9 — Pipe Cutting



CAUTION

DO NOT DEFORM PIPE WHILE CUTTING

Be extra careful not to damage, dent, or deform the pipe while cutting. This will drastically reduce the heating efficiency of the unit.

Step 2: Remove Burrs

Burrs can affect the air-tight seal of the refrigerant piping connection. Therefore, they must be completely removed.

- Hold the pipe at a downward angle to prevent burrs from falling into the pipe.
- Using a reamer or deburring tool, remove all burrs from the cut section of the pipe.




Fig. 10 — Deburring Tool

Step 3: Flare Pipe Ends

Proper flaring is essential to achieving an airtight seal.

- After removing the burrs from the cut pipe, seal the ends with PVC tape to prevent foreign materials from entering the pipe.
- Sheath the pipe with insulating material.
- Place factory flare nut on pipe. Make sure they are facing the right direction. Once the ends are flared, it is impossible to put them on or change their direction.




Fig. 11 — Copper pipe and flare nut

- Remove the PVC tape from ends of pipe when ready to perform the flaring work.
- Clamp the flare block on the end of the pipe. The end of the pipe must extend beyond the flare form.




Fig. 12 — Flare Block

- Place the flaring tool onto the form.
- Turn the handle of the flaring tool clockwise until the pipe is fully flared. Flare the pipe in accordance with the dimensions in Table 10.




Fig. 13 — Flare Shape

Table 10 — Piping Extension Beyond Flare Form

| PIPE GAUGE IN (MM) | TIGHTENING TORQUE Ft-lbs (N.m) | | FLARE DIMENSIONS (A) in (mm) | |
|-----------------------|--------------------------------|----------|---------------------------------|-------------|
| | Ft-lbs | N.m | Min. | Max. |
| Ø3/8 (9.52) | 23.6-27.75 | (32-39) | 0.52 (13.2) | 0.53 (13.5) |
| Ø5/8 (16) | 42-52.37 | (57-71) | 0.76 (19.2) | 0.78 (19.7) |
| Ø3/4 (19) | 49.4-74.5 | (67-101) | 0.91 (23.2) | 0.93 (23.7) |

- Remove the flaring tool and flare block, then inspect the end of the pipe for cracks and even flaring.

Step 4: Connect the Pipes

Connect the copper pipes to the indoor unit first, then connect the pipes to the outdoor unit. Connect the low-pressure pipe first, then connect the high pressure pipe.

1. When connecting the flare nuts, apply a thin coat of refrigeration oil to the flared ends of the pipes.
2. Align the center of the two pipes that are being connected.
3. Tighten the flare nut by hand.
4. Using a wrench, grip the nut on the unit tubing.
5. While firmly gripping the nut, use a torque wrench to tighten the flare nut according to the torque specifications in Table 10.
6. **NOTE: Use an adjustable wrench and a torque wrench when connecting or disconnecting pipes to or from the unit.**




Fig. 14 — Torque Wrench and Spanner Wrench

**CAUTION**

Wrap insulation around the piping. Direct contact with the bare piping may result in burns or frostbite. Ensure the pipe is properly connected. Over tightening may damage the bell mouth and under tightening may lead to leakage.

MINIMUM BEND RADIUS

1. Carefully bend the tubing in the middle according to Fig. 15.

**CAUTION**

DO NOT bend the tubing more than 90° or more than three times. Use care when bending pipe, do not kink pipe.

Use appropriate tool



min-radius 3.9in (100mm)

Fig. 15 —Bend Tubing

2. After connecting the copper pipes to the indoor unit, wrap the power cable, signal cable and the piping together with binding tape.

**CAUTION**

DO NOT intertwine signal cable with other wires. While bundling these items together, DO NOT intertwine or cross the signal cable with any other wiring.

OUTDOOR UNIT INSTALLATION



CAUTION

Prior to Installation


Before installing the indoor unit, ensure the compatibility with the outdoor unit using the product data as a reference. It is also necessary to confirm the proper application of the equipment and to perform a heat load calculation for proper sizing.

Before installing the unit, ensure the compatibility with the outdoor unit using the product data as a reference.

NOTE: Install the unit by following local codes and regulations. They may differ between different regions.

SELECT THE INSTALLATION LOCATION OF OUTDOOR UNITS

Choose an appropriate location before installing the outdoor unit. Use the following are standards to help choose an appropriate location for the unit.




- ☒ Firm and solid—the location can support the unit and will not vibrate.




- ☒ Noise from the unit will not disturb other people.




- ☒ Good air circulation and ventilation.



- ☒ Where snowfall is anticipated, take appropriate measures to prevent ice buildup and coil damage.



- ☒ The outdoor unit must be installed on risers of at least 6in(15cm) in height or per local code to get unit above local mean snow fall.



- ☒ Meets all spatial requirements shown in Installation Space Requirements above.

Fig. 16 —Standards for Proper Installation

CLEARANCE





Fig. 17 —Installation of Multiple Units

Table 11 — Rows of Series Installation

| | L | A |
|-------|---------------------|-------------------------|
| L ≤ H | L ≤ 1/2H | 9-7/8in (250mm) or more |
| | 1/2H < L ≤ H | 11-7/8in(300mm) or more |
| L > H | Cannot be installed | |

DO NOT INSTALL UNIT IN THE FOLLOWING LOCATIONS

- Near an obstacle that will block air inlets and outlets.
- In a location that is exposed to large amounts of dust.
- Near animals or plants that will be harmed by hot air discharge.
- Near any source of combustible gas.
- Near a public street, crowded areas, or where noise from the unit will disturb others.



CAUTION

SPECIAL CONSIDERATIONS FOR EXTREME WEATHER

If the unit is exposed to heavy wind:
Install unit so that air outlet fan is at a 90° angle to the direction of the wind. If needed, build a barrier n front of the unit to protect it from extremely heavy winds.

If the unit is frequently exposed to heavy rain or snow:
Build a shelter above the unit to protect it from the rain or snow. Be careful not to obstruct air flow around the unit.

INSTALL DRAIN JOINT (HEAT PUMP UNIT ONLY)

Before bolting the outdoor unit in place, you must install the drain joint at the bottom of the unit.

NOTE: There are two different types of drain joints depending on the type of outdoor unit.

If the drain joint comes with a rubber seal (see A in Fig. 18), perform the following:

1. Fit the rubber seal on the end of the drain joint that will connect to the outdoor unit.
2. Insert the drain joint into the hole in the base pan of the unit.
3. Rotate the drain joint 90° until it clicks in place facing the front of the unit.
4. Connect a drain hose extension (not included) to the drain joint to redirect water from the unit during heating mode..=

If the drain joint does not come with a rubber seal (see B in Fig. 18), perform the following:

1. Insert the drain joint into the hole on the base pan, press firmly to ensure it is properly installed and will not become loose.
2. Connect a drain hose extension (not included) to the drain joint to redirect water from the unit during heating mode.




Fig. 18 —Install Drain Joint



CAUTION

In Cold Climates

In cold climates, make sure that the drain hose is as vertical as possible to ensure swift water drainage. If water drains too slowly, it can freeze in the hose and flood the unit.

DO THE FOLLOWING to install the unit on the ground or on a concrete mounting platform.

1. Mark the positions for four expansion bolts based on dimensions chart.
2. Pre-drill holes for expansion bolts.
3. Place a nut on the end of each expansion bolt.
4. Hammer expansion bolts into the pre-drilled holes.
5. Remove nuts from expansion bolts and place outdoor unit on bolts.
6. Put washer on each expansion bolt, then replace the nuts.
7. Using a wrench, tighten each nut until snug.



WARNING

Wear eye protection at all times when drilling into concrete.

DO THE FOLLOWING to install the unit on a wall-mounted bracket.

1. Mark the position of bracket holes based on dimensions chart.
2. Pre-drill the holes for the expansion bolts.
3. Place a washer and nut on the end of each expansion bolt.
4. Thread expansion bolts through holes in mounting brackets, put mounting brackets in position, and hammer expansion bolts into the wall.
5. Check that the mounting brackets are level.
6. Carefully lift unit and place its mounting feet on brackets.
7. Bolt the unit firmly to the brackets.
8. If allowed, install the unit with rubber isolator pads to reduce vibrations and noise.



CAUTION

Make sure that the wall is made of solid brick, concrete, or of similarly strong material. The wall must be able to support at least four times the weight of the unit.

WIRING PRECAUTIONS



WARNING

READ THE FOLLOWING WARNINGS BEFORE PERFORMING ANY ELECTRICAL WORK.

All wiring must comply with local and national electrical codes, regulations and must be installed by a licensed electrician.

All electrical connections must be made according to the Electrical Connection Diagram located on the panels of the indoor and outdoor units.

If there is a serious safety issue with the power supply, stop work immediately. Explain your reasoning to the client, and refuse to install the unit until the safety issue is properly resolved. Power voltage should be within 90-110% of rated voltage. Insufficient power supply can cause malfunction, electrical shock, or fire.

Installation of an external surge suppressor at the outdoor disconnect is recommended.

Power must be connected, a switch or circuit breaker that disconnects all poles and has a contact separation of at least 1/8in (3mm)

must be incorporated in the fixed wiring. The qualified technician must use an approved

circuit breaker or switch.

Only connect the unit to an individual branch circuit. Do not connect another appliance to that circuit.

Make sure to properly ground the air conditioner. Every wire must be firmly connected. Loose wiring can cause the terminal to overheat, resulting in product malfunction and possible fire.

Do not let wires touch or rest against refrigerant tubing, the compressor, or any moving parts within the unit.

To avoid getting an electric shock, never touch the electrical components soon after the power supply has been turned off. After turning off the power, always wait 10 minutes or more before you touch the electrical components.

Make sure that you do not cross your electrical wiring with your signal wiring. This may cause distortion, interference or possibly damage to circuit boards. Connect the outdoor wires before connecting the indoor wires.



WARNING

Turn off the power to the main system before performing any electrical work.

OUTDOOR UNIT WIRING



WARNING

Turn off the power to the main system before performing any electrical work.

Step 1: Prepare the cable for connection.

1. Choose the right cable size.
2. Using wire strippers, strip the jacket from both ends of the signal cable to reveal approximately 5.9in (150mm) of wire.
3. Strip the insulation from the ends.
4. Stranded wire requires fork terminals or ring terminals to be crimped onto the ends of the wire.

NOTES:

- When connecting the wires, strictly follow the wiring diagram found inside the electrical box cover.
- Choose the cable type according to the local electrical codes and regulations.
- Choose the right cable size according to the Minimum Circuit Ampacity indicated on the nameplate of the unit.

Step 2: Remove the electric cover.

Remove the electric cover of the outdoor unit by loosening the three screws.






Fig. 19 —Remove Electrical Cover

Step 3: Connect the Fork Terminals to the Terminals

1. Match the wire colors/labels with the labels on the terminal block.
2. Firmly screw the u-lug of each wire to its corresponding terminal.




**Fig. 20 —Connect Fork Terminals to Terminals
(Sizes 18K-24K)**



**Fig. 21 —Connect Fork Terminals to Terminals
(Sizes 30K-60K)**

3. Clamp down the cable with the cable clamp.
4. Insulate unused wires with electrical tape. Keep them away from any electrical or metal parts.
5. Reinstall the cover of the electric control box.
6. Remove the wire cover from the unit by loosening the 3 screws.
7. Remove caps on the conduit panel.
8. Mount the conduit tubes (not included) on the conduit panel.
9. Properly connect both the power supply and low voltage lines to the corresponding terminals on the terminal block.
10. Ground the unit in accordance with local codes. Be sure to size each wire allowing several inches longer than the required length for wiring.

**Fig. 22 —Outdoor Unit Wiring****WARNING**

Isolate the power supply leads and communication leads by the strain relief and keep the power supply leads away from the communication leads.

SPECIFIC WIRING METHODS**WARNING**


Refer to the wiring nameplate for the wiring method. Do not connect 24V AC to S1 - S2, as this will damage the system.

SCENARIO 1:

This is the preferred method of control. This allows a 24 volt thermostat to be used with RS485 communication between the indoor and outdoor units. None of the 24 volt terminals in the outdoor unit can be used with this scenario.

- The **B** terminal and **W** terminal should not be used together at the air handler.
- **W** should only be used with a conventional thermostat for the heat demand at the air handler.
- **DS** is a reserve Terminal.

To use a 24V thermostat, Refer to the following wiring:

**Fig. 23 —Scenario 1**

CROSSOVER WIRING DIAGRAMS




Fig. 27 —Single-Stage Furnace with Variable Speed Heat Pump (with Single Speed Airflow)

APPLIES TO:

- 59SU5B / 58SC(0,1)B / 58SB(0,1)B / 59SC2E / 59SC6A / 59SP6B / 58SP0B / 59CU5B / 58CU0B
- 935SB / 830CB / 926SB / 81(0,1)SB / 8(0,1)SB / 912SE / 916SA / 935CB / 820SB
- F95CSU / F80CSU / G95CSU / G80CSU / N96VSN / N80VSL / N96MSN / N92MSN / N80MSN / N95MSU

NOTES:

- Heat pump must have a high pressure switch for dual fuel applications.
- 'O/B' energized on heating.
- Must use dual fuel thermostat for all furnace combinations. Simultaneous heat pump and furnace operation not permitted.
- Refer to indoor unit literature for additional information.
- For dual fuel application, 'W' and 'D' terminal in outdoor unit cannot be used.

NOTE: Reference <https://www.icpeqp.com/AHRIratings/ratings.aspx> for compatible indoor units.

CROSSOVER WIRING DIAGRAMS (CONT.)




Fig. 28 —Single-Stage and Two-Stage Furnace with Variable Speed Heat Pump

APPLIES TO:

- 58SU0B / 59TN6C / 58TN0B / 59TP6C / 58TP0B
- 986TD / 880TB / 926TC / 820TP / 830SB
- F96CTN / G96CTN / F80CTL / G80CTL / G96VTN / F96VTN / F80VTL / G80VTL / N80MSU
- OVL and OVM Oil Furnaces

NOTES:

- Heat pump must have a high pressure switch for dual fuel applications.
- 'O/B' energized on heating.
- Must use dual fuel thermostat for all furnace combinations. Simultaneous heat pump and furnace operation not permitted.
- Refer to indoor unit literature for additional information.

NOTE: Reference <https://www.icpeqp.com/AHRIratings/ratings.aspx> for compatible indoor units.

CROSSOVER WIRING DIAGRAMS (CONT.)




Fig. 29 —Single-Speed Fancoil with Variable Speed Heat Pump (1S Heat) 1

APPLIES TO: FMA5X / FMA5L

NOTES:

- 'O/B' energized on heating.
- Refer to indoor unit literature for additional information.

NOTE: Reference <https://www.icpeqp.com/AHRIratings/ratings.aspx> for compatible indoor units.

CROSSOVER WIRING DIAGRAMS (CONT.)




Fig. 30 —Single-Speed Fancoil with Variable Speed Heat Pump (MS Heat)

APPLIES TO: FJ5

NOTES:

- 'O/B' energized on heating.
- Refer to indoor unit literature for additional information.

NOTE: Reference <https://www.icpeqp.com/AHRIratings/ratings.aspx> for compatible indoor units.

CROSSOVER WIRING DIAGRAMS (CONT.)




Fig. 31 —Single-Speed Fancoil with Variable Speed Heat Pump (1S Heat) 2

APPLIES TO: FM(U,C)5(Z,X)

NOTES:

- 'O/B' energized on heating.
- Refer to indoor unit literature for additional information.

NOTE: Reference <https://www.icpeqp.com/AHRIratings/ratings.aspx> for compatible indoor units.

CROSSOVER WIRING DIAGRAMS (CONT.)




Fig. 32 —Two-Speed Fancoil with Variable Speed Heat Pump (1S Coil)

APPLIES TO: FT5 / FG5 / F55

NOTES:

- 'O/B' energized on heating.
- Refer to indoor unit literature for additional information.

NOTE: Reference <https://www.icpeqp.com/AHR/ratings/ratings.aspx> for compatible indoor units.

WIRING DIAGRAMS




Fig. 33 — Sizes 18K and 24K

Notes:

1. COMP. TOP OLP TEMP. SENSOR and EEV2 are only for 36K hyper heat model.
2. The symbol "-----" indicates the element is optional, the actual shape shall prevail.





Fig. 35 — Sizes 36K and 48K



OUTDOOR UNIT DIP SWITCH SETTING

Press the SW4 button 10S for force defrosting (the SW3 button is not active).

NOTE: Forced defrost should only be used to test defrost. All defrost termination conditions affect the length of time forced defrost is active.




Fig. 37 —Outdoor Unit DIP Switch

| No. | Dial Code | Features | ON | OFF |
|-----|-----------|--|--|---|
| 1 | SW-1 | Function to be defined | N/A | N/A |
| 2 | SW-2 | Communication method code | 24V communication (scenario 3 only) | RS 485 communication (scenarios 1 and 2 only) |
| 3 | SW-3 | Recovery time enhancement (scenario 3 only) | Increases compressor frequency for quicker recovery to set point | Default settings for scenarios 1 and 2 |
| 4 | SW-4 | Enhanced defrosting function (all 3 scenarios) | Enhanced defrosting | Default setting (standard defrost algorithm) |

NOTE: SW4 is the button for forced defrosting, and it is active for all three scenarios.


NOTE: When the SW1-4 is ON, the outdoor unit will have enhanced defrosting function.

If the enhanced defrosting is activated, defrost will be active after 40 minutes of compressor cumulative run time in heat mode.

If standard defrosting is activated, defrost will be active after 90 minutes of compressor cumulative run time in heat mode.

THERMOSTAT WIRING METHODS


NOTE: The following wiring diagram are suitable for the AHU and ODU with 24V thermostat. Any 24 volt connections to the outdoor should only be reserved for Scenario 3 wiring. Scenario's 1 and 2 should use the S1 and S2 terminals at the outdoor unit. failure to observe this could result in damage to system components.



S4-2 Default on, DH function off.
Turn switch off to activate DH
function.

S4-4 Default on, W1 and W2
shorted for single stage Aux heat
operation. Turn off to separate stages.

Fig. 38 —Wiring for 4H and 2C thermostat




S4-2 Default on, DH function off.
Turn switch off to activate DH
function.

S4-4 Default on, W1 and W2
shorted for single stage Aux heat
operation. Turn off to separate stages.

Fig. 39 —Wiring for 3H and 1C thermostat

THERMOSTAT WIRING METHODS (CONT.)



S4-2 Default on, DH function off.
Turn switch off to activate DH
function.

Emergency heating control two groups
of electric heating at the same time

Fig. 40 —Wiring for 3H and 2C thermostat





Fig. 41 —Wiring for 2H and 2C thermostat


THERMOSTAT WIRING METHODS (CONT.)



S4-2 Default on, DH function off.
Turn switch off to activate DH
function.

S4-4 Default on, W1 and W2
shorted for single stage Aux heat
operation. Turn off to separate stages.

Fig. 42 —Wiring for 3H and 2C thermostat



S4-4 Default on, W1 and W2
shorted for single stage Aux heat
operation. Turn off to separate stages.

Fig. 43 —Wiring for 2H and 1C thermostat




Fig. 44 —Wiring for 1H and 1C thermostat




Fig. 45 — Wiring for 1H and 1C thermostat

Control Logic

Table 12 — Indoor Unit Connector

| Connector | Purpose |
|-----------|-------------------------|
| R | 24V power Connection |
| C | Common |
| Y1 | Low Cooling |
| Y2 | High Cooling |
| B | Heating Reversing Valve |
| W | Heating control |
| D | Defrost control |
| L | System Fault Signal |

LED Display

The control displays unit status as well as any active fault codes on the LED display. If the unit is functioning normally, the LED will be blank. When a fault code is active, the display will flash the active fault code. Please refer to the fault code table located in the troubleshooting section of the Service Manual for detailed fault code information.

SPECIFICATIONS

Table 13 — Cooling and Heating Power Specifications

| MODEL (Btu/h) | | 18K | 24K | 30K | 36K | 48K | 60K |
|-----------------|-----------------------|---------------|-----|-------|-----|-----|-----|
| Power (Outdoor) | Phase | 1 Phase | | | | | |
| | Frequency and Voltage | 208/230, 60Hz | | | | | |
| Outdoor Unit | MCA | 16A | 19A | 29.5A | 29A | 38A | 40A |
| | MOP | 20A | 20A | 30A | 30A | 40A | 40A |
| Line Gages | Outdoor-Indoor | 2 | | | | | |
| | Signal Line | 16 | | | | | |
| | Thermostat Signal | --- | | | | | |
| | Line Diameter (AWG) | 18 | | | | | |

EVACUATE COIL AND TUBING SYSTEM



CAUTION

UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage or improper operation.

Never use the system compressor as a vacuum pump.

Refrigerant tubes and the indoor coil should be evacuated using the recommended 1/4 inch deep vacuum method. The alternate triple evacuation method may be used if the procedure outlined below is followed.

NOTE: Always break a vacuum with dry nitrogen.

USING VACUUM PUMP

1. Completely tighten flare nuts A, B, C, D. Connect the manifold gage charge hose to a charge port of the low side service valve (see Fig. 46).
2. Connect the charge hose to vacuum pump.
3. Fully open the low side of manifold gage (see Fig. 47).
4. Start the vacuum pump.
5. Evacuate using either the deep vacuum or triple evacuation method.
6. After evacuation is complete, fully close the low side of manifold gage and stop the vacuum pump operation.
7. The factory charge contained in the outdoor unit is good for up to 25 ft. (8 m) of line length. For refrigerant lines longer than 25 ft. (8 m), add refrigerant, up to the allowable length.
8. Disconnect the charge hose from the charge connection of the low side service valve.
9. Fully open service valves B and A.
10. Securely tighten the service valve caps.




Fig. 46 —Service Valve




Fig. 47 —Manifold

EVACUATION

Evacuation of the system will remove air or nitrogen (non-condensables) as well as moisture. A proper vacuum will assure a tight, dry system before charging with refrigerant. The two methods used to evacuate a system are the deep vacuum method and the triple vacuum method.

DEEP VACUUM METHOD

The deep vacuum method requires a vacuum pump capable of pulling a vacuum of 1/4 inch and a vacuum gauge capable of accurately measuring this vacuum depth. This method is the most positive way of assuring a system is free of air and moisture (see Figure 48).




Fig. 48 —Deep Vacuum Graph

TRIPLE EVACUATION METHOD

The triple evacuation method should be used when vacuum pump is not capable of pumping down to 1/4 inch and system does not contain any liquid water. Refer to Fig. 49 and proceed as follows:

1. Attach refrigeration gauges and evacuate system down to 28 inches of mercury and allow pump to continue operating for an additional 15 minutes.
2. Close service valves and shut off vacuum pump.
3. Connect a nitrogen cylinder and regulator to system and flow nitrogen until system pressure is 2 psig.
4. Close service valve and allow system to stand for 1 hour. During this time, dry nitrogen will be able to diffuse throughout the system absorbing moisture.
5. Repeat this procedure as indicated in Fig. 49. System is now free of any contaminants and water vapor.




Fig. 49 —Triple Evacuation Method

FINAL TUBING CHECK

Check to be certain factory tubing on both the indoor and outdoor unit has not shifted during shipment. Ensure tubes are not rubbing against each other or any sheet metal. Pay close attention to the feeder tubes, making sure wire ties on feeder tubes are secure and tight.

ADDING REFRIGERANT



CAUTION

DO NOT mix refrigerant types.

Some systems require additional charging depending on pipe lengths. In North America, the standard pipe length is 25ft (7.5m). The refrigerant should be charged from the service port on the outdoor unit's low pressure valve. The additional refrigerant to be charged can be calculated using Table 7:

TEST RUN



CAUTION

Failure to perform the test run may result in unit damage, property damage, or personal injury.

BEFORE TEST RUN

A test run must be performed after the entire system has been completely installed. Confirm the following points before performing the test:

- Indoor and outdoor units are properly installed.
- Piping and wiring are properly connected.
- No obstacles near the inlet and outlet of the unit that might cause poor performance or product malfunction.
- Refrigeration system does not leak.
- Drainage system is unimpeded and draining to a safe location.
- Heating insulation is properly installed.
- Grounding wires are properly connected.
- Length of the piping and additional refrigerant capacity have been recorded.
- Power voltage is the correct voltage for the unit.

TEST RUN INSTRUCTIONS

1. Open both the liquid and gas service valves.
2. Turn on the main power switch and allow the unit to warm up.
3. Set the UNIT to COOL mode.
4. For the Indoor Unit:
 - a. Double check to see if the room temperature is being registered correctly.
 - b. Check to see that the drainage system is unimpeded and draining smoothly.
 - c. Ensure there is no vibration or abnormal noise during operation.
5. For the Outdoor Unit
 - a. Check to see if the refrigeration system is leaking.
 - b. Make sure there is no vibration or abnormal noise during operation.
 - c. Ensure the wind, noise, and water generated by the unit do not disturb your neighbors or pose a safety hazard.
6. Drainage Test
 - a. Ensure the drainpipe flows smoothly. New buildings should perform this test before finishing the ceiling.
 - b. Turn on the main power switch and run the unit in COOL mode.
 - c. Check to see that the water is discharged. It may take up to one minute before the unit begins to drain depending on the drainpipe.
 - d. Make sure that there are no leaks in any of the piping.
 - e. Stop the unit. Turn off the main power switch and reinstall the test cover.

NOTE: If the unit malfunctions or does not operate according to your expectations, please refer to the Troubleshooting section of Service Manual before calling customer service.

TROUBLESHOOTING

For ease of service, the systems are equipped with diagnostic code display LEDs on both the indoor and outdoor units. The outdoor diagnostic display consists of two LEDs (Red and Green) on the outdoor unit board and is limited to a few errors.

The indoor diagnostic display is a combination of flashing LEDs on the display panel or the front of the unit. If possible, always check the diagnostic codes displayed on the indoor unit first.

The diagnostic codes displayed on the indoor unit are listed in Table 15.

INDOOR UNIT DIAGNOSTIC GUIDES

Table 15 — Error Codes

| Display | Malfunction and Protection Indication | Display | Malfunction and Protection Indication |
|-------------|--|-------------|---|
| EL01 | IDU and ODU Communication Error | PC08 | ODL Current Protection |
| EC07 | Outdoor DC fan motor speed out of control | PC10 | ODL AC voltage too low protection |
| EC51 | ODU EEPROM error | PC11 | ODL DC bus voltage too high protection |
| EC52 | Condenser coil temperature sensor (T3) error | PC12 | ODL DC bus voltage too low protection |
| EC53 | ODU temperature sensor (T4) error | PC30 | System pressure overload protection |
| EC54 | ODU exhaust temperature sensor error | PC31 | System pressure too low protection |
| EC55 | ODU IPM module temperature sensor error | PC40 | Communication failure between outdoor main control chip and the driver chip |
| EC56 | ODU T2B sensor | PC41 | Compressor current sampling circuit failure |
| EH00 | IDU EEPROM error | PC42 | Compressor starting failure |
| EH0A | Indoor EEPROM Parameter error | PC43 | Compressor lost phrase protection |
| EHC1 | Refrigerant Sensor detects a leak | PC44 | Compressor zero speed protection |
| EHC2 | Working condition of the refrigerant sensor is out of range and a leak is detected | PC45 | Voltage drop |
| EHC3 | Working condition of the refrigerant sensor is out of range | PC46 | Compressor speed out of control |
| EH02 | Zero-crossing signal detection error | PC49 | Compressor over current error |
| EH03 | Indoor fan motor speed is out of control | PC0A | Condenser high temperature protection |
| EH31 | Protection for low DC bus voltage of the external fan | PC0F | PFC failure |
| EH32 | Protection for high DC bus voltage of the external fan | PC0L | Outdoor low temperature protection |
| EH60 | IDU ENV temperature T1 sensor error | PH09 | IDU anti-cold wind stop machine |
| EH61 | IDU pipe temperature T2 sensor error | PH90 | Evaporator high temperature protection |
| EH0b | IDU PCB and display communication error | PH91 | Evaporator low temperature protection |
| FH0C | Indoor Unit humidity sensor malfunction | LC01 | Condenser high temperature frequency limited (L1) |
| FHCC | Refrigerant Sensor Error | LC02 | Compressor Discharge Pipe High temperature frequency limited (L2) |
| EL01 | IDU and ODU Communication Error | LC03 | Current frequency limited (L3) |
| EL0C | System leaks refrigerant | LC05 | Voltage frequency limited (L5) |
| FH0P | Wireless Module Self-Test Failure | LC06 | IPM module temperature frequency limited |
| FL09 | New and old platform mismatch failure | LH00 | Evaporator temperature frequency limited (L0) |
| PC00 | ODU IPM Protection | LH07 | Remote Control frequency limitation in effect |
| PC01 | ODU Voltage Protection | | |
| PC02 | Compressor top temperature (IPM module temperature protection) | --- | Mode conflict fault |
| | | nA | No fault or protection |
| PC03 | System Pressure Protection | | |

Table 16 — Leak Detection Error Codes

| | |
|-------------|--|
| EHC1 | Refrigerant Sensor detects a leak |
| EHC2 | Working condition of the refrigerant sensor is out of range and a leak is detected |

If you receive EHC1 or EHC2 codes, call a technician as soon as possible (See Table 16). No need to panic, the unit goes into TURBO mode until the error code is cleared. There is a “beep” noise coming from the indoor unit, which is normal in this case.

For additional diagnostic information, refer to the Service Manual.

CROSSOVER START-UP CHECKLIST

Installation Data

Site Address: _____

City: _____ State: _____ Zip Code: _____

Installing Contractor: _____ Contractor Contact #: () _____ - _____

Job Name: _____ Start-up Date: _____

Distributor: _____

System Details

| Units | Model No. | Serial No. | Controller |
|---------------|-----------|------------|------------|
| OUTDOOR UNIT | | | |
| INDOOR UNIT A | | | |

Wiring Electrical

Wire Size and Type Used? AWG: _____ TYPE: _____

Are there any breaks, splices, wire nuts or butt connectors between the outdoor unit and the indoor door unit? YES: _____ NO: _____

Was the wiring from the outdoor unit port to the correct indoor unit verified? YES: _____ NO: _____

REMARKS: _____

Voltage Check

Wiring: Single zone _____

| | | | | | | |
|--|-------------|--|---|-------------|--|---|
| Outdoor Unit Disconnect | 1(L1):GND | | Outdoor Unit Terminal Block | 1(L1):GND | | NOTES: _____ _____ _____ _____ |
| | 2(L2):GND | | | 2(L2):GND | | |
| | 1(L1):L2(2) | | | 1(L1):2(L2) | | |
| Indoor Unit Voltage Check @ Outdoor Unit | 1(L1):GND | | Indoor Unit Voltage Check @ Indoor Unit | 1(L1):GND | | NOTES: _____ _____ _____ _____ |
| | 2(L2):GND | | | 2(L2):GND | | |
| | 1(L1):2(L2) | | | 1(L1):2(L2) | | |
| | 2(L2):3(S) | | | 2(L2):3(S) | | |

Crossover Start-Up Checklist (CONT)

Piping

Leak Check:

System held 500 psig (max. 550psi) for a minimum of 30 minutes using dry nitrogen. YES: _____ NO: _____

Evacuation Method:

- Was the Triple Evacuation Method used as outlined in the installation manual? YES: _____ NO: _____
- Was the Deep Vacuum Method used as outlined in the installation manual? YES: _____ NO: _____
- Did the System Hold 500 microns for 1 hour? YES: _____ NO: _____
- Does the line set match the diameter of the evaporator connections? YES: _____ NO: _____

Single Zone Piping:

Has the liquid pipe length been measured and the additional charge calculated? Size: _____ Length: _____ Charge: _____

| |
|---------------|
| Notes: |
| |
| |
| |
| |

| PORT | LIQUID SIZE | | SUCTION SIZE | | LENGTH | CHARGE | NOTES: |
|------|-------------|--|--------------|--|--------|--------|--------|
| A | | | | | | | |

Performance Check

For 1:1 Single Zone Systems: Adjust the set-point to create an operational call for the desired testing operation. Allow the system to run for a minimum of 10 min. and record the following details:

(Operational data recorded on applicable heads with the wireless remote controller's Point Check function)

| UNIT | SET-POINT | MODE | T1 | T2 | T3 | T4 | Tb | Tp | Th | LA/Lr |
|------|-----------|------|----|----|----|----|----|----|----|-------|
| A | | | | | | | | | | |

Error Codes

Were there any error codes present at start-up? YES: _____ NO: _____

| | | |
|--------------------------|--|--------|
| Indoor Unit Error Code: | | Notes: |
| Outdoor Unit Error Code: | | |
| Wall Controller: | | |
| 24V Interface: | | |

Comments:
