

Podium computer keyboard



If the keyboard is acting strangely. Typing a “/” instead of “0”. Please turn off num lock by pushing the “Fn” and “num lock” keys.