


USB Voice Recorder

User's Guide

The USB flash drive is like a standard USB flash drive concealing a long-range voice-optimized microphone, voice-activated digital recorder, and 8 GB of memory. This small compact USB voice recorder is activated by switching the right-side button on. The 8GB internal storage stores up to 160 hours of audio recording. Can last up to 4 hours on a single charge. Record Audio of up to 20 feet.

In the Box: USB Voice Recorder



Getting Started

In order to charge the USB voice recorder, you will need to remove the cover cap to the USB and then insert it into a USB port adapter or PC for charging. Charge the device for at least 3 hours for a full charge. The LED on the USB recorder will remain solid red while charging.

After the device is fully charged the LED light will turn to Blue. The light will remain solid Blue.

Once the device is powered on, the LED will flash, and then the device will begin to record audio via the built-in Microphone.

To review and hear the recorded audio, you will need to insert the USB Voice recorder into a PC USB port. A pop-up folder will appear. You will then double-click the file to see all recorded files. You can then select which file you would like to listen to.

It is recommended to download the free [VLC Media Player](#) to play your audio files, this will prevent any formatting issues so that you can play and listen to your recorded files.

