


LEG EXTENSION



S3010 ASSEMBLY INSTRUCTION LEG EXTENSION

CONTENTS

01/IMPORTANT NOTICE

02/ ASSEMBLY PROCEDURE AND BILL OF MATERIALS

03/PRODUCT DESCRIPTION

04/PRODUCT PARAMETER

05/MAINTENANCE GUIDELINE

06/TROUBLESHOOTING

07/WARRANTY INSTRUCTION

01/IMPORTANT NOTICE

Thank you for choosing our machine, proper use of the machine is important to keep you convenient and away from danger. Please read the instruction before operating the machine:

1. Please read all user manuals before operating the machine, and operate the machine according to the instructions. Please keep the user manual until the machine is scrapped.
2. Keep users read and understand all cautions
3. Keep air fresh, flowing and enough motion space for users when operating the machine.
4. Keep the machine in good condition. Ensure all fixed parts are tightened without extra parts. Inspect the parts easy to wear out regularly.
5. Please contact the dealer or after-sales department to change wear-out or defective parts. DO NOT operate the machine when it out of use.
6. Please wear proper sports dress and gym shoes before operating it, DO NOT wear skirt, jewelry and tie up the hair to avoid any possible dangers.
7. Do warm-up exercises before operating the machine.
8. Stop workout and ask your doctor when any abnormal symptoms occurs such as headache, pain or emesis,

etc.

9. Children must exercise under the supervision of adults.

10. WARNING: Keep hands and feet away from moving parts.

11. WARNING: DO NOT beyond adjustable setting range.

12. WARNING: Keep baby or pets away from the machine when operating it.


13. WARNING: Keep all control apparatus in proper position.

14. WARNING: Please operate the machine in proper way, improper operating may not achieve workout effect of the machine, and lead to damage to your health.


15. Operating the machine in controlled area is recommended.

02/ASSEMBLY PROCEDURE

1) Step 1




Bill of materials			
No.	Name	Specification	Qty
1	Outer hexagonal bolt	M12X25	10
2	Split washer	Ø12	12
3	Drum washer	Ø12.5	11
4	Screw cap	Ø31*20.3	11
5	Outer hexagonal bolt	M12X20	2
6	Flat washer	Ø12	1
7	Gantry		1
8	Under connection support		1
9	Ground tube assembly		1
10	Fixed frame assembly		1




2) Step 2

Finished diagram





Bill of materials			
No.	Name	Specification	Qty
2	Split washer	Ø12	2
3	Drum washer	Ø12.5	1
4	Screw cap	Ø31*20.3	1
11	Hexagon pan head bolt	M12X25	1
12	Hexagon locknut	M12	1
13	Outer hexagonal bolt	M16X75	4
14	Hexagon locknut	M16	4
15	Flat washer	Ø16	8
16	Pin knob	Φ43*34*M8	2
17	Driving arm assembly		1
18	Armor	144*65*T4	2
19	Cam plate assembly		1
20	Kicking welding assembly		1
21	Rhombus seated bearing UCFLU205	GB/T7810-199	2
22	End cap	Φ43.5*14.5	1



3) Step 3

Bill of materials			
No.	Name	Specification	Qty
23	Hexagon pan head bolt	M10X25	2
24	Split washer	Ø10	2
25	Flat washer	Ø10	2
26	Hexagon CSK bolt	M10X65	2
27	Spring hanging	113*36*T6	1
28	Tension spring	Φ25*183*Φ2.2	1
29	Seat adjusting assembly		1
30	Adjusting plate	70*382*13	2
31	Stop block	26*39*25.5	2
32	Idler wheel	Φ70*78	1

Finished diagram




Bill of materials


No.	Name	Specification	Qty
2	Split washer	Ø12	2
3	Drum washer	Ø12.5	2

4) Step 4

Finished diagram



4	Screw cap	Ø31*20.3	2
5	Outer hexagonal bolt	M12X20	2
33	Hexagon pan head bolt	M8X25	8
34	Split washer	Ø8	8
35	Flat washer	Ø8	8
36	Seat	640*250*60	1
37	Leg cushion	600*470*60	1
38	Handle assembly		1




Bill of materials


No.	Name	Specification	Qty
23	Hexagon pan head bolt	M10X25	2

5) Step 5

Finished diagram




24	Split washer	Ø10	2
25	Flat washer	Ø10	2
39	Hexagon flat locknut	M8X10	4
40	Hexagon cylinder bolt	M6X15	6
41	Split washer	Ø6	6
42	Flat washer	Ø6	6
43	Hexagon pan head bolt	M5X12	8
44	Guide rod	¢ 20*1344	2
45	Guide rod fixing sleeve	Φ30*33	2
46	Safety board	1240*621.4*T2	1
47	Training flitch plate	415*174*T2	2
48	Weight stack	100Kg	1
49	Steel cable	¢ 6*4300	1



6) Step 6

Pulley installation instruction :



03/ PRODUCT DESCRIPTION

The machine is indoor fitness equipment, is suitable for aerobic exercise, mainly used to strength cardio-pulmonary function, and train the muscles supplemented. By workout with the machine pectorals and other muscles can be built up, achieve the purpose of bodybuilding and fitness.

The machine explains how to operate it properly and build up muscles by functional diagram, easy to learn.
User can adjust the resistance by weight stack easily.

The design and manufacture of the machine meets the human motion curve, the safety and durability are guaranteed.

The design and manufacture of the machine meets the human motion curve, and meets the standard of GB17498.1-2008 and GB17498.2-2008, the safety and durability are guaranteed.

·Large size steel tube and electrostatic spraying guarantee the safety and durability.

04/ PRODUCT PARAMETER

Name	Leg Extension	Model	S3010
Floor space	980*1200*1620	Weight stack	125Kg
Net weight	159Kg	Level	S
Category: S: Professional and Commercial; H: household			

05/ MAINTENANCE GUIDELINE

1. All the bolts and screws should be inspected regularly and keep tightened, rotating parts should be flexible without abnormal sound.
2. The machine should be keep clean. Please DO NOT clean the machine with strong cleaning solvent.
3. Any worn or damaged stress parts should be repaired or changed immediately.

06/ TROUBLESHOOTING

07/ WARRANTY INSTRUCTION

1. Warranty scope

The machine is damaged by any non-impersonal factors under proper maintenance. The warranty card is valid only when the user is original buyer.

2. The warranty period is one year since buying the machine.

3. The below-listed damages are out of warranty:

- 1). the damages caused by abuse, carelessness, accident or unauthorized modify.
- 2). the damages caused by improper adjusting weight stack pin.
- 3). the damages caused by improper maintenance.
- 4). the damages caused by other violation operating.