



Getac



K120G3 SM Parts For Centrica

May, 2024



CONFIDENTIALITY NOTICE

All contents / materials of this presentation contain important management and technical information and are proprietary and confidential information of Getac Technology Corporation and its subsidiaries. Leaking or forwarding any content / material of this presentation is strictly prohibited.

All contents / materials of this event are intended for viewing by the attendees only. Photograph and recording are prohibited throughout the presentation.

Photos or recordings taken on-site may result in immediate deletion of the contents and the attendees may be asked to leave this presentation immediately.

THIS IS A COVER SHEET FOR CONFIDENTIAL INFORMATION



CONFIDENTIALITY

Level 3

This document is confidential and contains proprietary information and intellectual property of Getac Technology Corporation and its subsidiaries (“Getac Group”). Neither this document nor any of the information contained herein may be reproduced or disclosed under any circumstances without prior express written permission of Getac Group. Please be aware that disclosure, copying or distribution of this document and the information contained therein is strictly prohibited.

All Getac Employees handling this document must be in accordance with most up-to-date Confidentiality Policy of Getac Group.

THIS IS A COVER SHEET FOR CONFIDENTIAL INFORMATION

Content

- Battery Pack (P/N 541314460120)
- AC Adapter & Power Cord (P/N 442GB2000003 & 332800003012)
- Protection Film (P/N 319142000002)
- Stylus & String (P/N 340142000064 & 340GA3400011)
- Smart Cart Door (Dummy P/N 344142000076 P/N 340GB1900046)
- AUDIO&THUNDERBOLT&SIM Door (P/N 340GB1900043)
- SSD DOOR (P/N 340GB1900044)
- SSD (P/N 5811GB190002)

Battery Pack (P/N 541314460120)

Slide the security lock of the battery release latch to the unlocked position (1) Slide the lock of the battery release latch upwards to the unlocked position (2) Slide the battery release latch toward the left .The battery pack will slightly pop up. Remove the battery pack from its compartment.



AC Adapter & Power Cord (P/N 442GB2000003 & 332800003012)

Accessory-AC Adapter & Power Cord




442GB2000003



332800003012

Protection Film (P/N 319142000002)

Accessory-Protection film



319142000002

Stylus & String (P/N 340142000064 & 340GA3400011)

Accessory- Stylus & String



340142000064



340GA3400011

Smart Cart Door (Dummy P/N 344142000076 P/N 340GB1900046)

1. Remove the two screws from the Smart Cart door, then remove the Smart Cart door.
2. Assemble back the new one.



340GB1900046

AUDIO&THUNDERBOLT&SIM Door (P/N 340GB1900043)

- 1.Remove the one screw lock the Audio&Thunderbolt&Sim door, then remove the Audio&Thunderbolt&Sim door.
2. Assemble back the new one.



340GB1900043

SSD Door (P/N 340GB1900044)

1. Remove the one screw lock the SSD door, then remove the SSD door.
2. Assemble back the new one.



340GB1900044

SSD (P/N 5811GB190002)

1. Locate the SSD canister and open its protective cover.
2. Pry the plastic strip to release it.
3. Using the plastic strip, pull the SSD canister out of the slot.



Remove SSD (P/N 5811GB190002)

1.Remove the two screws and one screw lock the SSD cover.



2. Remove the SSD cover and lever.



Remove SSD (P/N 5811GB190002)

1. Remove the SSD and connect board.



2. Pull out the SSD from the connector board.



Assemble SSD (P/N 5811GB190002)

1. Set the New SSD to the connect board; push the SSD towards the connector to seat it firmly.
2. Put the thermal pad(345128700102 & 345GA0200008) on the flash driver.



3. Set the SSD and connect board to the cover.
4. Fix the cover using the two screws (371102010432) and one screw (371102610025)
5. Noting the orientation, insert the new SSD canister all the way into the slot.



Assemble SSD (P/N 5811GB190002)

6. Make sure the plastic strip is engaged. Slide the plastic strip toward the locked position.



Incorrect (revealing the red part)



Thank You for Your Attention

