

# ***Dell Pro 16 (PC16250)***

---

## **Contents**

Features of the Dell Pro 16 (PC16250) .....	2
Performance & AI .....	2
Design & Durability .....	2
Display & Visuals.....	2
Connectivity .....	2
Smart Security .....	3
Battery & Charging.....	3
Touchpad Gestures (Windows Precision Touchpad).....	4
Keyboard Shortcut Highlights (Fn Key) .....	5
Full Keyboard Shortcuts for the Dell Pro 16 (PC16250).....	5
Function Key Primary Behavior .....	6

# *Features of the Dell Pro 16 (PC16250)*

---

## Performance & AI

- Powered by Intel Core Ultra processors with an integrated Neural Processing Unit (NPU).
  - Designed to handle AI-driven workloads and enhance productivity through intelligent task optimization.
  - Includes a dedicated Microsoft Copilot key for quick access to AI-powered assistance.
- 

## Design & Durability

- Premium, rigid aluminum chassis built for professional environments.
  - Engineered for durability while maintaining a sleek, modern design.
- 

## Display & Visuals

- 16-inch display with a 16:10 aspect ratio for increased vertical workspace.
  - Provides more viewing area for documents, spreadsheets, coding, and reading compared to traditional 16:9 displays.
- 

## *Connectivity*

---

- Modern connectivity options including:
- Thunderbolt 4 (USB Type-C) for high-speed data transfer, docking, and charging.
- HDMI 2.1 for high-resolution external display support.
- RJ-45 port (Ethernet)


#### Right view

- 1 USB 3.2 Gen 1 Type-A
- 2 USB 3.2 Gen 1 Type-A with PowerShare
- 3 RJ45 Ethernet port, 1GbE
- 4 Wedge-shaped lock slot

#### Left View

- 5 4.5mm barrel power delivery
- 6 HDMI 2.1
- 7 USB Type-C Thunderbolt™ 4 with Power Delivery 3.1 & DisplayPort™ 2.1
- 8 USB Type-C with Power Delivery 3.1 & DisplayPort™ 2.0
- 9 Global Headset Jack
- 10 Smart Card Reader (optional)<sup>[22]</sup>

### Ports and slots



## Smart Security

- Full HD (1080p) webcam with manual sliding privacy shutter.
- Optional IR camera for Windows Hello facial recognition (model dependent).
- Optional fingerprint reader integrated into the power button (model dependent).

## Battery & Charging

- Supports ExpressCharge technology for rapid battery charging.
  - Designed to minimize downtime and improve productivity.
- 

## ***Touchpad Gestures (Windows Precision Touchpad)***

---

- One-Finger Tap: Left-click
  - Two-Finger Tap: Right-click
  - Two-Finger Drag: Scroll vertically or horizontally
  - Two-Finger Pinch: Zoom in or out
  - Three-Finger Tap: Open Search
  - Three-Finger Swipe Up: Open Task View (all open windows)
  - Three-Finger Swipe Down: Show desktop
  - Three-Finger Swipe Left / Right: Switch between open applications
  - Four-Finger Swipe Left / Right: Switch between virtual desktops
-

## ***Keyboard Shortcut Highlights (Fn Key)***

---

- Fn + Esc: Toggle Fn Lock (switch between multimedia and standard function keys)
  - Fn + F1: Mute / Unmute audio
  - Fn + F2 / F3: Decrease / Increase volume
  - Fn + F4: Microphone Mute
  - Fn + F5: Keyboard backlight control
  - Fn + F6 / F7: Decrease / Increase screen brightness
  - Fn + F8: Switch to external display
  - Fn + F10: Print Screen
  - Fn + F12: End
- 

## ***Full Keyboard Shortcuts for the Dell Pro 16 (PC16250)***

---

Note: Keyboard characters may vary depending on the selected language, but shortcut key functions remain the same across all configurations.

Some keys include two symbols. Pressing the key alone types the lower symbol, while pressing Shift + the key types the upper symbol. For example:

Pressing 2 types 2

Pressing Shift + 2 types @

The F1–F12 keys on the top row serve as multimedia function keys, as indicated by the icons printed on them. Press the corresponding function key to perform the labeled action.

---

## ***Function Key Primary Behavior***

---

<b>Function Key</b>	<b>Primary Behavior</b>
F1	Mute or unmute audio
F2	Decrease volume
F3	Increase volume
F4	Mute or unmute microphone
F5	Keyboard backlight control
F6	Decrease screen brightness
F7	Increase screen brightness
F8	Switch to external display
F10	Print Screen
F11	Home
F12	End