





SF - 036 REV1

DATE: August 27, 2018

TO: All Service and Parts Managers SUBJECT: Low Voltage Board Connectors

The communicating controls in Goodman's Furnaces, Split Condensers, Heat Pumps and Air-Handlers are shipped with the required Phoenix connectors needed for connecting the low voltage wiring to these units. However we understand these connectors can from time to time get misplaced preventing you from completing the installation; therefore we have made these connectors available through service parts. Please refer to the following list for part numbers when ordering connectors:

Furnace and Air-Handler 9 pin connector: # F043067300S Split Condenser or Heat Pump 7 pin connector: # F043067500S Communicating mode 4 pin connector: # F043067900S





August 2018 Revision:

ComfortBridge™ Control Platform Furnace 6 pin Connector: # F043068000S



These connectors are in stock and available from Goodman Service Parts.

T: 888-593-9988 | F: 713-316-5541