

How to Switch Inputs and Outputs on the Arvitek Matrix Switcher in Room 406 & 410

Using using the Front Panel

1. Select an Input

Press the button for the input you want to use:

- Input 01 – **Mac**
- Input 02 – **PC**
- Input 03 – **Personal Device**

The LED for that input will light up to confirm your selection.



2. Select an Output and press Enter

Next, press the button for the output where you want that input to appear, then press Enter [You can also select ALL to send content to Projector, TV1, and TV2]

- Output 01 – **Projector**
- Output 02 – **TV01**
- Output 03 – **TV02**

