

SimplicityTouch




TROUBLESHOOTING a VGA image shift:

IF you are connecting to the panel via the VGA port of your computer and the screen displays to the left side of the panel screen with a black bar running down the right side, follow these steps:



STEP 1: Select the On-Screen Menu by selecting the GEAR icon on the panel buttons OR select the MENU button on the remote control. When the menu appears, it should already be in the PICTURE settings. Scroll down until you see "SCREEN" and select.

STEP 2: Once the SCREEN menu appears, select AUTO TUNE at the bottom.



STEP 3: Upon completion, your computer image should appear full screen. You may need to power the panel off and back on to see the results.