

How to start a meeting in Google Meet on your Owl

This article applies to the **Meeting Owl Pro** and **Meeting Owl**

After setting up your Meeting Owl ([//owl-labs.helpscoutdocs.com/article/177-get-started-with-your-owl](https://owl-labs.helpscoutdocs.com/article/177-get-started-with-your-owl)), start your first meeting in Google Meet.

Using Meeting Owl with Google Meet



0:38

1. Plug your USB cable into the Owl, and then into the computer.
2. Plug in your Owl's power adapter and wait until Owl's eyes stop pulsing.
3. Open Meet and join a meeting.
4. Select **More Options** (



) on the bottom right of the screen.

5. Select **Settings** (
English

[Need help?](#)



).

6. Select **Meeting Owl** for your Video, Microphone and Speaker.

7. Start your meeting.

✉ *Still need help? Contact Us (/contact)*

Last updated on May 19, 2021

© Owl Labs (<https://www.owl-labs.com>) 2022. Powered by Help Scout (https://www.helpscout.com/knowledge-base/?utm_source=docs&utm_medium=footerlink&utm_campaign=Docs+Branding)