


# Speed 3

ORIGINALITY DESIGN SMART – AND BEAUTIFUL

.....



## QUICK GUIDE



## What's in the box

Consult the checklist below for all components.



Speed 3



Power adapter



USB cable



Bracket



Adhesive tape




Screws



I/M



protective strip



Bottom of camera

## Description

Power	DC5V $\pm$ 10%
-------	----------------

Status light	<ul style="list-style-type: none"> <li>• Red light solid on: the camera network is abnormal</li> <li>• Red light blinked: awaiting WiFi connection, or currently connecting (faster blinking)</li> <li>• Blue light solid on: camera running correctly</li> <li>• Blue light blinked: awaiting manual WiFi configuration, or currently connecting (faster blinking)</li> </ul>
--------------	--


Microphone	Captures sound for your video
------------	-------------------------------

SD card slot	Supports local SD Card storage (Max.128G)
--------------	---


Reset	<p>Press and hold the 'reset' for 5 seconds to reset the device(if you have modified settings, they will return to factory defaults)</p> <p>Pressing for 1 second will activate manual WiFi setup mode</p>
-------	--

## Install

- 1 Use the included mounting bracket to fix the camera to a clean surface.




Step 1 Use the marker to draw the positions of the 2 screw holes on the wall surface to be installed.



Step 2 Screw 2 expansion screws into the newly marked position.




Step 3 Fix the mounting bracket to the wall.



Step 4 Snap camera base into bracket



- 2 Or, stick the camera to an inclined surface with the adhesive tape we provided.



If required ,you can apply the protective strip on Camera's edge to avoid any damage or hurt,



Step 1



Step 2



Step 3



Step 4

## Connect

### Download

CloudEdge is available for both iOS and Android OS. Search the name 'CloudEdge' in App Store or Android Market, or scan upper QR-Code to download the App.

#### • Support





### Set up router

This product only supports 2.4GHz frequency band router, does not support 5GHz frequency band router, please set the relevant parameters of the router before WiFi configuration, WiFi passwords do not include special characters such as ~!@#\$\$%^&\*(). When the device is configured in WiFi, the mobile phone and device are as close as to the router, which can speed up the configuration of the device.





## Registration process

- Step 1 Open the CloudEdge App, click 'SIGN UP', input a valid email address and select 'registration means agreement with user agreement privacy agreement' then click 'NEXT'.



- Step 2 Enter the email address and click 'OK', create a nickname and login password.



Note: Make sure your router, device, and mobile phone are nearby.


## QR Code Configuration

### Few notices before adding the device

1. This device only supports 2.4GHz WiFi router, please make sure you are using a 2.4GHz WiFi router.
2. Please follow the instructions and make sure the password is inputted correctly.
3. One device can only be added with one App account, if the device has been added with another account already, then it can't be added to any another account again.

### Process

Step 1 Open the CloudEdge App, click '+', and select the type of device to add.



Tap to add devices and select the two ways in the next step

Step 2 Please confirm the red LED light blinks, select 'The device has flashed red slowly or you hear a tone', click 'Next'. Then input the wireless password, click 'Next'.



1. After powering on the device, wait until the device starts
2. Make sure the status indicator changes from steady red to slow red, or hear the device prompt: "Please configure wireless network for camera".

[Descriptions for Status light](#)

- ✓ The device has flashed red slowly or you hear a tone

Next

Please fill in the wireless network to be connected  
Please ensure that the mobile phone is connected to the 2.4G WiFi network.

XXXXXXX

[Change WiFi](#)

\*\*\*\*\*

[Show password](#)

Next

**Step 3** The device is scanning the QR code at a distance of 15~25cm (you can click the 'operation' to view the scanning mode). After the device scans successfully, click 'Hear tone'.

#### Equipment scanning QR code

The distance between the two-dimension code is about 15~25cm, and the device scans the two-dimensional code and it will send a tone




Did not hear the tone

[Hear tone](#)




Please point the QR code in the screen of the mobile phone towards the device and keep the distance of about 15~25cm. Wait for the device to scan the QR code on the mobile phone.

Step 4 The device is successfully connected to the network. After the configuration is completed, the App automatically adds the successfully scanned device, and return to the device list. The configuration is completed.



Step 5 Click the play button to complete the preview. (Remind: long press the image to be previewed to remove the device, add device again to reset the device)



## Functions

### Pan/Tilt

Rotate your camera by sliding on your smartphone, providing you with 360 degrees of vision.

### Video flip

Flip your video stream up or down for maximum flexibility.

### Motion detection


Built-in motion sensors detect movement, and the camera will send you push notifications and app alerts.

### Record

Support 24H continuous recording with high capacity SD storage.

### Day & Night

Never miss a moment, even in complete darkness, with powerful night-vision technology.



Daytime



Night

Q: The device cannot be previewed properly?

A: Check whether the network is normal, you can place the camera close to the router, and if not, it is recommended to reset the device and add it again.

Q: Why is it still in the list of devices after resetting?

A: The reset device only resets the network configuration of the camera, but cannot change the configuration on the App, remove the camera, and must be deleted by the App.

Q: How to cut the camera network to another router?

A: First remove and reset the device on the App and then configure the device again by the App.

Q: Why doesn't the device identify the SD card?

A: It is recommended to plug in SD card after power cut. Confirm whether the SD card is normally available and the format is FAT32. And the TF card can't be identified when the internet environment is not good.

Q: Why I can't get the notifications with my cell phone App?

A: Please confirm that the App has been running on the phone, and the relevant reminder function has been opened; Message notification and authority confirmation in the mobile phone system have been opened.