


SERIES 2000™ NOTE VALIDATOR MODEL AE2600 CONFIGURATION COUPON | UNITED STATES - USD



 This document is used with the Series 2000 note validator model AE2600 and the Series 2000 installation guide. Copy or print this page on a standard, carbon-based, black-and-white copier/printer. Copy or print on U.S. letter size (8.5 in x 11 in / 215.9 mm x 279.4 mm) paper at 100% scale for the coupon to properly function. When using a different paper size, make sure the coupon copies or prints at the dimensions provided below for it to properly function.

To prepare the configuration coupon:

- Carefully cut out the coupon. The coupon should be the same size as a US note when complete.
- Use the table below as a guide for filling out the configuration coupon. Use an HB or No.2 pencil to fill out each line of the coupon. Only fill 1 block on each line and completely fill each block as dark as possible. Do not make marks outside of the blocks or on the back of the coupon.


Section	Select Preference for:	Description
1	# Of Bill Directions	Select 1 of the following: <ul style="list-style-type: none"> 1 – Accept bills face up in 1 direction (green seal first). 2 – Accept bills face up in either direction. 4 – Accept bills face up or down in either direction.
2	Bill Denomination	Fill in one block for each denomination. <ul style="list-style-type: none"> High Accept – For maximum bill acceptance. Select High Security – For a higher level of discrimination. OFF – To reject bills of that denomination.
3	Pulse	Set the width of the pulse. Select 1 of the following for pulse timing: <ul style="list-style-type: none"> Short – 50 milliseconds (ms) on / 50 milliseconds (ms) off. Long – 60 milliseconds (ms) on / 300 milliseconds (ms) off. Credit Line Vending Only – 30 milliseconds (ms) on / 50 milliseconds (ms) off (Not available on 12V battery models). Check with your host machine manufacturer for details.
4	Pulses per dollar	Set credit pulses per dollar accepted. Most vending machines use 1 pulse per dollar. Most gaming and lottery machines use 4 pulses per dollar.
5	Interface Selection	Select 1 of the following: <ul style="list-style-type: none"> Vending – Requires an input from the controller to enable and accept bills. Gaming Always Enable – Allows for acceptance at all times. A host or controller cannot disable the unit. Gaming – Allows for acceptance at during gaming. A host or controller can disable the unit.

2.60 in (66 mm)

Insert this end first

USE #2 Pencil
Photocopy can
be used

6.14 in (156 mm)



Carefully cut on the dotted line. The coupon should be the same size as a US note when complete.

Complete sections
1-5 ONLY

USE #2 Pencil
Photocopy can
be used

7

1

2

3

4

5

6

Of Bill
Directions

1

2

4

High
Accept

High
Security

OFF

Short

Long

Credit Line
Vending Only

1

2

3

4

Vending

Gaming

Always
Enable

\$1 **\$2** **\$5** **\$10** **\$20**

250056078

Model AE2600
Configuration
Coupon 001

