

# Field Guide

## LEAFTECH AG SCANNER

### START UP

- ✓ On your cellular device:
  - ✓ Turn off Wi-Fi
  - ✓ Turn on Bluetooth
  - ✓ Enable:
    - ✓ Android: Bluetooth tethering
    - ✓ Apple: Hotspot with maximize compatibility enabled
  - ✓ Turn on location services
- ✓ Power on scanner  
(flip switch)
- ✓ Wait for blue light to flash 2x.  
(~45 seconds)

### CONNECT

- ✓ Pair scanner via phone's Bluetooth menu
- ✓ Open Leaftech Ag App
- ✓ Select "Connect to a Paired Leaftech Device"
- ✓ Select your scanner
- ✓ Calibrate scanner & confirm connection:
  - ✓ Ensure scan bed is clean, clear of debris, and closed
  - ✓ Press Calibrate

### SCAN

- ✓ Enter all in-field inputs
- ✓ Place leaf on scanner bed and close bed
- ✓ Select Scan
- ✓ Accept or reject scan

#### IMPORTANT

- Scans may take up to 30 seconds to load
- If no internet connection, a blank screen will appear
- Once accepted the scan will be stored on your device

### SHUT DOWN DO NOT FLIP THE POWER SWITCH BEFORE FOLLOWING THE STEPS

- ✓ Select Shutdown in app
- ✓ Follow shut down prompts
- ✓ Flip power switch